


Powerware Series

**Eaton® 9395 UPS**  
**1000–1100 kVA**  
**Installation and Operation Manual**

For use with Three UPM (650–825 kVA) and Four UPM (1000–1100 kVA) UPS Models



**EATON**

*Powering Business Worldwide*



Powerware Series

**Eaton® 9395 UPS**  
**1000–1100 kVA**  
**Installation and Operation Manual**

For use with Three UPM (650–825 kVA) and Four UPM (1000–1100 kVA) UPS Models



*Powering Business Worldwide*

## **IMPORTANT SAFETY INSTRUCTIONS SAVE THESE INSTRUCTIONS**

---

This manual contains important instructions that you should follow during installation and maintenance of the UPS and batteries. Please read all instructions before operating the equipment and save this manual for future reference.

---

## **CONSIGNES DE SÉCURITÉ IMPORTANTES CONSERVER CES INSTRUCTIONS**

---

Ce manuel comporte des instructions importantes que vous êtes invité à suivre lors de toute procédure d'installation et de maintenance des batteries et de l'onduleur. Veuillez consulter entièrement ces instructions avant de faire fonctionner l'équipement et conserver ce manuel afin de pouvoir vous y reporter ultérieurement.

---

### **WARNING**



This is a product for restricted sales distribution to informed partners (EN/IEC 62040-2). Installation restrictions or additional measures may be needed to prevent electromagnetic disturbances.

---

Eaton, X-Slot, LanSafe, PowerXpert, and Powerware HotSync are registered trademarks and ConnectUPS is a trademark of Eaton Corporation or its subsidiaries and affiliates. IBM and AS/400 are registered trademarks of International Business Machines Corporation. Modbus is a registered trademark of Schneider Electric. National Electrical Code and NEC are registered trademarks of National Fire Protection Association, Inc. All other trademarks are property of their respective companies.

©Copyright 2008-2009 Eaton Corporation, Raleigh, NC, USA. All rights reserved. No part of this document may be reproduced in any way without the express written approval of Eaton Corporation.

# Table of Contents

<b>1</b>	<b>Introduction</b>	<b>1-1</b>
1.1	UPS Standard Features	1-2
1.1.1	Installation Features	1-2
1.1.2	Control Panel	1-2
1.1.3	Customer Interface	1-3
1.1.4	Advanced Battery Management	1-3
1.1.5	Power Management Software	1-4
1.2	Options and Accessories	1-4
1.2.1	Field Installed UPM	1-4
1.2.2	Sync Control	1-4
1.2.3	Single-Feed Kit	1-4
1.2.4	Distributed Bypass System	1-4
1.2.5	Input Output Module Configuration	1-5
1.2.6	Continuous Static Switch	1-5
1.2.7	Inherent Redundancy	1-5
1.2.8	Energy Saver and High Alert Modes	1-5
1.2.9	Advanced Power Management and High Alert Modes	1-6
1.2.10	Monitoring and Communication	1-6
1.3	Battery System	1-7
1.4	Basic System Configurations	1-7
1.5	Using This Manual	1-8
1.6	Conventions Used in This Manual	1-8
1.7	Symbols, Controls, and Indicators	1-9
1.8	For More Information	1-9
1.9	Getting Help	1-10
<b>2</b>	<b>Safety Warnings</b>	<b>2-1</b>
<b>Section I – Installation</b>		
<b>3</b>	<b>UPS Installation Plan and Unpacking</b>	<b>3-1</b>
3.1	Creating an Installation Plan	3-1
3.2	Preparing the Site	3-1
3.2.1	Environmental and Installation Considerations	3-1
3.2.2	UPS System Power Wiring Preparation	3-9
3.2.3	UPS System Interface Wiring Preparation	3-21
3.2.4	Distributed Bypass Power Wiring Preparation	3-23
3.3	Inspecting and Unpacking the UPS Cabinets	3-24
<b>4</b>	<b>UPS System Installation</b>	<b>4-1</b>
4.1	Preliminary Installation Information	4-1
4.2	Unloading the UPS Sections from the Pallet	4-1
4.3	Mechanically Joining the Sections	4-5
4.4	Electrically Connecting the Sections	4-8
4.5	Field Installed UPM Installation	4-16
4.6	Battery System Installation	4-16
4.7	Distributed Bypass Tie Cabinet Installation	4-16

4.8	Installing UPS External and Battery Power Wiring . . . . .	4-17
4.8.1	External Power Wiring Installation . . . . .	4-17
4.8.2	Battery Power Wiring . . . . .	4-24
4.9	Installing Interface Connections . . . . .	4-27
4.9.1	TB1, TB2, and TB3 Connections (Other than TB1 Battery Interface Connections) . . . . .	4-27
4.9.2	TB1 Battery Interface Connections . . . . .	4-32
4.9.3	X-Slot Connections . . . . .	4-34
4.10	Installing a REPO Switch . . . . .	4-35
4.11	Installing Options, Accessories, and Distributed Bypass Control Wiring . . . . .	4-38
4.12	Initial Startup . . . . .	4-38
4.13	Completing the Installation Checklist . . . . .	4-38
<b>5</b>	<b>Installing Options and Accessories . . . . .</b>	<b>5-1</b>
5.1	Installing an Optional Powerware Hot Sync CAN Bridge Card . . . . .	5-1
5.2	Installing Distributed Bypass Control Wiring . . . . .	5-4
5.3	Installing an Optional Remote Monitor Panel II . . . . .	5-9
5.4	Installing an Optional Relay Interface Module II . . . . .	5-11
5.5	Installing an Optional Supervisory Contact Module II . . . . .	5-13
5.6	Accessory Mounting Dimensions . . . . .	5-15
<b>Section II – Operation</b>		
<b>6</b>	<b>Understanding UPS Operation . . . . .</b>	<b>6-1</b>
6.1	UPS System Overview . . . . .	6-1
6.2	Single UPS . . . . .	6-2
6.2.1	Modes . . . . .	6-2
6.2.2	Normal Mode . . . . .	6-3
6.2.3	Energy Saver Mode . . . . .	6-4
6.2.4	Advanced Power Management . . . . .	6-4
6.2.5	Bypass Mode . . . . .	6-5
6.2.6	Battery Mode . . . . .	6-6
6.3	Single UPS Unit System Online Configurations . . . . .	6-8
6.4	Multiple UPS Distributed Bypass System . . . . .	6-20
6.4.1	Multiple UPS Parallel System Modes . . . . .	6-20
6.4.2	Normal Mode – Distributed Bypass . . . . .	6-21
6.4.3	Bypass Mode – Distributed Bypass . . . . .	6-22
6.4.4	Battery Mode – Distributed Bypass . . . . .	6-24
6.5	Multiple UPS Distributed Bypass System Online Configurations . . . . .	6-25
<b>7</b>	<b>UPS Operating Instructions . . . . .</b>	<b>7-1</b>
7.1	UPS Controls and Indicators . . . . .	7-1
7.1.1	Control Panel . . . . .	7-2
7.1.2	Circuit Breakers . . . . .	7-2
7.2	Using the Control Panel . . . . .	7-2
7.2.1	Status Indicators . . . . .	7-3
7.2.2	System Events . . . . .	7-3
7.2.3	Using the LCD and Pushbuttons . . . . .	7-4
7.2.4	Using the Menu . . . . .	7-5
7.2.5	Mimic Screen . . . . .	7-5
7.2.6	Display Menu Operation . . . . .	7-6
7.2.7	Load Off Screen . . . . .	7-9
7.2.8	System Status Screen and Controls . . . . .	7-10

7.3	Single UPS Operation	7-12
7.3.1	Starting the UPS in Normal Mode	7-12
7.3.2	Enable Energy Saver Mode from the UPS Command Menu	7-13
7.3.3	Disable Energy Saver Mode from the UPS Command Menu	7-13
7.3.4	Start Energy Saver High Alert Mode from the UPS Command Menu	7-14
7.3.5	Enable Advanced Power Management Mode from the UPS Command Menu	7-14
7.3.6	Disable Advanced Power Management Mode from the UPS Command Menu	7-15
7.3.7	Start Advanced Power Management High Alert Mode from the UPS Command Menu	7-15
7.3.8	Starting the UPS in Bypass Mode	7-16
7.3.9	Enable Energy Saver Mode from the Bypass Command Menu	7-17
7.3.10	Disable Energy Saver Mode from the Bypass Command Menu	7-17
7.3.11	Start Energy Saver High Alert Mode from the Bypass Command Menu	7-18
7.3.12	Enable Advanced Power Management Mode from the Bypass Command Menu	7-18
7.3.13	Disable Advanced Power Management Mode from the Bypass Command Menu	7-19
7.3.14	Start Advanced Power Management High Alert Mode from the Bypass Command Menu	7-19
7.3.15	Starting the UPMs	7-20
7.3.16	Starting a Single UPM	7-21
7.3.17	Transfer from Normal to Bypass Mode	7-22
7.3.18	Transfer from Bypass to Normal Mode	7-23
7.3.19	Transfer from Normal to Bypass Mode and Shut Down UPMs	7-23
7.3.20	Single UPM Shutdown	7-24
7.3.21	Single UPM Restart	7-24
7.3.22	UPS and Critical Load Shutdown	7-25
7.3.23	Charger Control	7-25
7.3.24	Using the UPS LOAD OFF Pushbutton or Command	7-26
7.3.25	Using the Remote Emergency Power-off Switch	7-28
7.4	Multiple UPS Distributed Bypass Operation	7-29
7.4.1	Starting the Distributed Bypass System in Normal Mode	7-29
7.4.2	Enable Energy Saver Mode from the UPS Command Menu	7-30
7.4.3	Disable Energy Saver Mode from the UPS Command Menu	7-30
7.4.4	Start Energy Saver High Alert Mode from the UPS Command Menu	7-31
7.4.5	Enable Advanced Power Management Mode from the UPS Command Menu	7-31
7.4.6	Disable Advanced Power Management Mode from the UPS Command Menu	7-32
7.4.7	Start Advanced Power Management High Alert Mode from the UPS Command Menu	7-32
7.4.8	Starting the Distributed Bypass System in Bypass Mode	7-33
7.4.9	Enable Energy Saver Mode from the Bypass Command Menu	7-34
7.4.10	Disable Energy Saver Mode from the Bypass Command Menu	7-34
7.4.11	Start Energy Saver High Alert Mode from the Bypass Command Menu	7-35
7.4.12	Enable Advanced Power Management Mode from the Bypass Command Menu	7-35
7.4.13	Disable Advanced Power Management Mode from the Bypass Command Menu	7-36
7.4.14	Start Advanced Power Management High Alert Mode from the Bypass Command Menu	7-36
7.4.15	Starting the UPS UPMs	7-37
7.4.16	Starting a Single UPM	7-38
7.4.17	Transfer from Normal to Bypass Mode	7-39
7.4.18	Transfer from Bypass to Normal Mode	7-40
7.4.19	Transfer from Normal to Bypass Mode and Shut Down UPMs	7-40
7.4.20	Single UPM Shutdown	7-41
7.4.21	Single UPM Restart	7-41
7.4.22	Single UPS Shutdown using Load Off	7-42
7.4.23	Single UPS Shutdown using UPM Shutdown	7-43
7.4.24	Single UPS Restart	7-44

7.4.25	UPS and Critical Load Shutdown .....	7-45
7.4.26	Charger Control .....	7-46
7.4.27	Using the UPS LOAD OFF Pushbutton or Command .....	7-46
7.4.28	Using the Remote Emergency Power-off Switch .....	7-48
<b>8</b>	<b>Communication .....</b>	<b>8-1</b>
8.1	X-Slot Cards .....	8-1
8.2	eNotify Service .....	8-2
8.2.1	eNotify Service Features .....	8-2
8.2.2	Installing eNotify Service .....	8-2
8.3	Eaton LanSafe Power Management Software .....	8-3
8.4	Remote Notification .....	8-3
8.5	Terminal Mode .....	8-4
8.5.1	Display UPS Control Panel .....	8-4
8.5.2	Event History Log .....	8-5
8.6	Building Alarm Monitoring .....	8-7
8.7	General Purpose Relay Contact .....	8-7
8.8	Remote Monitor Panel II .....	8-7
8.9	Relay Interface Module II .....	8-9
8.10	Supervisory Contact Module II .....	8-10
<b>9</b>	<b>UPS Maintenance .....</b>	<b>9-1</b>
9.1	Important Safety Instructions .....	9-1
9.2	Performing Preventive Maintenance .....	9-2
9.2.1	DAILY Maintenance .....	9-2
9.2.2	MONTHLY Maintenance .....	9-2
9.2.3	PERIODIC Maintenance .....	9-6
9.2.4	ANNUAL Maintenance .....	9-6
9.2.5	BATTERY Maintenance .....	9-6
9.3	Installing Batteries .....	9-6
9.4	Recycling the Used Battery or UPS .....	9-7
9.5	Maintenance Training .....	9-7
<b>10</b>	<b>Product Specifications .....</b>	<b>10-1</b>
10.1	Model Numbers .....	10-1
10.2	Specifications .....	10-1
10.2.1	UPS Input .....	10-1
10.2.2	UPS Output .....	10-2
10.2.3	UPS Environmental .....	10-2
	<b>Warranty .....</b>	<b>W-1</b>



## List of Figures

Figure 1-1. Eaton 9395 Four UPM UPS (1000–1100 kVA) . . . . .	1-2
Figure 1-2. Eaton 9395 Three UPM UPS (650–825 kVA) . . . . .	1-3
Figure 3-1. UPS Cabinet Dimensions – Three UPM (Front View) . . . . .	3-4
Figure 3-2. UPS Cabinet Dimensions – Four UPM (Front View) . . . . .	3-4
Figure 3-3. UPS Cabinet Dimensions (Right Side View) . . . . .	3-5
Figure 3-4. ISBM Section Dimensions (Front View) . . . . .	3-5
Figure 3-5. UPM Section Dimensions (Front View) . . . . .	3-6
Figure 3-6. UPM Section Dimensions (Top View) . . . . .	3-6
Figure 3-7. ISBM Section Dimensions (Top View) . . . . .	3-7
Figure 3-8. ISBM Section Dimensions (Bottom View) . . . . .	3-7
Figure 3-9. ISBM Section Center of Gravity . . . . .	3-8
Figure 3-10. UPM Section Center of Gravity . . . . .	3-8
Figure 3-11. Remote EPO Switch Dimensions . . . . .	3-9
Figure 3-12. UPS Cabinet as Shipped on Pallet (ISBM Section) . . . . .	3-25
Figure 3-13. UPS Cabinet as Shipped on Pallet (UPM Section) . . . . .	3-26
Figure 4-1. Removing the ISBM Section Left Side Shipping Bracket . . . . .	4-2
Figure 4-2. Removing the ISBM Section Right Side Shipping Bracket . . . . .	4-3
Figure 4-3. Removing the UPM Section Left Side Shipping Bracket . . . . .	4-4
Figure 4-4. Removing the UPM Section Right Side Shipping Bracket . . . . .	4-5
Figure 4-5. Section Joining . . . . .	4-6
Figure 4-6. ISBM and UPM Sections Joined . . . . .	4-7
Figure 4-7. ISBM Section to UPM Section Joining Brackets . . . . .	4-8
Figure 4-8. ISBM Section Intercabinet Power Terminal Locations . . . . .	4-11
Figure 4-9. ISBM Section Input Power Terminal Detail . . . . .	4-12
Figure 4-10. ISBM Section Battery Input Power Terminal Detail . . . . .	4-13
Figure 4-11. ISBM Section Output Power Terminal Detail . . . . .	4-13
Figure 4-12. UPS Intercabinet Interface Harness Locations . . . . .	4-14
Figure 4-13. PI1 Interface Board Location . . . . .	4-15
Figure 4-14. J39 Location on PI1 Interface Board . . . . .	4-15
Figure 4-15. ISBM and UPM Section Debris Shields . . . . .	4-18
Figure 4-16. ISBM Section Conduit and Wire Entry Locations . . . . .	4-19
Figure 4-17. Distributed Bypass Wire Length . . . . .	4-21
Figure 4-18. ISBM Section Power Terminal Locations . . . . .	4-22
Figure 4-19. ISBM Section Power Terminal Detail AA . . . . .	4-23
Figure 4-20. ISBM Section Power Terminal Detail BB – Common Battery . . . . .	4-25
Figure 4-21. ISBM Section Power Terminal Detail BB – Separate Battery . . . . .	4-26
Figure 4-22. ISBM Section Interface Terminal Locations . . . . .	4-28
Figure 4-23. Interface Terminal Detail . . . . .	4-30
Figure 4-24. Typical Alarm Relay Connection . . . . .	4-30
Figure 4-25. Terminal Blocks TB1, TB2, and TB3 Connector Assignments . . . . .	4-31
Figure 4-26. Typical Battery Interface Connection – Common Battery System . . . . .	4-33
Figure 4-27. Typical Battery Interface Connection – Separate Battery System . . . . .	4-33
Figure 4-28. X-Slot Communication Bays . . . . .	4-34
Figure 4-29. REPO Switch . . . . .	4-35
Figure 4-30. Normally-Open REPO Switch Wiring . . . . .	4-36
Figure 4-31. Normally-Closed REPO Switch Wiring . . . . .	4-37
Figure 4-32. Normally-Closed and Normally-Open REPO Switch Wiring . . . . .	4-38

Figure 5-1. Powerware Hot Sync CAN Bridge Card	5-1
Figure 5-2. Powerware Hot Sync CAN Bridge Card Connections	5-3
Figure 5-3. Distributed Bypass System CAN and Pull-Chain Simplified Interface Wiring	5-5
Figure 5-4. Distributed Bypass System UPS CAN Wiring without MOBs	5-5
Figure 5-5. Distributed Bypass Pull-Chain Wiring without MOBs	5-6
Figure 5-6. Distributed Bypass Pull-Chain Wiring with MOBs	5-7
Figure 5-7. Remote Monitor Panel II and Relay Interface Module II Terminal Locations	5-10
Figure 5-8. Remote Monitor Panel II, Relay Interface Module II, or Supervisory Contact Module II Wiring	5-10
Figure 5-9. J1, J2, J3, and J4 15-Pin D-Sub Connectors	5-12
Figure 5-10. Supervisory Contact Module II Terminal Location	5-13
Figure 5-11. Supervisory Contact Module II TB2	5-14
Figure 5-12. Remote Monitor Panel II Dimensions	5-15
Figure 5-13. Relay Interface Module II Dimensions	5-16
Figure 5-14. Supervisory Contact Module II Dimensions	5-17
Figure 6-1. Main Elements of the UPS System	6-1
Figure 6-2. Path of Current Through the UPS in Normal Mode	6-3
Figure 6-3. Path of Current Through the UPS in Bypass Mode	6-6
Figure 6-4. Path of Current Through the UPS in Battery Mode	6-7
Figure 6-5. UPS System – Four UPM, Common Rectifier Feed, Common Battery, Dual-Feed Configuration, Momentary Static Switch	6-9
Figure 6-6. UPS System – Four UPM, Common Rectifier Feed, Separate Battery, Dual-Feed Configuration, Momentary Static Switch	6-10
Figure 6-7. UPS System – Three UPM, Common Rectifier Feed, Common Battery, Dual-Feed Configuration, Momentary Static Switch	6-11
Figure 6-8. UPS System – Three UPM, Common Rectifier Feed, Separate Battery, Dual-Feed Configuration, Momentary Static Switch	6-12
Figure 6-9. UPS System – Four UPM, Common Rectifier Feed, Common Battery, Dual-Feed Configuration, Continuous Static Switch	6-13
Figure 6-10. UPS System – Four UPM, Common Rectifier Feed, Separate Battery, Dual-Feed Configuration, Continuous Static Switch	6-14
Figure 6-11. UPS System – Three UPM, Common Rectifier Feed, Common Battery, Dual-Feed Configuration, Continuous Static Switch	6-15
Figure 6-12. UPS System – Three UPM, Common Rectifier Feed, Separate Battery, Dual-Feed Configuration, Continuous Static Switch	6-16
Figure 6-13. UPS System – Four UPM Common Rectifier Feed, Common Battery, IOM Configuration	6-17
Figure 6-14. UPS System – Four UPM Common Rectifier Feed, Separate Battery, IOM Configuration	6-18
Figure 6-15. Simplified Dual-Feed UPS with Maintenance Bypass Panel	6-19
Figure 6-16. Path of Current through the UPSs in Normal Mode – Distributed Bypass	6-22
Figure 6-17. Path of Current through the UPSs in Bypass Mode – Distributed Bypass	6-23
Figure 6-18. Path of Current through the UPSs in Battery Mode – Distributed Bypass	6-24
Figure 6-19. Typical Distributed Bypass System – Momentary Static Switch, 1+1 and 2+0 Configurations	6-26
Figure 6-20. Typical Distributed Bypass System – Momentary Static Switch, 2+1 and 3+0 Configurations	6-27
Figure 6-21. Typical Distributed Bypass System – Momentary Static Switch, 3+1 and 4+0 Configurations	6-28
Figure 6-22. Typical Distributed Bypass System – Continuous Static Switch, 1+1 and 2+0 Configurations	6-29
Figure 6-23. Typical Distributed Bypass System – Continuous Static Switch, 2+1 and 3+0 Configurations	6-30
Figure 6-24. Typical Distributed Bypass System – Continuous Static Switch, 3+1 and 4+0 Configurations	6-31
Figure 7-1. UPS Controls and Indicators	7-1
Figure 7-2. UPS Control Panel	7-2
Figure 7-3. Parts of the LCD	7-4
Figure 7-4. Main Menu and Mimic Screen (Normal Mode)	7-5
Figure 7-5. Load Off Screen	7-9
Figure 7-6. Typical System Status Screen	7-10
Figure 7-7. REPO Operation	7-28

Figure 8-1. Optional X-Slot Cards ..... 8-2

Figure 8-2. Sample Event History Log ..... 8-6

Figure 8-3. Remote Monitor Panel II Front Panel ..... 8-7

Figure 8-4. Relay Interface Module II Customer Interface Connectors J1 through J4 ..... 8-9

Figure 8-5. Supervisory Contact Module II Enclosure ..... 8-10

Figure 9-1. ISBM Section Air Filter Locations – Momentary Static Switch ..... 9-3

Figure 9-2. ISBM Section Air Filter Locations – Continuous Static Switch ..... 9-4

Figure 9-3. UPM Section Air Filter Locations ..... 9-5

Figure 9-4. FI-UPM Air Filter Location ..... 9-6

This page intentionally left blank.

# Chapter 1

## Introduction

The Eaton® 9395 uninterruptible power supply (UPS) is a true online, continuous-duty, transformerless, double-conversion, solid-state, three-phase system, providing conditioned and uninterruptible AC power to protect the customer's load from power failures.

The Eaton 9395 Four UPM UPS (1000–1100 kVA) contains three sections: an integrated system bypass module (ISBM) or an Input Output Module (IOM) rated for a maximum of 1100 kVA, an Uninterruptible Power Module (UPM) section containing three UPMs, and a Field Installed UPM (FI-UPM). Each UPM is rated for a maximum of 275 kVA for a total maximum of 1100 kVA.

The Eaton 9395 Three UPM UPS (650–825 kVA) contains two sections: an ISBM or an IOM rated for a maximum of 1100 kVA (to provide future upgradability) and an UPM section containing three UPMs. Each UPM is rated for a maximum of 275 kVA for a total maximum of 825 kVA. The FI-UPM is not supplied as standard, but is available as an option to provide upgradability to a maximum of 1100 kVA.

The UPS is available as a single unit or an optional multiple unit distributed bypass system (see paragraph 1.2.4).

The Eaton 9395 online power protection system is used to prevent loss of valuable electronic information, minimize equipment downtime, and minimize the adverse effect on production equipment due to unexpected power problems.

The Eaton 9395 UPS continually monitors incoming electrical power and removes the surges, spikes, sags, and other irregularities that are inherent in commercial utility power. Working with a building's electrical system, the UPS system supplies clean, consistent power that sensitive electronic equipment requires for reliable operation. During brownouts, blackouts, and other power interruptions, batteries provide emergency power to safeguard operation.

The UPS is housed in a free-standing cabinet, divided into two sections to facilitate shipping. The sections match in style and color and have safety shields behind the door and front panels for hazardous voltage protection. The FI-UPM matches the UPS in style and color. Figure 1-1 shows the Eaton 9395 Four UPM UPS (1000–1100 kVA). Figure 1-2 shows the Eaton 9395 Three UPM UPS (650–825 kVA).



---

**NOTE** *Startup and operational checks must be performed by an authorized Eaton Customer Service Engineer, or the warranty terms specified on page W-1 become void. This service is offered as part of the sales contract for the UPS. Contact an Eaton service representative in advance (usually a two-week notice is required) to reserve a preferred startup date.*

---




Figure 1-1. Eaton 9395 Four UPM UPS (1000–1100 kVA)

## 1.1 UPS Standard Features

The UPS has many standard features that provide cost-effective and consistently reliable power protection. The descriptions in this section provide a brief overview of the UPS standard features.

### 1.1.1 Installation Features

Each UPS section is shipped separately. The sections are mechanically and electrically joined at the installation site, and can be permanently bolted to the floor.

Power wiring can be routed through the top or bottom of the cabinet with connections made to easily accessible terminals. Control wiring is routed through the top of the cabinet and must be installed in accordance with Class 1 wiring methods.

### 1.1.2 Control Panel

The control panel, located on the front of the UPS, contains a liquid crystal display (LCD) and pushbutton switches to control the operation of the UPS and to display the status of the UPS system. See Chapter 7, “UPS Operating Instructions,” for additional information.




Figure 1-2. Eaton 9395 Three UPM UPS (650–825 kVA)

### 1.1.3 Customer Interface

- **Building Alarm Monitoring** – Up to five inputs in the UPS are available to connect the facility's alarm system contacts. Some system configurations may limit the number of inputs available. The UPS uses these inputs to monitor the building alarms in addition to the UPS status. See Chapter 8, "Communication," for additional information.
- **Alarm Contact** – One alarm contact is provided for connection to equipment at the facility, such as a light, an audible alarm, or a computer terminal. The equipment connected to this contact alerts you to a UPS alarm. See Chapter 8, "Communication," for additional information.
- **X-Slot Communication Bays** – Four communication bays are standard equipment. One to four optional X-Slot® connectivity cards can be installed in the UPS module at any time. X-Slot cards are quickly installed at the front of the UPS and are hot-pluggable. See Chapter 8, "Communication," for additional information.

### 1.1.4 Advanced Battery Management

A three-stage charging system increases battery service life by optimizing recharge time, and protects batteries from damage due to high current charging and inverter ripple currents. Charging at high currents can overheat and damage batteries.

### 1.1.5 Power Management Software

Eaton LanSafe® Power Management Software is bundled as part of the Software Suite CD shipped with the UPS. See Chapter 8, “Communication,” for additional information.

## 1.2 Options and Accessories

Contact an Eaton sales representative for information about the following options.

### 1.2.1 Field Installed UPM

A Field Installed UPM (FI-UPM) provides upgradability for the Eaton 9395 Three UPM UPS. The FI-UPM may be installed at any time in the future when power needs change. The module cabinet is installed on the left side of the ISBM section and is wired directly to the UPS. No input or output wiring changes are needed for a capacity increase if the original installation was wired for increased capacity. Operation remains the same as the original UPS.

### 1.2.2 Sync Control

An optional Eaton 9395 Sync Control maintains the critical load outputs of two separate single module Eaton 9395 UPS systems in synchronization. This option facilitates the uninterrupted transfer of the load from one load bus to another by means of transfer switches. The Sync Control is housed in a wall-mounted panel that can be located between the UPS units for easy wiring.

### 1.2.3 Single-Feed Kit

An optional kit is available for converting the dual-feed rectifier and bypass inputs to a single-feed configuration. The kit consists of jumpers and bus bar extensions for each phase, and the hardware required for installation.

If the capacity of the UPMs falls below the redundancy level or the load increases above redundancy level, but is still able to maintain the load, a loss of redundancy alarm is sounded. If the load exceeds the capacity of remaining UPMs, the UPS transfers to bypass.

### 1.2.4 Distributed Bypass System

There are two types of redundancy: UPS based (based on the number of UPSs) and UPM based (based on the number of UPMs). Each UPS contains three or four UPMs.

A distributed bypass UPS system with two to five UPSs can be installed to provide a capacity and/or redundant system. This load sharing system provides more capacity than a single UPS, and can provide backup, depending on the load and configuration. In addition, when one UPM is taken out of service for maintenance or is not operating properly, a redundant UPM continues to supply uninterrupted power to the critical load. A Powerware Hot Sync® Controller Area Network (CAN) Bridge Card provides connectivity and operational mode control. The distributed bypass system consists of two to five UPSs each with a parallel CAN card, and a customer-supplied tie cabinet or load distribution panel to act as a tie point.



The tie cabinet must contain Module Output Breakers (MOBs) with dual auxiliary contacts for control of the system. Without dual auxiliary MOBs, UPMs are not allowed to go to bypass individually during servicing. All UPMs will go to bypass instead of just the UPM needing service, decreasing critical load protection. With dual auxiliary MOBs, one UPM can be bypassed while the remaining UPMs support the load as long as the remaining UPMs have the capacity to do so.

### 1.2.5 Input Output Module Configuration

The UPS can be supplied in an Input Output Module (IOM) configuration without the bypass input connections, the static switch, the motorized wraparound bypass breaker, and the backfeed protection contactor. This configuration is primarily used in multiple UPS parallel systems that do not need a bypass for each UPS and use a separate System Bypass Module (SBM) to provide system bypass capabilities.

### 1.2.6 Continuous Static Switch

A continuous static switch can be supplied in place of the momentary static switch to provide transfer of the load from the inverter to the bypass source in the event the inverter become unavailable. The continuous static switch eliminates the need for an additional motorized wraparound bypass breaker.

### 1.2.7 Inherent Redundancy

To deliver greater reliability, the Eaton 9395 UPS can be configured by an authorized Eaton Customer Service Engineer for inherent redundancy. When configured, the UPS automatically becomes redundant if the load is at or below the capacity of the UPMs minus the capacity of one UPM. Under normal conditions the UPMs in the UPS share the load equally. If one or more UPMs becomes unavailable and the load is at or below the capacity of remaining UPMs, the remaining UPMs supply the load instead of transferring to bypass.

If the capacity of the UPMs falls below the redundancy level or the load increases above redundancy level, but is still able to maintain the load, a loss of redundancy alarm is sounded. If the load exceeds the capacity of remaining UPMs, the UPS transfers to bypass.

### 1.2.8 Energy Saver and High Alert Modes



**NOTE** *Energy Saver mode requires the UPS to be factory built with a Continuous Static Switch (CSS). See paragraph 1.4 for applicable configuration.*

**NOTE** *Advanced Power Management and Energy Saver modes are mutually exclusive.*

As a subset of Normal mode, Energy Saver mode maximizes efficiency by eliminating unnecessary power conversion when the commercial power source is within acceptable voltage and frequency limits. In this mode, the UPS is actively monitoring the critical bus and instantly and seamlessly transitions to double-conversion mode (inverter online) if a commercial electrical power brownout, blackout, overvoltage, undervoltage, or out-of-tolerance frequency condition occurs.

In High Alert mode the unit transfers from Energy Saver mode to double-conversion mode or if in double-conversion mode remains in double-conversion mode for a default time period of one hour. High Alert mode allows the user to place the unit in double-conversion mode when outside conditions could cause a power disturbance. At the completion of the time period, the unit defaults back to Energy Saver mode. If the High Alert command is received during the time period, the timer will be restarted.

### 1.2.9 Advanced Power Management and High Alert Modes




---

**NOTE** *Advanced Power Management and Energy Saver modes are mutually exclusive.*

---

Advanced Power Management (APM) maintains UPM redundancy and achieves higher efficiencies by intelligently controlling the UPM's load level. The efficiency rating for each UPM is highest when loads are greater than 50% of the system rating. Therefore, shifting the load to fewer UPMs can achieve higher efficiencies when the UPS load is lighter.

In APM mode, the UPS is actively monitoring the critical bus and UPMs are available to assume load in less than 2 ms to respond to load changes.

The APM feature has three configurable modes of operation: Online mode, Online mode with APM, and High Alert mode. All modes are selectable from the front panel.

APM mode supports both distributed bypass and SBM parallel configurations.

In High Alert mode, all idle UPMs go online for one hour. At the completion of the hour, the UPS defaults back to APM mode. If the high alert command is received during the one hour, the one hour timer will be restarted.

### 1.2.10 Monitoring and Communication

- **Remote Monitor Panel II (RMP II)** – An optional RMP II contains backlit status indicators and a local horn, allowing monitoring of the operational status and alarm condition of the UPS from virtually any location within the facility.
- **Relay Interface Module II (RIM II)** – An optional RIM II uses relay contact closures to indicate the UPS operating status and alarm condition.
- **Supervisory Contact Module II (SCM II)** – An optional SCM II establishes an interface between the UPS system equipment and the customer's monitor.
- **X-Slot Cards** – Optional X-Slot cards support several protocols, such as SNMP, HTTP, IBM® AS/400®, and Modbus®.
- **eNotify Remote Monitoring and Diagnostics Service** – An optional service that provides 24/7 remote monitoring of 43 alarms, temperature/humidity and battery charge information, daily heartbeat check, and monthly report. The service also provides customer notification of significant alarms, remote diagnostics, and dispatch of technicians. A ConnectUPS™-X Web/SNMP Card is required in an X-Slot communication bay. An optional Powerware Environmental Monitoring Probe (EMP) is required for temperature/humidity monitoring.

See Chapter 8, "Communication," for additional information on monitoring and communication features.

### 1.3 Battery System

Although not provided with the UPS, a battery system is required to provide emergency short-term backup power to safeguard operation during brownouts, blackouts, and other power interruptions. The battery system should be equipped with lead-acid batteries. An external battery disconnect switch must be used.

The UPMs may be powered with either a common or separate battery system. In a common battery system, single and multiple UPMs are powered from one common battery source. In a separate battery system, multiple UPMs are each powered from separate battery sources.

UPMs in distributed bypass and parallel systems must use a separate battery system.

A supplemental 48 Vdc shunt trip signal for the battery disconnect device is provided by the UPS, but is not required for normal operation.

### 1.4 Basic System Configurations

The following basic UPS system configurations are possible:

- Single UPS with three common battery UPMs, a common battery FI-UPM, and a standalone common battery system with a battery disconnect (four UPM configuration)
- Single UPS with three common battery UPMs, and a standalone common battery system with a battery disconnect (three UPM configuration)
- Single UPS with three separate battery UPMs, a separate battery FI-UPM, and a standalone separate battery system with a battery disconnect for each UPM (four UPM configuration)
- Single UPS with three separate battery UPMs and a standalone separate battery system with a battery disconnect for each UPM (three UPM configuration)
- Distributed bypass system with two to five UPSs and a customer-supplied tie cabinet

The UPS system configuration can be enhanced by adding optional accessories such as a Remote Emergency Power-off (REPO) control, RMP II, or X-Slot communication cards.

The base configuration (first two digits of the configuration number) for the UPS are listed in Table 1-1. The configuration number can be found on the rating label mounted on the internal safety shield panel inside the front door.

**Table 1-1. Base Configuration Digits**

Configuration	Base Digits
1100 kVA ISBM, four UPM, Momentary Static Switch (MSS)	CW
1100 kVA ISBM, three UPM, MSS	CY
1100 kVA ISBM, four UPM, Continuous Static Switch (CSS)	CH
1100 kVA ISBM, three UPM, CSS	CT
1100 kVA IOM, four UPM	CQ

## 1.5 Using This Manual

This manual describes how to install and operate the Eaton 9395 1000–1100 kVA UPS. Read and understand the procedures described in this manual to ensure trouble-free installation and operation. In particular, be thoroughly familiar with the REPO procedure (see paragraph 7.3.25 on page 7-28).


The information in this manual is divided into sections and chapters. The system, options, and accessories being installed dictate which parts of this manual should be read. At a minimum, Chapters 1 through 4 and Chapter 7 should be examined.

Read through each procedure before beginning the procedure. Perform only those procedures that apply to the UPS system being installed or operated.

## 1.6 Conventions Used in This Manual

This manual uses these type conventions:

- **Bold type** highlights important concepts in discussions, key terms in procedures, and menu options, or represents a command or option that you type or enter at a prompt.
- *Italic type* highlights notes and new terms where they are defined.
- **Screen type** represents information that appears on the screen or LCD.

Icon	Description
	Information notes call attention to important features or instructions.
[Keys]	Brackets are used when referring to a specific key, such as [Enter] or [Ctrl].

In this manual, the term *UPS* refers only to the UPS cabinet and its internal elements. The term *UPS system* refers to the entire power protection system – the UPS cabinet, the battery system, and options or accessories installed.

## 1.7 Symbols, Controls, and Indicators

The following are examples of symbols used on the UPS or accessories to alert you to important information:



**RISK OF ELECTRIC SHOCK** - Observe the warning associated with the risk of electric shock symbol.



**CAUTION: REFER TO OPERATOR'S MANUAL** - Refer to your operator's manual for additional information, such as important operating and maintenance instructions.



This symbol indicates that you should not discard the UPS or the UPS batteries in the trash. This product contains sealed, lead-acid batteries and must be disposed of properly. For more information, contact your local recycling/reuse or hazardous waste center.



This symbol indicates that you should not discard waste electrical or electronic equipment (WEEE) in the trash. For proper disposal, contact your local recycling/reuse or hazardous waste center.

## 1.8 For More Information

Refer to the *Eaton 9390 and 9395 Sync Control Installation and Operation Manual* for the following additional information:

- Installation instructions, including site preparation, planning for installation, and wiring and safety information. Detailed illustrations of the cabinet with dimensional and connection point drawings are provided.
- Operation, including controls, functions of the standard and optional features, procedures for using with the UPS, and information about maintenance.

Refer to the *Eaton 9395 Field Installed UPM Mechanical Installation Manual* for the following additional information:

- Mechanical installation instructions, including site preparation, planning for mechanical installation, and safety information.
- Detailed illustrations of the cabinet, including dimension and pallet removal drawings.

Visit [www.eaton.com/powerquality](http://www.eaton.com/powerquality) or contact an Eaton service representative for information on how to obtain copies of these manuals.

## 1.9 Getting Help

If help is needed with any of the following:

- Scheduling initial startup
- Regional locations and telephone numbers
- A question about any of the information in this manual
- A question this manual does not answer

Please call the Eaton Help Desk at:

United States: **1-800-843-9433** or **1-919-870-3028**  
Canada: **1-800-461-9166 ext 260**  
All other countries: **Call your local service representative**

### IMPORTANT SAFETY INSTRUCTIONS SAVE THESE INSTRUCTIONS

This manual contains important instructions that should be followed during installation and maintenance of the UPS and batteries. Read all instructions before operating the equipment and save this manual for future reference.

The UPS is designed for industrial or computer room applications, and contains safety shields behind the door and front panels. However, the UPS is a sophisticated power system and should be handled with appropriate care.

#### DANGER



This UPS contains **LETHAL VOLTAGES**. All repairs and service should be performed by **AUTHORIZED SERVICE PERSONNEL ONLY**. There are **NO USER SERVICEABLE PARTS** inside the UPS.

#### WARNING



- The UPS is powered by its own energy source (batteries). The output terminals may carry live voltage even when the UPS is disconnected from an AC source.
- To reduce the risk of fire or electric shock, install this UPS in a temperature and humidity controlled, indoor environment, free of conductive contaminants. Ambient temperature must not exceed 40°C (104°F). Do not operate near water or excessive humidity (95% maximum). The system is not intended for outdoor use.
- Ensure all power is disconnected before performing installation or service.
- Batteries can present a risk of electrical shock or burn from high short-circuit current. The following precautions should be observed: 1) Remove watches, rings, or other metal objects; 2) Use tools with insulated handles; 3) Do not lay tools or metal parts on top of batteries; 4) Wear rubber gloves and boots.
- **ELECTRIC ENERGY HAZARD**. Do not attempt to alter any UPS or battery wiring or connectors. Attempting to alter wiring can cause injury.
- Do not open or mutilate batteries. Released electrolyte is harmful to the skin and eyes. It may be toxic.

#### CAUTION



- Installation or servicing should be performed by qualified service personnel knowledgeable of UPS and battery systems, and required precautions. Keep unauthorized personnel away from equipment. Consider all warnings, cautions, and notes before installing or servicing equipment. *DO NOT DISCONNECT the batteries while the UPS is in Battery mode.*
- Replace batteries with the same number and type of batteries as originally installed with the UPS.
- Disconnect the charging source prior to connecting or disconnecting terminals.
- Determine if the battery is inadvertently grounded. If it is, remove the source of the ground. Contacting any part of a grounded battery can cause a risk of electric shock. An electric shock is less likely if you disconnect the grounding connection before you work on the batteries.
- Proper disposal of batteries is required. Refer to local codes for disposal requirements.
- Do not dispose of batteries in a fire. Batteries may explode when exposed to flame.
- Keep the UPS door closed and front panels installed to ensure proper cooling airflow and to protect personnel from dangerous voltages inside the unit.
- Do not install or operate the UPS system close to gas or electric heat sources.

- The operating environment should be maintained within the parameters stated in this manual.
  - Keep surroundings uncluttered, clean, and free from excess moisture.
  - Observe all DANGER, CAUTION, and WARNING notices affixed to the inside and outside of the equipment.
- 

### CAUTION



To prevent damage to the wiring channel and wiring in the UPS cabinet base when lifting or moving the cabinet:

- Lift and move the cabinet using only the front or rear forklift slots.
- Verify that the forklift forks are in a horizontal position before inserting them into the forklift slots. DO NOT angle fork tips upward.
- Insert the forks all the way through the base. DO NOT insert forks partially into the base to move the cabinet.
- Forks may be partially inserted into the front or rear forklift slots for minor positioning if the forks are kept in a horizontal position with no upward angling.
- DO NOT use the forklift slots on the end of the cabinet to move the cabinet.
- End forklift slots may be used for minor positioning if the forks are kept in a horizontal position with no upward angling.

If these instructions are not followed, damage to the wiring channel and wiring will occur.

---

### AVERTISSEMENT!



- Les batteries peuvent présenter un risque de décharge électrique ou de brûlure par des courts-circuits de haute intensité. Prendre les précautions nécessaires.
  - Pour le remplacement, utiliser le même nombre et modèle des batteries.
- 

### ATTENTION!



- Une mise au rebut réglementaire des batteries est obligatoire. Consulter les règlements en vigueur dans votre localité.
  - Ne jamais jeter les batteries au feu. L'exposition aux flammes risque de les faire exploser.
-



# **Section I**

## **Installation**



## Chapter 3

# UPS Installation Plan and Unpacking

Use the following basic sequence of steps to install the UPS:

1. Create an installation plan for the UPS system (Chapter 3).
2. Prepare your site for the UPS system (Chapter 3).
3. Inspect and unpack the UPS sections (Chapter 3).
4. Unload and install the UPS sections, and wire the system (Chapter 4).
5. Install features, accessories, or options, as applicable (Chapter 5).
6. Complete the Installation Checklist (Chapter 4).
7. Have authorized service personnel perform preliminary operational checks and start up the system.



---

**NOTE** *Startup and operational checks must be performed by an authorized Eaton Customer Service Engineer, or the warranty terms specified on page W-1 become void. This service is offered as part of the sales contract for the UPS. Contact an Eaton service representative in advance (usually a two-week notice is required) to reserve a preferred startup date.*

---

### 3.1 Creating an Installation Plan

Before installing the UPS system, read and understand how this manual applies to the system being installed. Use the procedures and illustrations in paragraph 3.2 and Chapter 4 to create a logical plan for installing the system.

### 3.2 Preparing the Site

For the UPS system to operate at peak efficiency, the installation site should meet the environmental parameters outlined in this manual. If the UPS is to be operated at an altitude higher than 1500m (5000 ft), contact an Eaton service representative for important information about high altitude operation. The operating environment must meet the weight, clearance, and environmental requirements specified.

#### 3.2.1 Environmental and Installation Considerations

The UPS system installation must meet the following guidelines:

- The system must be installed on a level floor suitable for computer or electronic equipment.
- The system must be installed in a temperature and humidity controlled indoor area free of conductive contaminants.

Failure to follow guidelines may void your warranty.

The UPS equipment operating environment must meet the weight requirements shown in Table 3-1 and the size requirements shown in Figure 3-1 through Figure 3-11. Dimensions are in millimeters (inches).

Table 3-1 does not include the weight of the Field Installed UPM (FI-UPM). For FI-UPM weights and dimensions, refer to the *Eaton 9395 Field Installed UPM Mechanical Installation Manual*, listed in paragraph 1.8 on page 1-9.

**Table 3-1. UPS Cabinet Weights**

Model	Section	Weight kg (lb)	
		Shipping	Installed
Eaton 9395-1100/1000	ISBM (MSS)	1850 (4078)	1750 (3858)
	ISBM (CSS)	1018 (2245)	919 (2025)
	IOM	708 (1560)	608 (1340)
	UPM	1590 (3505)	1482 (3267)
Eaton 9395-1100/1100	ISBM (MSS)	1850 (4078)	1750 (3858)
	ISBM (CSS)	1018 (2245)	919 (2025)
	IOM	708 (1560)	608 (1340)
	UPM	1590 (3505)	1482 (3267)

NOTE MSS = Momentary Static Switch; CSS = Continuous Static Switch; IOM = Input Output Module

The UPS cabinet uses forced air cooling to regulate internal component temperature. Air inlets are in the front of the cabinet and outlets are in the top. Allow clearance in front of and above each cabinet for proper air circulation. The clearances required around the UPS cabinet are shown in Table 3-2.

**Table 3-2. UPS Cabinet Clearances**

<b>From Top of Cabinet</b>	457.2 mm (18") minimum clearance for ventilation
<b>From Front of Cabinet</b>	914.4 mm (36") working space
<b>From Back of Cabinet</b>	None Required
<b>From Right Side of Cabinet</b>	152.4 mm (6") working space
<b>From Left Side of Cabinet</b>	None Required

The basic environmental requirements for operation of the UPS are:

- Ambient Temperature Range: 0–40°C (32–104°F)
- Recommended Operating Range: 20–25°C (68–77°F)
- Maximum Relative Humidity: 95%, noncondensing



### CAUTION

If battery systems are located in the same room as the UPS, the battery manufacturer's environmental requirements should be followed if they are more stringent than the UPS requirements. Operating temperatures above the recommended range will result in decreased battery life and performance, and may reduce or void the battery warranty.

The UPS ventilation requirements are shown in Table 3-3.

**Table 3-3. Air Conditioning or Ventilation Requirements During Full Load Operation**


Model	Rating	Input/Output Voltage	Heat Rejection BTU/hr × 1000 (kg-cal/hr)	Ventilation Required for Cooling Air Exhaust		
Eaton 9395-1100/1000 (MSS)	1000 kVA	400/400	193 (48635)	Approximately 3020 liter/sec (6400 cfm)		
		480/480	195 (49127)			
Eaton 9395-1100/1100 (MSS)	1100 kVA	400/400	212 (53499)			
		480/480	215 (54040)			
Eaton 9395-1100/650 (MSS)	650 kVA	400/400	125 (31613)			
		480/480	127 (31933)			
Eaton 9395-1100/750 (MSS)	750 kVA	400/400	145 (36476)		Approximately 2265 liter/sec (4800 cfm)	
		480/480	146 (36845)			
Eaton 9395-1100/825 (MSS)	825 kVA	400/400	159 (40124)			
		480/480	161 (40530)			
Eaton 9395-1100/1000 (CSS)	1000 kVA	400/400	193 (48635)			Approximately 3020 liter/sec (6400 cfm)
		480/480	195 (49127)			
Eaton 9395-1100/1100 (CSS)	1100 kVA	400/400	212 (53499)			
		480/480	215 (54040)			
Eaton 9395-1100/650 (CSS)	650 kVA	400/400	125 (31613)			
		480/480	127 (31933)			
Eaton 9395-1100/750 (CSS)	750 kVA	400/400	145 (36476)	Approximately 2265 liter/sec (4800 cfm)		
		480/480	146 (36845)			
Eaton 9395-1100/825 (CSS)	825 kVA	400/400	159 (40124)			
		480/480	161 (40530)			
Eaton 9395-1100/1000 (IOM)	1000 kVA	400/400	193 (48635)		Approximately 3020 liter/sec (6400 cfm)	
		480/480	195 (49127)			
Eaton 9395-1100/1100 (IOM)	1100 kVA	400/400	212 (53499)			
		480/480	215 (54040)			

NOTE MSS = Momentary Static Switch; CSS = Continuous Static Switch; IOM = Input Output Module




Dimensions are in millimeters [inches].

**Figure 3-1. UPS Cabinet Dimensions – Three UPM (Front View)**



Dimensions are in millimeters [inches].

**Figure 3-2. UPS Cabinet Dimensions – Four UPM (Front View)**



Dimensions are in millimeters [inches].

Figure 3-3. UPS Cabinet Dimensions (Right Side View)




Figure 3-4. ISBM Section Dimensions (Front View)




Figure 3-5. UPM Section Dimensions (Front View)





Figure 3-6. UPM Section Dimensions (Top View)

Dimensions are in millimeters [inches].






Front

Dimensions are in millimeters [inches].



Figure 3-7. ISBM Section Dimensions (Top View)



Front



Dimensions are in millimeters [inches].

Figure 3-8. ISBM Section Dimensions (Bottom View)




Dimensions are in millimeters [inches].

**Figure 3-9. ISBM Section Center of Gravity**



Dimensions are in millimeters [inches].

**Figure 3-10. UPM Section Center of Gravity**



Dimensions are in millimeters [inches].

**Figure 3-11. Remote EPO Switch Dimensions**

### 3.2.2 UPS System Power Wiring Preparation

Read and understand the following notes while planning and performing the installation:

- Refer to national and local electrical codes for acceptable external wiring practices.
- To allow for future kVA upgrades, consider installing a derated UPS using wiring and external overcurrent protection breakers sized for a fully rated UPS.
- To allow for a future upgrade, install a three UPM model using conductors and external overcurrent protection breakers sized the same as a fully rated 1100 kVA model.
- For external wiring, use 90°C copper or aluminum wire. Wire sizes listed in Table 3-4 through Table 3-7 are for copper wiring only. If wire is run in an ambient temperature greater than 30°C, higher temperature wire and/or larger size wire may be necessary. Wire sizes are based on using the specified breakers.
- Wire ampacities are chosen from Table 310-16 of the National Electrical Code® (NEC®). Specification is for copper wire with a 90°C rating.
- Material and labor for external wiring requirements are to be provided by designated personnel.
- If installing a maintenance bypass, a minimum of two separate feeds with upstream feeder breakers, or a single feed with two upstream feeder breakers, must be provided: one for the UPS or rectifier input breaker (RIB) (if installed) and one for the maintenance bypass input. DO NOT use a single feed or a single feeder breaker to supply both the UPS or RIB and the maintenance bypass. If a bypass input breaker (BIB) is installed in the maintenance bypass and a single-feed UPS is being installed, a single feed to the maintenance bypass is acceptable for supplying both the UPS and the bypass.
- The bypass feed into this equipment uses three or four wires. The rectifier feed into this equipment uses three wires. The phases must be symmetrical about ground (from a Wye source) for proper equipment operation.

- If the load requires a neutral, a bypass source neutral must be provided. If the load does not require a neutral and there is no neutral conductor connected at the bypass input, a neutral to ground bonding jumper must be installed. DO NOT install both a source neutral and a bonding jumper. See Table 3-4, Table 3-5, Table 3-6, or Table 3-7 for neutral bonding jumper wire sizes. The bonding jumper must be copper wire.



### CAUTION

HIGH IMPEDANCE GROUND SOURCES - If the supply source is a high impedance ground (IT) type, the input neutral conductor must be connected from the source of supply. If the load requires a neutral, then an input neutral conductor must be pulled into the UPS. In no circumstances shall a neutral to ground bonding jumper be installed in the UPS.



### CAUTION

DELTA SOURCES (TN-S) - The UPS cannot be operated from a mid-point or end-point grounded delta supply source. With this type of supply source, there is no capability to provide an output neutral. In no circumstances shall a neutral to ground bonding jumper be installed in the UPS.

- The ISBM and UPM sections are shipped with debris shields covering the ventilation grills on top of the sections. Do not remove the debris shields until installation is complete. However, remove the shields before operating the UPS. Once the debris shields are removed, do not place objects on the ventilation grills.
- In a common battery system, single and multiple UPMs are powered from one common battery source. In a separate battery system, multiple UPMs are each powered from separate battery sources.
- UPMs in distributed bypass and parallel systems must use a separate battery system.
- On a UPS configured as an Input Output Module (IOM), requirements for bypass input wiring, termination, conduit, and bypass breaker are not applicable.
- A Field Installed UPM (FI-UPM) is always designated as UPM 4.

If the power rating listed on the nameplate of the installed UPS is not found in the following tables, wire the UPS using the fully rated specifications. Otherwise, calculate the required wire, conduit, and breaker sizes using the following guidelines in addition to those already listed in paragraph 3.2.2:

- Select wire size according to the UPS nameplate.
- Do not use wire larger than the largest size listed in Table 3-4 through Table 3-7.
- Use terminal recommendations from Table 3-10 through Table 3-12.
- Size and number of conduits must not exceed those listed in Table 3-13.
- Select overcurrent protection input, battery, and output breakers according to the UPS nameplate rated for either 80% or 100%.
- Follow all applicable NEC and local codes.

For four UPM external wiring requirements, including the minimum AWG size of external wiring, see Table 3-4 for installations using a common battery system or Table 3-5 for installations using a separate battery system. Wire sizes listed are for copper wiring only.

For three UPM external wiring requirements, including the minimum AWG size of external wiring, see Table 3-6 for installations using a common battery system or Table 3-7 for installations using a separate battery system. Wire sizes listed are for copper wiring only. Because of the future upgradability to a fully rated 1100 kVA UPS with the addition of the FI-UPM, the UPS wiring is specified for 1100 kVA in Table 3-6 and Table 3-7.

**Table 3-4. Input/Output Ratings and External Wiring Requirements for the Four UPM Eaton 9395-1100/1000 and 9395-1100/1100 – Common Battery**

Basic Unit Rating	Units		Rating 50/60 Hz			
	kVA	kW	1000	1100	1100	
Input and Output Voltage	Volts	400/400	480/480	400/400	480/480	
<b>AC Input to UPS Rectifier (0.98 Minimum pF)</b> Full load current plus battery recharge current (3) Phases, (1) Ground	<b>A</b>	Amps	1660	1370	1507	
Minimum Conductor Size Number per Phase		AWG or kcmil (each)	500 (6)	500 (5)	500 (6)	500 (5)
<b>AC Input to UPS Bypass (Four Wire)</b> Full Load Current (3) Phases, (1) Ground	<b>B</b>	Amps	1443	1203	1588	1323
Minimum Conductor Size Number per Phase		AWG or kcmil (each)	500 (5)	500 (4)	500 (5)	500 (5)
<b>AC Input to UPS Bypass (Five Wire)</b> Full Load Current (3) Phases, (1) Neutral, (1) Ground	<b>B</b>	Amps	1443	1203	1588	1323
Minimum Conductor Size Number per Phase		AWG or kcmil (each)	500 (6)	500 (5)	500 (6)	500 (6)
<b>DC Input from Battery Disconnect to UPS</b> (1) Positive, (1) Negative	<b>C</b>	Total Amps	2000	2000	2181	2203
Minimum Conductor Size Number per Pole		AWG or kcmil (each)	500 (8)	500 (8)	500 (9)	500 (9)
<b>AC Output to Critical Load (Four Wire)</b> Full Load Current (3) Phases, (1) Ground	<b>D</b>	Amps	1443	1203	1588	1323
Minimum Conductor Size Number per Phase		AWG or kcmil (each)	500 (5)	500 (4)	500 (5)	500 (5)
<b>AC Output to Critical Load (Five Wire)</b> Full Load Current (3) Phases, (1) Neutral, (1) Ground	<b>D</b>	Amps	1443	1203	1588	1323
Minimum Conductor Size Number per Phase		AWG or kcmil (each)	500 (6)	500 (5)	500 (6)	500 (6)
<b>Neutral Bonding Jumper (Four Wire Output Only)</b> Minimum Conductor Size Number	<b>—</b>	AWG or kcmil (each)	250 (1)	4/0 (1)	250 (1)	250 (1)

NOTE Callout letters **A**, **B**, **C**, and **D** map to Figure 6-5 on page 6-9 or Figure 6-9 on page 6-13. Callout letters **A**, **C**, and **D** map to Figure 6-13 on page 6-17.

NOTE Bypass wiring data is not applicable to IOM configurations.

**Table 3-5. Input/Output Ratings and External Wiring Requirements for the Four UPM Eaton 9395-1100/1000, and 9395-1100/1100 – Separate Battery**

Basic Unit Rating	Units	Rating 50/60 Hz				
	kVA	1000	1000	1100	1100	
	kW	900	909	990	1000	
<b>Input and Output Voltage</b>	Volts	400/400	480/480	400/400	480/480	
<b>AC Input to UPS Rectifier (0.98 Minimum pF)</b> Full load current plus battery recharge current (3) Phases, (1) Ground	<b>A</b>	Amps	1660	1370	1826	1507
Minimum Conductor Size Number per Phase		AWG or kcmil (each)	500 (6)	500 (5)	500 (6)	500 (5)
<b>AC Input to UPS Bypass (Four Wire)</b> Full Load Current (3) Phases, (1) Ground	<b>B</b>	Amps	1443	1203	1588	1323
Minimum Conductor Size Number per Phase		AWG or kcmil (each)	500 (5)	500 (4)	500 (5)	500 (5)
<b>AC Input to UPS Bypass (Five Wire)</b> Full Load Current (3) Phases, (1) Neutral, (1) Ground	<b>B</b>	Amps	1443	1203	1588	1323
Minimum Conductor Size Number per Phase		AWG or kcmil (each)	500 (6)	500 (5)	500 (6)	500 (6)
<b>DC Input from Each Battery Disconnect to Each UPS UPM</b> (1) Positive, (1) Negative	<b>C</b>	Amps per UPM	551	551	551	551
Minimum Conductor Size Number per Pole		AWG or kcmil (each)	250 (3)	250 (3)	250 (3)	250 (3)
<b>AC Output to Critical Load (Four Wire)</b> Full Load Current (3) Phases, (1) Ground	<b>D</b>	Amps	1443	1203	1588	1323
Minimum Conductor Size Number per Phase		AWG or kcmil (each)	500 (5)	500 (4)	500 (5)	500 (5)
<b>AC Output to Critical Load (Five Wire)</b> Full Load Current (3) Phases, (1) Neutral, (1) Ground	<b>D</b>	Amps	1443	1203	1588	1323
Minimum Conductor Size Number per Phase		AWG or kcmil (each)	500 (6)	500 (5)	500 (6)	500 (6)
<b>Neutral Bonding Jumper (Four Wire Output Only)</b> Minimum Conductor Size Number	—	AWG or kcmil (each)	250 (1)	4/0 (1)	250 (1)	250 (1)

NOTE Callout letters **A**, **B**, **C**, and **D** map to Figure 6-6 on page 6-10 or Figure 6-10 on page 6-14. Callout letters **A**, **C**, and **D** map to Figure 6-14 on page 6-18.

NOTE Bypass wiring data is not applicable to IOM configurations.

**Table 3-6. Input/Output Ratings and External Wiring Requirements for the Three UPM Eaton 9395-1100/650, 9395-1100/750, and 9395-1100/825 – Common Battery**

Basic Unit Rating	Units		Rating 50/60 Hz					
	kVA	kW	650	650	750	750	825	825
			585	591	675	682	743	750
<b>Input and Output Voltage</b>	Volts		400/400	480/480	400/400	480/480	400/400	480/480
<b>AC Input to UPS Rectifier (0.98 Minimum pF)</b> Full load current plus battery recharge current (3) Phases, (1) Ground	<b>A</b>	Amps	1079	891	1245	1028	1369	1130
Minimum Conductor Size Number per Phase		AWG or kcmil (each)	500 (6)	500 (5)	500 (6)	500 (5)	500 (6)	500 (5)
<b>AC Input to UPS Bypass (Four Wire)</b> Full Load Current (3) Phases, (1) Ground	<b>B</b>	Amps	938	782	1083	902	1191	992
Minimum Conductor Size Number per Phase		AWG or kcmil (each)				500 (5)		
<b>AC Input to UPS Bypass (Five Wire)</b> Full Load Current (3) Phases, (1) Neutral, (1) Ground	<b>B</b>	Amps	938	782	1083	902	1191	992
Minimum Conductor Size Number per Phase		AWG or kcmil (each)				500 (6)		
<b>DC Input from Battery Disconnect to UPS</b> (1) Positive, (1) Negative	<b>C</b>	Total Amps	1280	1280	1502	1502	1600	1600
Minimum Conductor Size Number per Pole		AWG or kcmil (each)				500 (9)		
<b>AC Output to Critical Load (Four Wire)</b> Full Load Current (3) Phases, (1) Ground	<b>D</b>	Amps	938	782	1083	902	1191	992
Minimum Conductor Size Number per Phase		AWG or kcmil (each)				500 (5)		
<b>AC Output to Critical Load (Five Wire)</b> Full Load Current (3) Phases, (1) Neutral, (1) Ground	<b>D</b>	Amps	938	782	1083	902	1191	992
Minimum Conductor Size Number per Phase		AWG or kcmil (each)				500 (6)		
<b>Neutral Bonding Jumper (Four Wire Output Only)</b> Minimum Conductor Size Number	—	AWG or kcmil (each)				250 (1)		

NOTE Callout letters **A**, **B**, **C**, and **D** map to Figure 6-7 on page 6-11 or Figure 6-11 on page 6-15.

**Table 3-7. Input/Output Ratings and External Wiring Requirements for the Three UPM Eaton 9395-1100/650, 9395-1100/750, and 9395-1100/825 – Separate Battery**

Basic Unit Rating	Units		Rating 50/60 Hz					
	kVA	kW	650	650	750	750	825	825
Input and Output Voltage	Volts		400/400	480/480	400/400	480/480	400/400	480/480
<b>AC Input to UPS Rectifier (0.98 Minimum pF)</b> Full load current plus battery recharge current (3) Phases, (1) Ground	<b>A</b>	Amps	1079	891	1245	1028	1369	1130
Minimum Conductor Size Number per Phase		AWG or kcmil (each)	500 (6)	500 (5)	500 (6)	500 (5)	500 (6)	500 (5)
<b>AC Input to UPS Bypass (Four Wire)</b> Full Load Current (3) Phases, (1) Ground	<b>B</b>	Amps	938	782	1083	902	1191	992
Minimum Conductor Size Number per Phase		AWG or kcmil (each)				500 (5)		
<b>AC Input to UPS Bypass (Five Wire)</b> Full Load Current (3) Phases, (1) Neutral, (1) Ground	<b>B</b>	Amps	938	782	1083	902	1191	992
Minimum Conductor Size Number per Phase		AWG or kcmil (each)				500 (6)		
<b>DC Input from Each Battery Disconnect to Each UPS UPM</b> (1) Positive, (1) Negative	<b>C</b>	Amps per UPM	551	551	551	551	551	551
Minimum Conductor Size Number per Pole		AWG or kcmil (each)				250 (3)		
<b>AC Output to Critical Load (Four Wire)</b> Full Load Current (3) Phases, (1) Ground	<b>D</b>	Amps	938	782	1083	902	1191	992
Minimum Conductor Size Number per Phase		AWG or kcmil (each)				500 (6)		
<b>AC Output to Critical Load (Five Wire)</b> Full Load Current (3) Phases, (1) Neutral, (1) Ground	<b>D</b>	Amps	938	782	1083	902	1191	992
Minimum Conductor Size Number per Phase		AWG or kcmil (each)				500 (6)		
<b>Neutral Bonding Jumper (Four Wire Output Only)</b> Minimum Conductor Size Number	—	AWG or kcmil (each)				250 (1)		

NOTE Callout letters **A, B, C,** and **D** map to Figure 6-8 on page 6-12 or Figure 6-12 on page 6-16.

Terminals E1A through E5A and E9A through E12A are stud type terminals. The intercabinet power wiring connections for this equipment are rated at 90°C. See Table 3-8 for intercabinet power cable terminations and Table 3-9 for supplied intercabinet wiring terminal hardware.

The torque values listed in Table 3-8 for the M8 studs are the maximum allowable. Tightening further will risk breaking or twisting the stud.

Figure 4-8 through Figure 4-11 starting on page 4-11 show the location of the intercabinet power cable terminals inside the UPS.



**Table 3-8. UPS Intercabinet Power Cable Terminations for the Four UPM Eaton 9395-1100/1000 and 9395-1100/1100, and the Three UPM Eaton 9395-1100/650, 9395-1100/750, and 9395-1100/825**

Terminal Function	Terminal	Function	Bus Landing	Tightening Torque Nm (lb ft)	Stud
AC Input to UPM Section	E1A (UPM 1) E1A (UPM 2) E1A (UPM 3) E1A (UPM 4 – Four UPM Model)	Phase A	3 – stud mounting	14.2 (10.4)	M8
	E2A (UPM 1) E2A (UPM 2) E2A (UPM 3) E2A (UPM 4 – Four UPM Model)	Phase B	3 – stud mounting	14.2 (10.4)	M8
	E3A (UPM 1) E3A (UPM 2) E3A (UPM 3) E3A (UPM 4 – Four UPM Model)	Phase C	3 – stud mounting	14.2 (10.4)	M8
AC Output from UPM Section	E9A (UPM 1) E9A (UPM 2) E9A (UPM 3)	Phase A	3 – stud mounting	14.2 (10.4)	M8
	E10A (UPM 1) E10A (UPM 2) E10A (UPM 3)	Phase B	3 – stud mounting	14.2 (10.4)	M8
	E11A (UPM 1) E11A (UPM 2) E11A (UPM 3)	Phase C	3 – stud mounting	14.2 (10.4)	M8
	E12A (UPM 1) E12A (UPM 2) E12A (UPM 3)	Neutral	3 – stud mounting	14.2 (10.4)	M8
DC Input to UPM Section	1E4A (UPM 1) 2E4A (UPM 2) 3E4A (UPM 3)	Positive	6 – stud mounting (2 per UPM)	14.2 (10.4)	M8
	1E5A (UPM 1) 2E5A (UPM 2) 3E5A (UPM 3)	Negative	6 – stud mounting (2 per UPM)	14.2 (10.4)	M8

**Table 3-9. Supplied Intercabinet Wiring Terminal Hardware Kit**

Part	Size	Quantity	Terminals Used On	Eaton Part Number
Flat Washer	M8	36	UPM AC Input, UPM Battery Input, UPM AC Output, and Neutral	180500036-080
Conical Washer	M8	36	UPM AC Input, UPM Battery Input, UPM AC Output, and Neutral	180500037-080
Nut	M8	36	UPM AC Input, UPM Battery Input, UPM AC Output, and Neutral	180200001-05

Terminals E1 through E12 are 2-hole busbar mountings for standard NEMA 2-hole barrel lugs. The power wiring connections for this equipment are rated at 90°C. See Table 3-10 for power cable terminations, Table 3-11 for supplied terminal hardware, and Table 3-12 for recommended installation parts and tools not supplied by Eaton Corporation.

Figure 4-18 through Figure 4-21 starting on page 4-22 show the location of the power cable terminals inside the UPS.

**Table 3-10. UPS External Power Cable Terminations for the Four UPM Eaton 9395-1100/1000 and 9395-1100/1100, and the Three UPM Eaton 9395-1100/650, 9395-1100/750, and 9395-1100/825**

Terminal Function	Terminal	Function	Bus Landings (using both sides of bus)	Tightening Torque Nm (lb ft)	Bolt Size
AC Input to UPS Rectifier	E1	Phase A	6 – 2 bolt mounting	76 (56)	M12
	E2	Phase B	6 – 2 bolt mounting	76 (56)	M12
	E3	Phase C	6 – 2 bolt mounting	76 (56)	M12
AC Input to Bypass	E6	Phase A	6 – 2 bolt mounting	76 (56)	M12
	E7	Phase B	6 – 2 bolt mounting	76 (56)	M12
	E8	Phase C	6 – 2 bolt mounting	76 (56)	M12
AC Output to Critical Load	E9	Phase A	6 – 2 bolt mounting	76 (56)	M12
	E10	Phase B	6 – 2 bolt mounting	76 (56)	M12
	E11	Phase C	6 – 2 bolt mounting	76 (56)	M12
DC Input from Battery or Battery Disconnect to UPS – Common Battery	E4	Battery (+)	12 – 2 bolt mounting (3 UPM) 16 – 2 bolt mounting (4 UPM)	76 (56)	M12
	E5	Battery (-)	12 – 2 bolt mounting (3 UPM) 16 – 2 bolt mounting (4 UPM)	76 (56)	M12
DC Input from Battery or Battery Disconnect to UPS – Separate Battery (UPM 1)	E4	Battery (+)	4 – 2 bolt mounting	76 (56)	M12
	E5	Battery (-)	4 – 2 bolt mounting	76 (56)	M12
DC Input from Battery or Battery Disconnect to UPS – Separate Battery (UPM 2)	E4	Battery (+)	4 – 2 bolt mounting	76 (56)	M12
	E5	Battery (-)	4 – 2 bolt mounting	76 (56)	M12
DC Input from Battery or Battery Disconnect to UPS – Separate Battery (UPM 3)	E4	Battery (+)	4 – 2 bolt mounting	76 (56)	M12
	E5	Battery (-)	4 – 2 bolt mounting	76 (56)	M12
DC Input from Battery or Battery Disconnect to UPS – Separate Battery (UPM 4 FI-UPM)	E4	Battery (+)	4 – 2 bolt mounting	76 (56)	M12
	E5	Battery (-)	4 – 2 bolt mounting	76 (56)	M12
Input and Output Neutral	E12	Neutral	12 – 2 bolt mounting	22 (16)	M10
Customer Ground	Ground	Ground	15 – 1 bolt mounting	22 (16)	M10

NOTE Customer ground, sized in accordance with NEC Table 250.122, can be run in any conduit listed in Table 3-13 on page 3-18.

NOTE Bypass terminations are not applicable to IOM configurations.

**Table 3-11. Supplied External Wiring Terminal Hardware Kit**

Part	Size	Quantity	Terminals Used On	Eaton Part Number
Bolt, Grade 5	M10 x 25 mm	15	Ground	180190078-087
Bolt, Grade 5	M12 x 50 mm	98	Rectifier Input, Bypass Input, Battery Input, Output, and Neutral	180190078-115
Flat Washer	M10	15	Ground	180500036-100
Flat Washer	M12	196	Rectifier Input, Bypass Input, Battery Input, Output, and Neutral	180500036-120
Conical Washer	M10	15	Ground	180500037-100
Conical Washer	M12	98	Rectifier Input, Bypass Input, Battery Input, Output, and Neutral	180500037-120
Nut	M12	98	Rectifier Input, Bypass Input, Battery Input, Output, and Neutral	180200001-07

NOTE Bypass terminations are not applicable to IOM configurations.

**Table 3-12. Recommended Installation Parts and Tools (Not Supplied by Eaton)**

Part	Size	Quantity	Manufacturer	Part Number	Notes
Long Barrel 2-Hole Lug	2/0 AWG	As required	Thomas & Betts	54862BE	Copper wire only
	3/0 AWG		Thomas & Betts	54864BE	
	4/0 AWG		Thomas & Betts	54866BE	
	250 MCM		Thomas & Betts	54868BE	
	300 MCM		Thomas & Betts	54870BE	
	350 MCM		Thomas & Betts	54872BE	
	400 MCM		Thomas & Betts	54874BE	
500 MCM	Thomas & Betts	54876BE			
Manual Hydraulic Crimp Tool	14 Ton	1	Thomas & Betts	TBM14M	
Die Set	N/A	1	Thomas & Betts	15506	

Conduit sizes were chosen from NEC Table 4, Electrical Metallic Tubing (EMT). See Table 3-13 for conduit requirements.

Per NEC article 300, 3(B)(1), all three-phase conductors must be run in the same conduit. Neutral and ground must be run in the same conduit as the phase conductors.

Conduit is sized to accommodate one neutral conductor the same size as the phase conductor and one ground conductor sized in accordance with NEC Table 250.122.

Conduit sizes listed are for copper wiring only.

**Table 3-13. Power Cable Conduit Requirements**

UPS Model	Voltage	Terminal	Number of Wires in Conduit	Minimum Conduit Trade Size	Number of Conduits	
Eaton 9395-1100/1000	400 Vac	AC Input to UPS Rectifier (A, B, C, Ground)	4	3	6	
		AC Input to Bypass and Output (Four Wire) (A, B, C, Ground)	4	3	5	
		AC Input to Bypass and Output (Five Wire) (A, B, C, Neutral, Ground)	5	3-1/2	6	
	480 Vac	AC Input to UPS Rectifier (A, B, C, Ground)	4	3	5	
		AC Input to Bypass and Output (Four Wire) (A, B, C, Ground)	4	3	4	
		AC Input to Bypass and Output (Five Wire) (A, B, C, Neutral, Ground)	5	3	5	
	DC	Battery (Positive, Negative, Ground)		See Note 1		
	Eaton 9395-1100/1100	400 Vac	AC Input to UPS Rectifier (A, B, C, Ground)	4	3	6
			AC Input to Bypass and Output (Four Wire) (A, B, C, Ground)	4	3	5
AC Input to Bypass and Output (Five Wire) (A, B, C, Neutral, Ground)			5	3-1/2	6	
480 Vac		AC Input to UPS Rectifier (A, B, C, Ground)	4	3	5	
		AC Input to Bypass and Output (Four Wire) (A, B, C, Ground)	4	3	5	
		AC Input to Bypass and Output (Five Wire) (A, B, C, Neutral, Ground)	5	3-1/2	6	
DC		Battery (Positive, Negative, Ground)		See Note 1		

**Table 3-13. Power Cable Conduit Requirements (continued)**

UPS Model	Voltage	Terminal	Number of Wires in Conduit	Minimum Conduit Trade Size	Number of Conduits
Eaton 9395-1100/650 Eaton 9395-1100/750 Eaton 9395-1100/825 See Note 2	400 Vac	AC Input to UPS Rectifier (A, B, C, Ground)	4	3	6
		AC Input to Bypass and Output (Four Wire) (A, B, C, Ground)	4	3	5
		AC Input to Bypass and Output (Five Wire) (A, B, C, Neutral, Ground)	5	3-1/2	6
	480 Vac	AC Input to UPS Rectifier (A, B, C, Ground)	4	3	5
		AC Input to Bypass and Output (Four Wire) (A, B, C, Ground)	4	3	5
		AC Input to Bypass and Output (Five Wire) (A, B, C, Neutral, Ground)	5	3-1/2	6
DC	Battery (Positive, Negative, Ground)		See Note 1		

NOTE 1 Select conduit taking into consideration the DC input wire sizes listed in Table 3-4 on page 3-11 or Table 3-5 on page 3-12, the DC terminations listed in Table 3-10 on page 3-16, type of battery installation, and requirements from NEC Table 4, Electrical Metallic Tubing (EMT).

NOTE 2 Because of the future upgradability to a fully rated 1100 kVA UPS with the addition of the FI-UPM, these conduit sizes are specified for an 1100 kVA UPS.

NOTE 3 Bypass conduit data is not applicable to IOM configurations.

External overcurrent protection and disconnect are not provided by this product, but are required by codes. Refer to Table 3-4, Table 3-5, Table 3-6, or Table 3-7 starting on page 3-11 for wiring requirements. If an output lockable disconnect is required, it is to be supplied by the customer.

Table 3-14 lists the recommended rating for input circuit breakers.

**Table 3-14. Recommended Input Circuit Breaker Ratings**

UPS Model	Input Rating		
	Load Rating	400V	480V
Eaton 9395-1100/1000	80% Rated	2500A	2000A
	100% Rated	2000A	1600A
Eaton 9395-1100/1100	80% Rated	2500A	2000A
	100% Rated	2000A	1600A
Eaton 9395-1100/650 Eaton 9395-1100/750 Eaton 9395-1100/825 See Note	80% Rated	2500A	2000A
	100% Rated	2000A	1600A

NOTE Because of the future upgradability to a fully rated 1100 kVA UPS with the addition of the FI-UPM, these breaker sizes are specified for an 1100 kVA UPS.



## CAUTION

To reduce the risk of fire, connect only to a circuit provided with maximum input circuit breaker current ratings from Table 3-14 in accordance with the NEC, ANSI/NFPA 70.

The line-to-line unbalanced output capability of the UPS is limited only by the full load per phase current values for AC output to critical load shown in Table 3-4, Table 3-5, Table 3-6, or Table 3-7 starting on page 3-11. The recommended line-to-line load unbalance is 50% or less.

Bypass and output overcurrent protection and bypass and output disconnect switches are to be provided by the customer. Module Output Breakers (MOBs) are to be provided by the customer. Table 3-15 lists the recommended rating for bypass, output, and MOB circuit breakers. Bypass breakers are not applicable for IOM configurations.

**Table 3-15. Recommended Bypass, Output, and MOB Circuit Breaker Ratings**

UPS Model	Bypass, Output, and MOB Rating		
	Load Rating	400V	480V
Eaton 9395-1100/1000	80% Rated	2000A	1600A
	100% Rated	1600A	1600A
Eaton 9395-1100/1100	80% Rated	2000A	2000A
	100% Rated	1600A	1600A
Eaton 9395-1100/650	80% Rated	2000A	2000A
Eaton 9395-1100/750	100% Rated	1600A	1600A
Eaton 9395-1100/825			
See Note 1			

NOTE 1 Because of the future upgradability to a fully rated 1100 kVA UPS with the addition of the FI-UPM, these breaker sizes are specified for an 1100 kVA UPS.

NOTE 2 Bypass breakers are not required for IOM configurations.

There is no manual DC disconnect device within the UPS.

A battery disconnect switch is required for battery systems and may also be required by NEC or local codes. The battery disconnect switch should be installed between the battery and the UPS.

Battery voltage is computed at 2 volts per cell as defined by Article 480 of the NEC. Rated battery current is computed at 2 volts per cell.

The battery wiring used between the battery and the UPS should not allow a voltage drop of more than 1% of nominal DC voltage at rated battery current.

External DC input overcurrent protection and disconnect switch is to be provided by the customer. Table 3-16 and Table 3-17 list the maximum ratings for continuous-duty rated circuit breakers satisfying the criteria for both. Recommended disconnect size is based on a maximum full load discharge time less than 3 hours. For longer discharge times a larger disconnect may be required.

**Table 3-16. Recommended DC Input Battery Disconnect Ratings – Common Battery**

UPS Model	Input Rating	
	400V	480V
Eaton 9395-1100/1000	2500A	2500A
Eaton 9395-1100/1100	3000A	3000A
Eaton 9395-1100/650 Eaton 9395-1100/750 Eaton 9395-1100/825 See Note	3000A	3000A

NOTE Because of the future upgradability to a fully rated 1100 kVA UPS with the addition of the FI-UPM, these breaker sizes are specified for an 1100 kVA UPS.

**Table 3-17. Recommended DC Input Battery Disconnect Ratings – Separate Battery**

UPS Model	Input Rating (each UPM)	
	400V	480V
Eaton 9395-1100/1000		
Eaton 9395-1100/1100		
Eaton 9395-1100/650 Eaton 9395-1100/750 Eaton 9395-1100/825 See Note	700A	700A

NOTE Because of the future upgradability to a fully rated 1100 kVA UPS with the addition of the FI-UPM, these breaker sizes are specified for an 1100 kVA UPS.

### 3.2.3 UPS System Interface Wiring Preparation

Control wiring for features and options should be connected at the customer interface terminal blocks located inside the UPS.



#### WARNING

Do not directly connect relay contacts to the mains related circuits. Reinforced insulation to the mains is required.

Read and understand the following notes while planning and performing the installation:

- Use Class 1 wiring methods (as defined by the NEC) for interface wiring up to 30V. The wire should be rated at 24V, 1A minimum.
- Use Class 2 wiring methods (as defined by the NEC) for interface wiring from 30V to 600V. The wire should be rated at 600V, 1A minimum and 12 AWG maximum.
- Use twisted-pair wires for each input and return or common.
- All interface wiring and conduit is to be provided by the customer.
- When installing external interface wiring (for example, building alarm, relay output, battery breaker trip, and X-Slot) to the UPS interface terminals, conduit must be installed between each device and the UPS cabinet.
- Install the interface wiring in separate conduit from the power wiring.

- When installing internal interface wiring to X-Slot terminals, route the wiring through the internal opening in the X-Slot communication bay.
- All building alarm inputs or remote features require an isolated normally-open contact or switch (rated at 24 Vdc, 20 mA minimum) connected between the alarm input and common terminal. All control wiring and relay and switch contacts are customer-supplied.
- The building alarms can be programmed to display the alarm functional name.
- LAN and telephone drops for use with X-Slot connectivity cards must be provided by the customer.
- The UPS battery aux signal wiring from the UPS must be connected to the battery disconnect device.
- A supplemental 48 Vdc shunt trip signal for the battery disconnect device is provided, but is not required for normal operation.
- Battery aux and 48 Vdc shunt trip wiring should be a minimum of 18 AWG.
- The REPO feature opens all contactors in the UPS cabinet and isolates power from your critical load. Local electrical codes may also require tripping upstream protective devices to the UPS.
- The REPO switch must be a latching-type switch not tied to any other circuits.
- A jumper wire must be connected between pins 1 and 2 on TB1, if the normally-closed REPO contact is not used.
- REPO wiring should be a minimum of 22 AWG and a maximum of 14 AWG.
- The REPO switch wiring must be in accordance with NEC Article 725 Class 2 requirements.
- The maximum distance between the REPO and the UPS cannot exceed 150 meters (500 feet).
- Alarm relay contacts have a maximum current rating of 5A and a switched voltage rating of 30 Vac and 28 Vdc.
- Alarm relay wiring should be a minimum of 22 AWG.



### 3.2.4 Distributed Bypass Power Wiring Preparation

Read and understand the following notes while planning and performing the installation:

- All distributed bypass UPS rectifier inputs must come from one source and all bypass input feeds must come from one source.
- Distributed bypass UPS input wiring size requirements and output wiring size requirements from the UPSs to the tie cabinet or distribution panel are the same as listed in Table 3-4, Table 3-5, Table 3-6, or Table 3-7 starting on page 3-11.
- If the load requires a neutral, a bypass source neutral must be provided. If the load does not require a neutral and there is no neutral conductor connected at the bypass input, a neutral to ground bonding jumper must be installed. Install neutral conductors from the UPSs to the common point of connection (tie cabinet), and then install a system neutral to ground bonding jumper. The bonding jumper must be copper wire. DO NOT install both a source neutral and a bonding jumper.

If the recommended system neutral bonding jumper installation method cannot be accomplished, each UPS should have a separate neutral to ground bonding jumper installed. See Table 3-4, Table 3-5, Table 3-6, or Table 3-7 starting on page 3-11 for UPS neutral bonding jumper wire sizes. The bonding jumper must be copper wire. DO NOT install both a source neutral and a bonding jumper.

#### CAUTION



**HIGH IMPEDANCE GROUND SOURCES** - If the supply source is a high impedance ground (IT) type, the input neutral conductor must be connected from the source of supply. If the load requires a neutral, then an input neutral conductor must be pulled into the UPS. In no circumstances shall a neutral to ground bonding jumper be installed in the UPS.

#### CAUTION



**DELTA SOURCES (TN-S)** - The UPS cannot be operated from a mid-point or end-point grounded delta supply source. With this type of supply source, there is no capability to provide an output neutral. In no circumstances shall a neutral to ground bonding jumper be installed in the UPS.

- MOBs with dual auxiliary contacts are to be provided by the customer. Table 3-15 on page 3-20 lists the recommended rating for the MOBs.

The tie cabinet must contain Module Output Breakers (MOBs) with dual auxiliary contacts for control of the system. Without dual auxiliary MOB, UPMs are not allowed to go to bypass individually during servicing. All UPMs will go to bypass instead of just the UPM needing service, decreasing critical load protection. With dual auxiliary MOB, one UPM can be bypassed while the remaining UPMs support the load as long as the remaining UPMs have the capacity to do so.

### 3.3 Inspecting and Unpacking the UPS Cabinets

The UPS cabinet is divided into two sections palletted separately for shipping. The sections are shipped bolted to wooden pallets (see Figure 3-12 and Figure 3-13) and protected with outer protective packaging material.



#### WARNING

The UPS sections are heavy (see Table 3-1 on page 3-2). If unpacking and unloading instructions are not closely followed, the cabinets may tip and cause serious injury.



#### CAUTION

To prevent damage to the wiring channel and wiring in the UPM section base when lifting or moving the cabinet:

- Lift and move the UPM section using only the front or rear forklift slots.
- Verify that the forklift forks are in a horizontal position before inserting them into the forklift slots. DO NOT angle fork tips upward.
- Insert the forks all the way through the base. DO NOT insert forks partially into the base to move the cabinet.
- Forks may be partially inserted into the front or rear forklift slots for minor positioning if the forks are kept in a horizontal position with no upward angling.
- DO NOT use the forklift slots on the end of the cabinet to move the cabinet.
- End forklift slots may be used for minor positioning if the forks are kept in a horizontal position with no upward angling.

If these instructions are not followed, damage to the wiring channel and wiring will occur.

1. Carefully inspect the outer packaging for evidence of damage during transit.



#### CAUTION

Do not install a damaged cabinet. Report any damage to the carrier and contact an Eaton service representative immediately.



**NOTE** For the following step, verify that the forklift or pallet jack is rated to handle the weight of the cabinet (see Table 3-1 on page 3-2 for cabinet weight).

2. Use a forklift or pallet jack to move the packaged cabinets to the installation site, or as close as possible, before unpacking. If possible, move the cabinets using the pallet. Insert the forklift or pallet jack forks from the right side of the pallet (facing the cabinet), between the supports on the bottom of the pallet (see Figure 3-9 and Figure 3-10 on page 3-8 for the UPS cabinet center of gravity measurements). If the cabinets must be moved using the cabinet front or rear fork lift slots, see the caution statement at the beginning of this procedure.



#### CAUTION

Do not tilt the UPS cabinets more than 10° from vertical or the cabinets may tip over.

3. Set the pallet on a firm, level surface, allowing a minimum clearance of 3m (10 ft) on each side for removing the cabinet from the pallet.




**NOTE** The ISBM and UPM sections are shipped with debris shields covering the ventilation grills on top of the sections (see Figure 4-15 on page 4-18). Do not remove the debris shields until installation is complete.


4. Remove the protective covering from the cabinets.
5. Remove the packing material, and discard or recycle in a responsible manner.
6. Inspect the contents for any evidence of physical damage, and compare each item with the Bill of Lading. If damage has occurred or shortages are evident, contact an Eaton service representative immediately to determine the extent of the damage and its impact on further installation.



**NOTE** While waiting for installation, protect the unpacked cabinets from moisture, dust, and other harmful contaminants. Failure to store and protect the UPS properly may void your warranty.



**Figure 3-12. UPS Cabinet as Shipped on Pallet (ISBM Section)**



**Figure 3-13. UPS Cabinet as Shipped on Pallet (UPM Section)**

### 4.1 Preliminary Installation Information



#### WARNING

Installation should be performed only by qualified personnel.

Refer to the following while installing the UPS system:

- Chapter 3 for cabinet dimensions, equipment weight, wiring and terminal data, and installation notes.
- Do not tilt the cabinets more than  $\pm 10^\circ$  during installation.
- Remove the conduit landing plates to add conduit landing holes as required. Plate material is 16 gauge steel (1.5 mm/0.06" thick).
- If perforated floor tiles are required for ventilation, place them in front of the UPS.

### 4.2 Unloading the UPS Sections from the Pallet

The ISBM and UPM sections are bolted to separate wooden pallets supported by wood skids. To remove the pallets:



#### WARNING

The UPS sections are heavy (see Table 3-1 on page 3-2). If unpacking and unloading instructions are not closely followed, the cabinets may tip and cause serious injury.



#### CAUTION

- Do not tilt cabinets more than  $10^\circ$  from vertical.
- Lift the cabinets only with a forklift or damage may occur.

To prevent damage to the wiring channel and wiring in the UPM section base when lifting or moving the cabinet:


- Lift and move the UPM section using only the front or rear forklift slots.
- Verify that the forklift forks are in a horizontal position before inserting them into the forklift slots. DO NOT angle fork tips upward.
- Insert the forks all the way through the base. DO NOT insert forks partially into the base to move the cabinet.
- Forks may be partially inserted into the front or rear forklift slots for minor positioning if the forks are kept in a horizontal position with no upward angling.
- DO NOT use the forklift slots on the end of the cabinet to move the cabinet.
- End forklift slots may be used for minor positioning if the forks are kept in a horizontal position with no upward angling.

If these instructions are not followed, damage to the wiring channel and wiring will occur.




**NOTE** For the following steps, verify that the forklift or pallet jack is rated to handle the weight of the cabinet (see Table 3-1 on page 3-2 for cabinet weight).

1. If not already accomplished, use a forklift or pallet jack to move the ISBM and UPM sections to the installation area, or as close as possible, before unloading from the pallets. If possible, move each section using the pallet. Insert the forklift or pallet jack forks from the right side of the pallet (facing the cabinet), between the supports on the bottom of the pallet (see Figure 3-9 and Figure 3-10 on page 3-8 for the ISBM and UPM section center of gravity measurements). If the sections must be moved using the cabinet front or rear fork lift slots, see the caution statements at the beginning of this procedure.
2. Remove the three bolts securing the left side shipping bracket to the cabinet and three bolts securing the bracket to the pallet (see Figure 4-1 or Figure 4-3). Remove the left side shipping bracket.
3. Remove the three bolts securing the right side shipping bracket to the cabinet and three bolts securing the bracket to the pallet (see Figure 4-2 or Figure 4-4). Remove the right side shipping bracket.




**Figure 4-1. Removing the ISBM Section Left Side Shipping Bracket**




**Figure 4-2. Removing the ISBM Section Right Side Shipping Bracket**

4. Using a forklift (see the caution statement at the beginning of this procedure), raise the cabinet until the cabinet bottom clears the pallet by approximately 3 mm (1/8").
5. Pull the pallet from under the cabinet. Discard or recycle the pallet and shipping brackets in a responsible manner.
6. Carefully lower the cabinet until the cabinet base contacts the floor.
7. Repeat Steps 2 through 6 for the remaining cabinet.
8. Proceed to paragraph 4.3.



**Figure 4-3. Removing the UPM Section Left Side Shipping Bracket**





**Figure 4-4. Removing the UPM Section Right Side Shipping Bracket**


### 4.3 Mechanically Joining the Sections



**NOTE** The following procedure permits the UPS sections to be installed in a location where there is limited space to slide the sections together from the sides.

**NOTE** For the following steps, verify that the forklift or pallet jack is rated to handle the weight of the section (see Table 3-1 on page 3-2 for cabinet weight).

1. Using a forklift, move the UPM section to the final installed location.
2. Remove one top screw and two bottom screws securing the UPM section wireway panel (see Figure 4-5). Lift the panel straight up to remove it from the panel hanger brackets at the top of the cabinet.
3. Remove the screws securing the top and bottom internal safety shield panels and remove the panels. Retain the hardware for later use.
4. Remove the screws securing the corner channel and remove the channel (see Figure 4-5). Retain the hardware for later use.



**Figure 4-5. Section Joining**

5. Remove the screws securing the left top panel and remove the panel (see Figure 4-5). Retain the hardware for later use.
6. Remove the screws securing the left middle panel and remove the panel (see Figure 4-5). Retain the hardware for later use.

### CAUTION




Use care during installation to protect components mounted on the right side of the ISBM section and the intercabinet wiring harnesses attached to the left side UPM section from damage.



**NOTE** Clearance between the ISBM and the UPM sections must be less than 1/2" so that joining brackets can be installed.

7. Using a forklift with the forks in the front forklift slots, position the ISBM section adjacent to the left side of the previously installed UPM section. Verify that the ISBM section right side is against the UPM section left side and the front of the cabinet bases are flush with each other (see Figure 4-6).
8. Reinstall the corner channel (see Figure 4-5) and secure using the retained hardware.
9. Reinstall the left middle panel (see Figure 4-5) and secure using the retained hardware.




**Figure 4-6. ISBM and UPM Sections Joined**

10. Reinstall the left top panel (see Figure 4-5) and secure using the retained hardware.



**NOTE** Three flat cabinet joining brackets are provided in the hardware kit for securing the ISBM and UPM sections at the top front, top rear, and front base (see Steps 11 and 12).

11. Locate the hardware kit (packed inside a drawstring bag tied to the left middle panel of the UPM section). Locate two flat brackets and screws from the hardware kit. Align the holes in the flat brackets over holes in the top rear and top front of the ISBM and UPM sections. Secure the brackets with the screws from the hardware kit (see Figure 4-7).
12. Locate one flat bracket and screws from the hardware kit. Align the holes in the flat bracket over holes in the front base of the ISBM and UPM sections. Secure the bracket with the screws from the hardware kit (see Figure 4-7).
13. Proceed to paragraph 4.4.



**Figure 4-7. ISBM Section to UPM Section Joining Brackets**

#### 4.4 Electrically Connecting the Sections

1. Unfasten the front door latch and swing the door open (see Figure 4-1 on page 4-2).
2. Remove the door. Remove the retaining screw located inside the door at the bottom hinge pivot point, then lift the door off. Retain the hardware for later use.
3. Remove the screws securing the ISBM section right bottom internal safety shield panel and remove the panel to gain access to the internal input, output, and battery terminals. Retain the hardware for later use.



**NOTE** AC and DC input intercabnet power wiring harnesses are supplied coiled and secured in the UPM wireway on the left side of the UPM section (see Figure 4-6 on page 4-7).

4. Locate the AC and DC input intercabnet power wiring harnesses (long cables labeled xG1, xG2, and xG3). Remove wire ties as necessary and uncoil the cables.
5. Locate the 1G1, 1G2, 2G1, 2G2, 3G1, and 3G2 power wiring harnesses. Route these harnesses through the wiring access in the right side panel of the ISBM section to the AC Input to UPMs terminals. See Figure 4-8 on page 4-11 for terminal locations.




---

**NOTE** Two cable lugs will be connected to each terminal stud. When connecting the cable lugs, install the first lug on the stud with the raised barrel portion facing the back of the cabinet. Install the second lug with the raised barrel portion facing the front of the cabinet.

---

6. Locate the intercabinet wiring terminal hardware kit packed on the bottom right side of the ISBM section.
7. Using hardware from the intercabinet wiring terminal hardware kit (see Table 3-9 on page 3-15), connect phase A, B, and C cable lug connections to the AC Input to UPMs terminals. Follow the callout details in Figure 4-9 on page 4-12 to connect the correct cable lug to the proper terminals. See paragraph 3.2.2 on page 3-9 for wiring and termination requirements.




---

**NOTE** In Step 8 if wiring a UPS with a Momentary Static Switch (MSS), route the wiring harnesses in the area as shown in Figure 4-8 on page 4-11 to provide operating clearance for the bypass breaker CB4 charging handle.

---

8. Locate the 1G3, 2G3, and 3G3 power wiring harnesses. Route these harnesses through the wiring access in the right side panel of the ISBM section to the DC Input to UPMs terminals. See Figure 4-8 on page 4-11 for terminal locations.




---

**NOTE** When connecting the UPM battery cables, verify the cables are connected to the correct terminals.

---

9. Using hardware from the intercabinet wiring terminal hardware kit (see Table 3-9), connect the positive and negative cable lug connections to the DC Input to UPMs terminals. Follow the callout details in Figure 4-10 on page 4-13 to connect the correct cable lug to the proper terminals. See paragraph 3.2.2 on page 3-9 for wiring and termination requirements.




---

**NOTE** AC output intercabinet power wiring harnesses are supplied attached to the interior left side panel of the UPM section (see Figure 4-5 on page 4-6).

---

10. Locate the 1G4, 1G5, 2G4, 2G5, 3G4, and 3G5 power wiring harnesses. Remove the front two columns of wire ties securing the cables to facilitate routing cables to the AC Output from UPMs terminals. See Figure 4-8 on page 4-11 for terminal locations.




---

**NOTE** Two cable lugs will be connected to each terminal stud. When connecting the cable lugs, install the first lug on the stud with the raised barrel portion facing the back of the cabinet. Install the second lug with the raised barrel portion facing the front of the cabinet.

---

11. Using hardware from the intercabinet wiring terminal hardware kit (see Table 3-9), connect phase A, B, and C and Neutral cable lug connections to the AC Output from UPMs terminals. Follow the callout details in Figure 4-11 on page 4-13 to connect the correct cable lug to the proper terminals. See paragraph 3.2.2 on page 3-9 for wiring and termination requirements.
12. Install the remaining hardware (three washers, conical washers, and nuts) onto the AC Input to UPMs terminals designated for the four UPM model and secure the hardware (see Figure 4-9 on page 4-12). This hardware is used by an Eaton Customer Service Engineer to install a Field Installed UPM (FI-UPM).

13. Locate the ground braid in the bottom left front corner of the UPM section. The ground braid is secured at the factory to the UPM section ground bolt. Route the ground braid through the wiring access in the right side panel of the ISBM section to the ground bolt in the ISBM section.
14. Connect the ground braid to the ISBM section ground bolt and secure.




---

**NOTE** Four intercabinet interface wiring harnesses are supplied coiled inside the protective cage on the right side panel of the ISBM section (see A in Figure 4-12 on page 4-14).

---

15. In the ISBM section (see A in Figure 4-12 on page 4-14), locate the coiled wiring harnesses with the J50, J51, J61, and J70 connectors attached. Remove the wire ties securing the harnesses and carefully remove the harnesses from the protective cage. If necessary, loosen the screws securing the protective cage.
16. Locate the mating P50 connector in the UPM section wireway (see B in Figure 4-12 on page 4-14) and connect the P50 connector to the J50 connector.
17. Locate the mating P51 connector in the UPM section wireway (see B in Figure 4-12 on page 4-14) and connect the P51 connector to the J51 connector.
18. Locate the mating P61 connector in the UPM section wireway (see B in Figure 4-12 on page 4-14) and connect the P61 connector to the J61 connector.
19. Locate the mating P70 connector in the UPM section wireway (see B in Figure 4-12 on page 4-14) and connect the P70 connector to the J70 connector.





---

**NOTE** One intercabinet interface cable is supplied coiled against the left side panel of the UPM section (see B in Figure 4-12 on page 4-14).

---


20. In the UPM section (see B in Figure 4-12 on page 4-14), locate the coiled RJ-45 CAN cable. Remove the wire ties securing the cable to the interior left side panel of the UPM section. Route this cable through the round wiring access in the right side panel of the ISBM section (see B in Figure 4-12 on page 4-14).
21. In the ISBM section, locate the J39 inverter CAN connector on the PI1 interface board and connect the RJ-45 CAN cable connector to the J39 connector (see Figure 4-13 and Figure 4-14 on page 4-15).
22. Dress the interface harnesses and secure in place with wire ties as necessary to prevent wire damage.
23. When all wiring is complete, reinstall the safety shield panels removed in previous steps.
24. Reinstall the front wireway panel.
25. If installing a four UPM UPS, proceed to paragraph 4.5; otherwise, proceed to Step 26.
26. If installing a battery system, proceed to paragraph 4.6; otherwise, proceed to Step 27.
27. If installing a tie cabinet or distribution panel for a distributed bypass system, proceed to paragraph 4.7; otherwise, proceed to paragraph 4.8.



**NOTE** On a UPS configured with a Continuous Static Switch (CSS), CB4 is not installed.

**NOTE** On a UPS configured as an Input Output Module (IOM), CB4 is not installed.

**Figure 4-8. ISBM Section Intercabinet Power Terminal Locations**




**NOTE** Two cable lugs will be connected to each terminal stud. When connecting the cable lugs, install the first lug on the stud with the raised barrel portion facing the back of the cabinet. Install the second lug with the raised barrel portion facing the front of the cabinet.

**NOTE** On a UPS without CB1, UPM input wiring terminations are in the same positions on the bus bars installed in the place of CB1.


**NOTE** On a UPS configured as an IOM, UPM input wiring terminations are the same as an ISBM configuration.

**Figure 4-9. ISBM Section Input Power Terminal Detail**






**Figure 4-10. ISBM Section Battery Input Power Terminal Detail**




**NOTE** Two cable lugs will be connected to each terminal stud. When connecting the cable lugs, install the first lug on the stud with the raised barrel portion facing the back of the cabinet. Install the second lug with the raised barrel portion facing the front of the cabinet.

**Figure 4-11. ISBM Section Output Power Terminal Detail**



**Figure 4-12. UPS Intercabinet Interface Harness Locations**



ISBM Section Right Side Inside View

Figure 4-13. P11 Interface Board Location




Figure 4-14. J39 Location on P11 Interface Board

## 4.5 Field Installed UPM Installation



---

**NOTE** FI-UPM installation is not applicable to a three UPM model.

---

If installing a four UPM model, install the FI-UPM using the instructions in the *Eaton 9395 Field Installed UPM Mechanical Installation Manual*, listed in paragraph 1.8 on page 1-9. After the FI-UPM is installed, proceed to paragraph 4.6 if installing a battery system; otherwise, proceed to paragraph 4.7 to complete the wiring of the UPS.

## 4.6 Battery System Installation

If installing a battery system, install the customer-supplied battery system according to the battery and battery system manufacturer's instructions and all applicable codes and regulations, including the NEC, Article 480. After the battery system is installed, proceed to paragraph 4.7 if installing a distributed bypass tie cabinet; otherwise, proceed to paragraph 4.8 to complete the wiring of the UPS.

## 4.7 Distributed Bypass Tie Cabinet Installation



---

**NOTE** The tie cabinet must contain Module Output Breakers (MOBs) with dual auxiliary contacts for control of the system. Without dual auxiliary MOBs, UPMs are not allowed to go to bypass individually during servicing. All UPMs will go to bypass instead of just the UPM needing service, decreasing critical load protection. With dual auxiliary MOBs, one UPM can be bypassed while the remaining UPMs support the load as long as the remaining UPMs have the capacity to do so.

---

If installing a distributed bypass system, install the customer-supplied tie cabinet or distribution panel according to the tie cabinet or distribution panel manufacturer's instructions and all applicable codes and regulations, including the NEC, Article 480. After the tie cabinet is installed, proceed to paragraph 4.8 to complete the wiring of the UPS.

## 4.8 Installing UPS External and Battery Power Wiring



**NOTE** The ISBM and UPM sections are shipped with debris shields covering the ventilation grills on top of the sections (see Figure 4-15). Do not remove the debris shields until installation is complete. However, remove the shields before operating the UPS. Once the debris shields are removed, do not place objects on the ventilation grills.

**NOTE** Remove the ISBM section top or bottom conduit landing plate to drill or punch conduit holes (see Figure 4-16 on page 4-19).

**NOTE** If the load requires a neutral, a bypass source neutral must be provided. If the load does not require a neutral and there is no neutral conductor connected at the bypass input, a neutral to ground bonding jumper must be installed. **DO NOT** install both a source neutral and a bonding jumper. See Table 3-4 on page 3-11 for neutral bonding jumper wire sizes. Bonding jumper must be copper wire.

### CAUTION



**HIGH IMPEDANCE GROUND SOURCES** - If the supply source is a high impedance ground (IT) type, the input neutral conductor must be connected from the source of supply. If the load requires a neutral, then an input neutral conductor must be pulled into the UPS. In no circumstances shall a neutral to ground bonding jumper be installed in the UPS.

### CAUTION



**DELTA SOURCES (TN-S)** - The UPS cannot be operated from a mid-point or end-point grounded delta supply source. With this type of supply source, there is no capability to provide an output neutral. In no circumstances shall a neutral to ground bonding jumper be installed in the UPS.

Use the procedures in the following paragraphs to connect the external and battery power wiring.

### 4.8.1 External Power Wiring Installation

To install wiring to connections:

1. Remove one top screw and two bottom screws securing each ISBM section left and right front panel (see Figure 4-2 on page 4-3). Lift the panels straight up to remove them from the panel hanger brackets at the top of the cabinet.
2. Remove the screws securing the top and bottom internal safety shield panels and remove the panels to gain access to the input, output, and battery terminals. Retain the hardware for later use.
3. Route the input and output cables through either the top or bottom of the cabinet to the UPS terminals. See Figure 4-16 through Figure 4-19 for wiring access information and terminal locations.

**Top Access Wiring.** Remove the top conduit plate from the top of the ISBM section. Identify all conduit requirements and mark their location. Drill and punch all conduit holes in the top conduit plate prior to mounting on the ISBM section. Install the conduit plate and install all conduit runs into the plate. Pull wiring through conduit into the ISBM section wiring area.

**Bottom Access Wiring.** Remove the bottom conduit plate from the inside bottom of the ISBM section. Identify all conduit requirements and mark their location. Drill and punch all conduit holes in the bottom conduit plate prior to mounting on the ISBM section. Install the conduit plate and install all conduit runs into the plate. Pull wiring through conduit into the ISBM section wiring area.






Figure 4-15. ISBM and UPM Section Debris Shields



**Figure 4-16. ISBM Section Conduit and Wire Entry Locations**

4. Locate the external wiring terminal hardware kit packed on the bottom left side of the ISBM section.
5. Using hardware from the external wiring terminal hardware kit (see Table 3-11 on page 3-17), connect phase A, B, and C rectifier input power wiring from the utility source to the rectifier input terminals in the ISBM section. See paragraph 3.2.2 on page 3-9 for wiring and termination requirements.
6. If installing a UPS configured as an Input Output Module (IOM), proceed to Step 8; otherwise, proceed to Step 7.
7. Using hardware from the external wiring terminal hardware kit (see Table 3-11 on page 3-17), connect phase A, B, and C, and Neutral (if required) bypass input power wiring from the utility source to the bypass input terminals and neutral terminals in the ISBM section. See paragraph 3.2.2 on page 3-9 for wiring and termination requirements.
8. If wiring a distributed bypass system, proceed to Step 9; otherwise, proceed to Step 11.


**CAUTION**

Distributed bypass system wiring length should be in accordance with Figure 4-17, to ensure approximately equal current sharing when in Bypass mode.

---

9. Using hardware from the external wiring terminal hardware kit (see Table 3-11 on page 3-17), connect phase A, B, and C, and Neutral power wiring from the output and neutral terminals of each UPS unit to the customer-supplied tie cabinet or load distribution panel. See paragraph 3.2.2 on page 3-9 for wiring and termination requirements.
10. Proceed to paragraph 4.8.2.
11. Using hardware from the external wiring terminal hardware kit (see Table 3-11 on page 3-17), connect phase A, B, and C, and Neutral (if required) power wiring from output terminals and neutral terminals to the critical load. See paragraph 3.2.2 on page 3-9 for wiring and termination requirements.
12. Proceed to paragraph 4.8.2.






**NOTE** Required parallel system wiring length must be equal to ensure approximately equal current sharing when in Bypass mode. For proper operation the following must be true:

$$1A = 2A = 3A = 4A$$

$$1B = 2B = 3B = 4B$$


**NOTE** Any difference in wire length will result in decreased capacity of the UPS system while on bypass. For example, a 10% difference between the longest and shortest wire lengths will result in a decrease in bypass capacity of 10%.

**Figure 4-17. Distributed Bypass Wire Length**



**NOTE** AC Input to Bypass terminals are not applicable to an IOM configuration.

**Figure 4-18. ISBM Section Power Terminal Locations**



**NOTE** AC Input to Bypass terminals are not applicable to an IOM configuration.

**Figure 4-19. ISBM Section Power Terminal Detail AA**

## 4.8.2 Battery Power Wiring



### CAUTION

When sizing the battery system, do not exceed the internal battery charger capabilities. See Chapter 10, "Product Specifications," for maximum battery charger currents.

To install wiring to connections:



**NOTE** An installed FI-UPM is always designated as UPM 4.

1. Route the battery cables between the ISBM section and the battery system or battery disconnect. See Figure 4-16, Figure 4-18, Figure 4-20, and Figure 4-21 for wiring access information and terminal locations.
2. If wiring the UPS for a common battery, proceed to Step 3; if wiring for a separate battery, proceed to Step 5.
3. Using hardware from the external wiring terminal hardware kit (see Table 3-11 on page 3-17), connect the positive, negative, and ground DC power wiring from the battery system or disconnect to the ISBM section battery and ground terminals. Use both sets of terminals shown in Figure 4-20 as needed. See paragraph 3.2.2 on page 3-9 for wiring and termination requirements.
4. Proceed to Step 6.
5. Using hardware from the external wiring terminal hardware kit (see Table 3-11 on page 3-17), connect the positive, negative, and ground DC power wiring from the battery systems or disconnects to the ISBM section battery and ground terminals. Use one set of terminals for each UPM as shown in Figure 4-21. See paragraph 3.2.2 on page 3-9 for wiring and termination requirements.
6. After wiring the UPS system to the facility power and critical load, be sure to ground the system according to local and/or national electrical wiring codes.
7. If wiring interface connections, proceed to paragraph 4.9; otherwise, proceed to Step 8.
8. When all wiring is complete, reinstall the top and bottom safety shield panels removed in paragraph 4.8.1, Step 2 on page 4-17. Secure with the retained hardware.
9. Reinstall the left front panel removed in paragraph 4.8.1, Step 1 on page 4-17 and secure with the retained hardware.




Figure 4-20. ISBM Section Power Terminal Detail BB – Common Battery




Figure 4-21. ISBM Section Power Terminal Detail BB – Separate Battery

## 4.9 Installing Interface Connections



### WARNING

Hazardous voltages are present near the user interface terminal area if the UPS is not totally disconnected.

Use the procedures in the following paragraphs to connect the TB1, TB1 Battery, TB2, and TB3 interface connections.

### 4.9.1 TB1, TB2, and TB3 Connections (Other than TB1 Battery Interface Connections)



**NOTE** When installing interface wiring for TB1, TB2, and TB3 connections, conduit must be installed between each device and the UPS cabinet.

**NOTE** Interface wiring must be installed from the top of the UPS cabinet.

To install wiring to connections:

1. Verify the UPS system is turned off and all power sources are removed. See Chapter 7, "UPS Operating Instructions," for shutdown instructions.
2. If not already opened, unfasten the front door latch and swing the door open (see Figure 4-1 on page 4-2).
3. If not already removed, remove the door. Remove the retaining screw located inside the door at the bottom hinge pivot point, then lift the door off. Retain the hardware for later use.
4. Terminal block TB3 is accessible on the left side of the X-Slot communication bay. To gain access to terminal block TB1, TB2, and the left interface entry conduit landing plates, remove the screws securing the top internal safety shield panel and remove the panel. Retain the hardware for later use (see Figure 4-22 on page 4-28).
5. Remove the interface entry conduit landing plates to drill or punch holes (see Figure 4-16 on page 4-19).
6. Reinstall the interface entry plates and install the conduit.



### WARNING

Do not directly connect relay contacts to the mains related circuits. Reinforced insulation to the mains is required.

7. To locate the appropriate terminals and review the wiring and termination requirements, see paragraph 3.2.3 on page 3-21, Table 4-1 on page 4-29, and Figure 4-22 through Figure 4-25.
8. Route and connect the wiring.
9. If wiring TB1 battery interface connections, proceed to paragraph 4.9.2; if wiring the X-Slot connections only, proceed to paragraph 4.9.3; otherwise, proceed to Step 10.
10. Reinstall the top internal safety shield panel and secure with the retained hardware.

11. Reinstall the front door removed in Step 3 and secure with the retained hardware.
12. Close the door and secure the latch.




Figure 4-22. ISBM Section Interface Terminal Locations



**Table 4-1. TB1, TB2, and TB3 Interface Connections**

Terminal TB1	Name	Description
1	REPO NC	Input: Normally-closed dry contact used to activate UPS EPO from a remote switch.
2	REPO Return	
3	REPO NO	Input: Normally-open dry contact used to activate UPS EPO from a remote switch.
4	REPO Return	
5	Battery Aux	Input: Normally-open contact used to indicate when UPS battery breaker is open or closed.
6	Battery Aux Common	
7	48 Vdc Battery Shunt Trip +	Output: Contacts used to open battery breaker or disconnect.
8	48 Vdc Battery Shunt Trip –	
9	Output Contactor K3 NC Aux	Output: Normally-closed contact opens when output contactor closes.
10	Output Contactor K3 NC Aux Common	


  

Terminal TB2	Name	Description
1	Pull Chain	Output: Backup control for parallel operation.
2	Pull Chain Common	
3	Alarm Relay NC	Output: General purpose normally-closed (NC) relay contact.
4	Alarm Relay Common	
5	Alarm Relay NO	Output: General purpose normally-open (NO) relay contact.
6	Alarm Relay Common	
7	Not Used	
8	Not Used	
9	Not Used	
10	Not Used	


  

Terminal TB3	Name	Description
1	Building Alarm 1	Input: Programmable UPS alarm, activated by a remote dry contact closure.
2	Building Alarm 1 Return	
3	Building Alarm 2	Input: Programmable UPS alarm, activated by a remote dry contact closure.
4	Building Alarm 2 Return	
5	Building Alarm 3 Default: Charger Off	Input: Programmable UPS alarm, activated by a remote dry contact closure. Default function set for charger off.
6	Building Alarm 3 Return	
7	Building Alarm 4 Default: On Generator	Input: Programmable UPS alarm, activated by a remote dry contact closure. Default function set for on generator.
8	Building Alarm 4 Return	
9	Building Alarm 5 Default: Maintenance Bypass	Input: Programmable UPS alarm, activated by a remote dry contact closure. Default function set for maintenance bypass.
10	Building Alarm 5 Return	

NOTE "Return" indicates connection to electronics circuit ground. "Common" indicates connection to common side of isolated relay contact.




**Figure 4-23. Interface Terminal Detail**



- NOTE** Alarm relay contacts have a maximum current rating of 5A and a switched voltage rating of 30 Vac and 28 Vdc.
- NOTE** Alarm relay normally-open and normally-closed return terminals are separated on the terminal board but are electrically in common.
- NOTE** Do not directly connect relay contacts to the mains related circuits. Reinforced insulation to the mains is required.
- NOTE** Alarm relay wiring should be a minimum of 22 AWG.

**Figure 4-24. Typical Alarm Relay Connection**



**NOTE** All building alarm inputs require an isolated normally-open or normally-closed contact or switch (rated at 24 Vdc, 20 mA minimum) connected between the alarm input and common terminal as shown. Building alarm inputs can be programmed for use with either normally-open or normally-closed contacts. All control wiring and relay and switch contacts are customer-supplied.

**NOTE** The building alarms can be programmed to display the alarm functional name.

**NOTE** A jumper wire must be connected between pins 1 and 2 on TB1, if the normally-closed REPO contact is not used.

**Figure 4-25. Terminal Blocks TB1, TB2, and TB3 Connector Assignments**

## 4.9.2 TB1 Battery Interface Connections

To install wiring to connections:

1. Verify the UPS system is turned off and all power sources are removed. See Chapter 7, "UPS Operating Instructions," for shutdown instructions.
2. Unfasten the front door latch and swing the door open (see Figure 4-1 on page 4-2).
3. Remove the door. Remove the retaining screw located inside the door at the bottom hinge pivot point, then lift the door off. Retain the hardware for later use.
4. To gain access to terminal block TB1 and the interface entry conduit landing plate, remove the screws securing the top internal safety shield panel and remove the panel. Retain the hardware for later use (see Figure 4-22 on page 4-28).
5. To locate the appropriate terminals and review the wiring and termination requirements, see paragraph 3.2.2 on page 3-9, Table 4-1 on page 4-29, and Figure 4-22 through Figure 4-27.





---

**NOTE** *When installing shunt trip and battery aux interface wiring to the UPS interface terminals, conduit must be installed between the UPS and battery system.*


---

6. Remove the left interface entry conduit landing plate to drill or punch holes (see Figure 4-16 on page 4-19).
7. Reinstall the interface entry plate and install the conduit.
8. Route the shunt trip (optional) and battery aux wiring from the battery disconnects to the UPS cabinet. See Figure 4-16 and Figure 4-18 for UPS wiring access information and terminal locations.
9. Connect the wiring to the TB1 terminals.
10. Reinstall the top internal safety shield panel and secure with the retained hardware.
11. Reinstall the front door removed in Step 3 and secure with the retained hardware.
12. If wiring X-Slot connections, proceed to paragraph 4.9.3; otherwise, proceed to Step 13.
13. Close the door and secure the latch.



**NOTE** Battery aux and DC shunt trip wiring should be a minimum of 18 AWG.

**Figure 4-26. Typical Battery Interface Connection – Common Battery System**



**NOTE** Battery aux and DC shunt trip wiring should be a minimum of 18 AWG.

**Figure 4-27. Typical Battery Interface Connection – Separate Battery System**

### 4.9.3 X-Slot Connections




**NOTE** LAN and telephone drops for use with X-Slot cards must be provided by the customer.

**NOTE** When installing external wiring to X-Slot cards, conduit must be installed to the UPS cabinet. When installing internal wiring to X-Slot terminals, route the wiring through the internal opening in the X-Slot communication bay.

For installation and setup of an X-Slot card, contact an Eaton service representative (see page 1-10).

To install wiring to connections:

1. If not already installed, install the LAN and telephone drops.
2. Unfasten the front door latch and swing the door open (see Figure 4-1 on page 4-2).
3. Remove the right interface entry conduit landing plate to drill or punch holes (see Figure 4-16 on page 4-19).
4. Reinstall the interface entry plate and install the conduit.
5. Route and install the LAN, telephone, and other cables to the appropriate X-Slot cards. See Figure 4-22 on page 4-28 and Figure 4-28 for X-Slot communication bay locations.
6. Close the door and secure the latch.
7. Refer to the manual supplied with the X-Slot card for operator instructions.



**Figure 4-28. X-Slot Communication Bays**

## 4.10 Installing a REPO Switch

A latching-type Remote Emergency Power-off (REPO) switch can be used in an emergency to shut down the UPS and remove power to the critical load from a location away from where the UPS is installed. Figure 4-29 shows a REPO switch.



**NOTE** Before installing a REPO switch, verify that the UPS was installed according to the instructions in paragraphs 4.2 through 4.9.

**NOTE** When installing the REPO switch, you must install conduit between the device and the UPS cabinet for wiring the switch.

**NOTE** Remove the UPS cabinet interface entry conduit landing plates to drill or punch holes (see Figure 4-16 on page 4-19).

**NOTE** The REPO switch must be a normally-open or normally-closed latching-type switch not tied into any other circuits.

**NOTE** This procedure is intended to be used for the installation of the Eaton Corporation-supplied REPO switch. If installing another manufacturer's switch, use this procedure only as a guide.

**NOTE** The REPO switch wiring must be in accordance with NEC Article 725 Class 2 requirements.

To Install a REPO switch:

1. Verify the UPS system is turned off and all power sources are removed. See Chapter 7, "UPS Operating Instructions," for shutdown instructions.
2. Securely mount the REPO switch. Recommended locations include operator's consoles or near exit doors. See Figure 3-11 on page 3-9 for enclosure dimensions and wiring knockouts.
3. Unfasten the front door latch and swing the door open (see Figure 4-1 on page 4-2).
4. Remove the door. Remove the retaining screw located inside the door at the bottom hinge pivot point, then lift the door off. Retain the hardware for later use.





Figure 4-29. REPO Switch

5. To gain access to terminal block TB1 and the interface entry conduit landing plate, remove the screws securing the top internal safety shield panel and remove the panel. Retain the hardware for later use (see Figure 4-22 on page 4-28).
6. Remove the left interface entry conduit landing plate to drill or punch holes (see Figure 4-16 on page 4-19).
7. Reinstall the interface entry plate and install conduit.
8. To locate the appropriate terminals and review the wiring and termination requirements, see paragraph 3.2.2 on page 3-9, Table 4-1 on page 4-29, and Figure 4-22 through Figure 4-25 starting on page 4-31.
9. Route and connect the wiring as shown in Table 4-2 and Figure 4-30.
10. If the normally-closed REPO TB1 connection in the UPS is not used, connect a jumper wire between pins 1 and 2 on TB1.
11. If you are installing multiple REPO switches, wire additional switches in parallel with the first REPO.

**Table 4-2. REPO Wire Terminations**

From REPO Station(s) Switch Contact Block (Either Block)	To Customer Interface Terminal Board TB1 in UPS Cabinet	Wire Size	Tightening Torque
3 NO	TB1-3	Twisted Wires (2) 14–22 AWG (0.75–4.0 mm <sup>2</sup> )	7 lb in (0.8 Nm)
4 NO	TB1-4		



**NOTE** REPO switch rating is 24 Vdc, 1A minimum.

**NOTE** The REPO switch must be a latching-type switch not tied to any other circuits.


**NOTE** REPO normally-open and normally-closed return terminals are separated on the terminal board but are electrically in common.

**Figure 4-30. Normally-Open REPO Switch Wiring**



12. If required, install wiring from the REPO switch to the trip circuitry of the upstream protective devices. A second contact block is provided on the REPO switch for this function (see Figure 4-29). The REPO switch wiring must be in accordance with NEC Article 725 Class 2 requirements.
13. Reinstall the top internal safety shield panel and secure with the retained hardware.
14. Reinstall the front door removed in Step 4 and secure with the retained hardware.
15. Close the door and secure the latch.

Figure 4-31 shows the wiring connections if the normally-closed REPO contacts are used and Figure 4-32 shows alternative methods of connecting a REPO switch if using another manufacturer's switch.




**NOTE** REPO switch rating is 24 Vdc, 1A minimum.

**NOTE** The REPO switch must be a latching-type switch not tied to any other circuits.

**NOTE** REPO normally-open and normally-closed return terminals are separated on the terminal board but are electrically in common.

**Figure 4-31. Normally-Closed REPO Switch Wiring**



**NOTE** REPO switch rating is 24 Vdc, 1A minimum.

**NOTE** The REPO switch must be a latching-type switch not tied to any other circuits.

**NOTE** REPO normally-open and normally-closed return terminals are separated on the terminal board but are electrically in common.

**Figure 4-32. Normally-Closed and Normally-Open REPO Switch Wiring**

#### 4.11 Installing Options, Accessories, and Distributed Bypass Control Wiring

To install options, accessories, and distributed bypass control wiring, see Chapter 5, "Installing Options and Accessories."

#### 4.12 Initial Startup

Startup and operational checks must be performed by an authorized Eaton Customer Service Engineer, or the warranty terms specified on page W-1 become void. This service is offered as part of the sales contract for the UPS. Contact an Eaton service representative in advance (usually a two-week notice is required) to reserve a preferred startup date.

#### 4.13 Completing the Installation Checklist

The final step in installing the UPS system is completing the following Installation Checklist. This checklist ensures that you have completely installed all hardware, cables, and other equipment. Complete all items listed on the checklist to ensure a smooth installation. Make a copy of the Installation Checklist before filling it out, and retain the original.

After the installation is complete, an Eaton Customer Service Engineer must verify the operation of the UPS system and commission it to support the critical load. The service representative cannot perform any installation tasks other than verifying software and operating setup parameters. Service personnel may request a copy of the completed Installation Checklist to verify all applicable equipment installations have been completed.



**NOTE** The Installation Checklist MUST be completed prior to starting the UPS system for the first time.

## Installation Checklist

- All packing materials and restraints have been removed from each cabinet.
- Each cabinet in the UPS system is placed in its installed location.
- Joining brackets are installed between the ISBM and UPM sections.
- Intercabinet power wiring is installed between the ISBM and UPM sections.
- Intercabinet interface wiring is installed between the ISBM and UPM sections.
- A cabinet grounding/mounting kit is installed between the ISBM and UPM sections.
- All conduits and cables are properly routed to the UPS and any ancillary cabinets.
- All power cables are properly sized and terminated.
- Neutral conductors are installed or bonded to ground per requirements.
- Battery cables are terminated on E4 (+) and E5 (-).
- Battery aux contact signal wiring is connected from the UPS to the battery disconnect.
- Battery shunt trip signal wiring is connected from the UPS to the battery disconnect. (OPTIONAL)
- LAN and telephone drops are installed.
- All telephone and LAN connections have been completed.
- A ground conductor is properly installed.
- Air conditioning equipment is installed and operating correctly.
- The area around the installed UPS system is clean and dust-free. (It is recommended that the UPS be installed on a level floor suitable for computer or electronic equipment.)
- Adequate workspace exists around the UPS and other cabinets.
- Adequate lighting is provided around all UPS equipment.
- A 120 Vac service outlet is located within 7.5 meters (25 feet) of the UPS equipment.
- The REPO device is mounted in its installed location and its wiring is terminated inside the UPS cabinet.
- The normally-closed (NC) Emergency Power-off contact (pins 1 and 2 on TB1) is jumpered if not used.
- Alarm relays and building alarms are wired appropriately. (OPTIONAL)
- A remote battery disconnect is mounted in its installed location and its wiring is terminated inside the UPS. (OPTIONAL)
- Accessories are mounted in installed locations and wiring is terminated inside the UPS cabinet. (OPTIONAL)
- The debris shields covering the UPS cabinet ventilation grills are removed.
- Startup and operational checks are performed by an authorized Eaton Customer Service Engineer.

### **Distributed Bypass Installation Checklist**


- Each cabinet in the distributed bypass system is placed in its installed location.
- All conduits and cables are properly routed to the UPS cabinets and to the tie cabinet or distribution panel.
- All power cables are properly sized and terminated.
- Neutral conductors are installed or bonded to ground as per requirements.
- A ground conductor is properly installed.
- Controller Area Network (CAN) wiring between the UPS cabinets is properly installed.
- Pull-chain wiring between the UPS cabinets is properly installed.
- Adequate workspace exists around the UPS cabinets, the tie cabinet, and other cabinets.
- Startup and operational checks are performed by an authorized Eaton Customer Service Engineer.



This page intentionally left blank.

### 5.1 Installing an Optional Powerware Hot Sync CAN Bridge Card

As an option, a Powerware Hot Sync Controller Area Network (CAN) Bridge Card, shown in Figure 5-1, can be installed to provide connectivity for operational mode control of a parallel system. In addition, this card can be used to connect optional system monitoring devices, such as a Remote Monitor Panel II, a Relay Interface Module II, or a Supervisory Contact Module II to the UPS.



**Figure 5-1. Powerware Hot Sync CAN Bridge Card**



**NOTE** Only one Powerware Hot Sync CAN Bridge Card can be installed in the UPS. Multiple CAN cards are not supported and will cause system conflicts.

To install the card:

1. Verify the UPS system is turned off and all power sources are removed. See Chapter 7, "UPS Operating Instructions," for shutdown instructions.
2. Unfasten the front door latch and swing the door open (see Figure 4-1 on page 4-2).
3. Install the Powerware Hot Sync CAN Bridge Card into an open X-Slot communication bay on the front of the UPS. See Figure 4-22 on page 4-28 and Figure 4-28 on page 4-34 for X-Slot communication bay locations.

4. Read and understand the following notes while planning and performing the wiring installation:
  - Conduit must be installed between the UPS cabinet and the device for signal wiring. Conduit must be installed between the device and the power source for power wiring. Install the signal wiring in separate conduit from the power wiring.
  - Conduit and wiring between the UPS and the device are to be supplied by the customer.
  - Maximum distance between the UPS cabinet and the device is not to exceed 150 meters (500 feet).
  - Use Class 1 wiring methods (as defined by the NEC) for interface and power wiring up to 30V. The wire should be rated at 24V, 1A minimum.
  - Use Class 2 wiring methods (as defined by the NEC) for interface and power wiring from 30 to 600V.
  - Signal wiring should be a minimum of 22 AWG and a maximum of 14 AWG. The wire should be twisted pair, rated for 5A maximum. Power wiring should be a minimum of 22 AWG and a maximum of 14 AWG. The wire should be rated for 1A minimum.
  - Use only 75°C copper wire.
  - 120 Vac for the RMP II, RIM II, or SCM II should be provided from the critical bus by facility planners or the customer.
  
5. Install wiring from the Powerware Hot Sync CAN Bridge Card in accordance with the following instructions:
  - Parallel system wiring (see paragraph 5.2)
  - RMP II (see paragraph 5.3)
  - RIM II (see paragraph 5.4)
  - SCM II (see paragraph 5.5)

To locate the appropriate terminals on the Powerware Hot Sync CAN Bridge Card, see Figure 5-2 and Table 5-1.






Figure 5-2. Powerware Hot Sync CAN Bridge Card Connections

Table 5-1. Powerware Hot Sync CAN Bridge Card Interface Connections

J3 Terminal	Name	Description
1	Alarm	Programmable UPS alarm. Activated by a remote dry contact closure.
2	Alarm Return	
3	Alarm Relay NC	Normally-closed contact opens when UPS is on bypass.
4	Alarm Relay Com	Bypass contact return.
5	Alarm Relay NO	Normally-open contact closes when UPS is on bypass.
6	TX	RMP II, RIM II, and SCM II connections.
7	TX	
8	CAN L	CAN input for parallel operation.
9	Can H	
10	Shield	

## 5.2 Installing Distributed Bypass Control Wiring



**NOTE** When installing external wiring to the Powerware Hot Sync CAN Bridge Card, conduit must be installed to the UPS cabinet. When installing internal wiring to the Powerware Hot Sync CAN Bridge Card terminals, route the wiring through the internal opening in the X-Slot communication bay.

**NOTE** When installing interface wiring for the pull chain, conduit must be installed between UPSs.


To install distributed bypass control wiring:

1. Verify the UPS system is turned off and all power sources are removed. See Chapter 7, "UPS Operating Instructions," for shutdown instructions.
2. Perform the procedure listed in paragraph 5.1.
3. Terminal block TB3 is accessible on the left side of the X-Slot communication bay (see Figure 4-22 on page 4-28). To gain access to terminal block TB1, TB2, and the left interface entry conduit landing plates, remove the screws securing the top internal safety shield panel and remove the panel. Retain the hardware for later use.
4. Remove the interface entry conduit landing plates to drill or punch holes (see Figure 4-16 on page 4-19).
5. Reinstall the interface entry plates and install the conduit.
6. To locate the appropriate terminals and review the wiring and termination requirements, see paragraph 3.2.3 on page 3-21, Table 4-1 on page 4-29, and Figure 4-22 through Figure 4-25.
7. Route and install CAN wiring between the UPS cabinets. See Figure 5-2 and Table 5-1 for the Powerware Hot Sync CAN Bridge Card terminal location and Figure 5-3, Figure 5-4, and Table 5-2 for wiring information.
8. If a tie cabinet with Module Output Breakers (MOBs) is being wired, proceed to Step 11; otherwise, proceed to Step 9.
9. Route and install distributed bypass system pull-chain wiring between the UPS cabinets. See Figure 5-5 and Table 5-3 on page 5-6 for wiring information.
10. Proceed to Step 12.
11. Route and install distributed bypass system pull-chain wiring between the UPS cabinets and tie cabinet MOBs. See Figure 5-6 on page 5-7 and Table 5-4 on page 5-8 for wiring information.




**NOTE** Setup of the Powerware Hot Sync CAN Bridge Card for parallel operation must be performed by an authorized Eaton Customer Service Engineer. Contact an Eaton service representative to schedule a date.

12. Reinstall the top internal safety shield panel and secure with the retained hardware.
13. Close the door and secure the latch.



**NOTE** This drawing is for distributed bypass wiring purposes and is not a floor layout plan. UPSs can be placed in any physical order.

**Figure 5-3. Distributed Bypass System CAN and Pull-Chain Simplified Interface Wiring**




**NOTE** External CAN connections between UPSs require shielded twisted pair wire.

**Figure 5-4. Distributed Bypass System UPS CAN Wiring without MOBs**

**Table 5-2. CAN Bridge Card Wiring Terminations**

From UPS 1 CAN Bridge Card	To UPS 2 CAN Bridge Card	To UPS 3 CAN Bridge Card (If Installed)	To UPS 4 CAN Bridge Card (If Installed)
J3-8 (L)	J3-8 (L)	J3-8 (L)	J3-8 (L)
J3-9 (H)	J3-9 (H)	J3-9 (H)	J3-9 (H)
J3-10 (Shield)	J3-10 (Shield)	J3-10 (Shield)	J3-10 (Shield)




**NOTE** Use twisted pair wiring between the UPS and MOB AUX contacts.

**Figure 5-5. Distributed Bypass Pull-Chain Wiring without MOBs**

**Table 5-3. Pull-Chain Wiring Terminations**

From UPS 1	To UPS 2	To UPS 3 (If Installed)	To UPS 4 (If Installed)
TB2-1 (Pull Chain)	TB2-1 (Pull Chain)	TB2-1 (Pull Chain)	TB2-1 (Pull Chain)
TB2-2 (Pull Chain Common)	TB2-2 (Pull Chain Common)	TB2-2 (Pull Chain Common)	TB2-2 (Pull Chain Common)



- NOTE** NC and NO designations on MOB AUX contacts are defined with breaker in OFF (open) position.
- NOTE** If MOB contacts have pigtail leads, use the same wire gauge to connect to UPS and use the correct crimp connections for the wire gauge.
- NOTE** External CAN connections between UPS cabinets require shielded twisted pair wire.
- NOTE** Use twisted pair wiring between the UPS and MOB AUX contacts.
- NOTE** Always confirm contact operation prior to wiring.

Figure 5-6. Distributed Bypass Pull-Chain Wiring with MOB

**Table 5-4. Pull-Chain Wiring Terminations with MOBs**

From	To	Function
UPS 1 CAN Bridge Card J3-1 (Alarm)	MOB 1 Aux 1 NC	MOB Open Alarm
UPS 1 CAN Bridge Card J3-2 (Alarm Return)	MOB 1 Aux 1 Com	
UPS 1 TB2-1 (Pull Chain)	MOB 1 Aux 2 NO	Pull Chain
UPS 1 TB2-2 (Pull Chain Common)	UPS 2 TB2-2 (Pull Chain Common)	Pull Chain Common
UPS 2 CAN Bridge Card J3-1 (Alarm)	MOB 2 Aux 1 NC	MOB Open Alarm
UPS 2 CAN Bridge Card J3-2 (Alarm Return)	MOB 2 Aux 1 Com	
UPS 2 TB2-1 (Pull Chain)	MOB 2 Aux 2 NO	Pull Chain
UPS 2 TB2-2 (Pull Chain Common)	UPS 3 TB2-2 (Pull Chain Common)	Pull Chain Common
UPS 3 CAN Bridge Card J3-1 (Alarm)	MOB 3 Aux 1 NC	MOB Open Alarm
UPS 3 CAN Bridge Card J3-2 (Alarm Return)	MOB 3 Aux 1 Com	
UPS 3 TB2-1 (Pull Chain)	MOB 3 Aux 2 NO	Pull Chain
UPS 3 TB2-2 (Pull Chain Common)	UPS 4 TB2-2 (Pull Chain Common)	Pull Chain Common
UPS 4 CAN Bridge Card J3-1 (Alarm)	MOB 4 Aux 1 NC	MOB Open Alarm
UPS 4 CAN Bridge Card J3-2 (Alarm Return)	MOB 4 Aux 1 Com	
UPS 4 TB2-1 (Pull Chain)	MOB 4 Aux 2 NO	Pull Chain
MOB 1 Aux 2 Com	MOB 2 Aux 2 Com	Pull Chain MOB Common
MOB 2 Aux 2 Com	MOB 3 Aux 2 Com	
MOB 3 Aux 2 Com	MOB 4 Aux 2 Com	

### 5.3 Installing an Optional Remote Monitor Panel II

To install RMP II wiring:

1. Verify the UPS system is turned off and all power sources are removed. See Chapter 7, "UPS Operating Instructions," for shutdown instructions.
2. Perform the procedure listed in paragraph 5.1.




---

**NOTE** *If mounting to a hollow wall, secure the enclosure to a wood or metal stud within the wall. Do not use hollow wall anchors.*

---

3. Securely mount the RMP II at the desired location. See Figure 5-12 on page 5-15 for mounting hole locations.




---

**NOTE** *When installing signal wiring for CAN card J3 terminals, conduit must be installed between the device and the UPS cabinet.*

---

4. Remove the ISBM cabinet top right interface conduit landing plate to drill or punch conduit holes (see Figure 4-16 on page 4-19).
5. Reinstall the conduit landing plate.
6. Install conduit between the UPS and RMP II. See Figure 5-12 on page 5-15 for RMP II knockout hole location.
7. Install wiring between the UPS and RMP II. See Figure 5-2 and Table 5-1 for the Powerware Hot Sync CAN Bridge Card terminal location and wiring information, and Figure 5-7, Figure 5-8, and Table 5-5 for the RMP II terminal location and wiring information.




---

**NOTE** *120 Vac for the RMP II should be supplied from the critical bus by facility planners or the customer.*

---

8. Install 120 Vac power wiring from the critical bus to the RMP II. See Figure 5-7, Figure 5-8, and Table 5-5 for the terminal location and wiring information.
9. Close the front door and secure the latch.
10. Restart the UPS. See Chapter 7, "UPS Operating Instructions," for startup instructions.




Figure 5-7. Remote Monitor Panel II and Relay Interface Module II Terminal Locations




Figure 5-8. Remote Monitor Panel II, Relay Interface Module II, or Supervisory Contact Module II Wiring

Table 5-5. RMP II, RIM II, or SCM II Wiring Terminations

From UPS CAN Card	To RMP II, RIM II, or SCM II	Tightening Torque Nm (lb in)	Remarks
J3-6 (TX)	TB1-5 (RDX*)	0.9 (8)	Use twisted pair
J3-7 (TX)	TB1-4 (RDX)	0.9 (8)	
N/A	TB3 Line	0.9 (8)	
N/A	TB3 Neutral	0.9 (8)	
N/A	Ground Terminal	2.7 (24) Maximum	






---

**NOTE** Setup of the Powerware Hot Sync CAN Bridge Card must be performed by an authorized Eaton Customer Service Engineer. Contact an Eaton service representative to schedule a date.

---

11. To check the operation of the RMP II, ensure that the UPS is supplying the load via inverter or bypass. If the indicators on the RMP II show the appropriate status, then it is operating correctly.

If the communication link between the UPS and the RMP II is not present, the RMP II performs a self-test (all indicators flash and the horn beeps at one-second intervals). If the self-test occurs, check all harness connectors and the fuse for proper seating. If all connections are secure but the RMP II continues to self-test, replace the fuse with the spare included in the hardware kit. If a fuse replacement does not correct the problem, contact an Eaton service representative for verification that the RMP II is working correctly.

12. To test the indicator lamps, press and hold the horn silence pushbutton for three seconds. All lamps should illuminate, and the horn sounds continuously until you release the pushbutton.

## 5.4 Installing an Optional Relay Interface Module II

To install RIM II wiring:

1. Verify the UPS system is turned off and all power sources are removed. See Chapter 7, "UPS Operating Instructions," for shutdown instructions.
2. Perform the procedure listed in paragraph 5.1 on page 5-1.




---

**NOTE** If mounting to a hollow wall, secure the enclosure to a wood or metal stud within the wall. Do not use hollow wall anchors.

---

3. Securely mount the RIM II at the desired location. See Figure 5-13 on page 5-16 for mounting hole locations.




---

**NOTE** When installing signal wiring for CAN card J3 terminals, conduit must be installed between the device and the UPS cabinet.

---

4. Remove the ISBM cabinet top right interface conduit landing plate to drill or punch conduit holes (see Figure 4-16 on page 4-19).
5. Reinstall the conduit landing plate.
6. Install conduit between the UPS and RIM II. See Figure 5-13 on page 5-16 for RIM II knockout hole location.
7. Install wiring between the UPS and RIM II. See Figure 5-2 and Table 5-1 for the Powerware Hot Sync CAN Bridge Card terminal location and wiring information, and Figure 5-7, Figure 5-8, and Table 5-5 for the RIM II terminal location and wiring information.




---

**NOTE** 120 Vac for the RIM II should be supplied from the critical bus by facility planners or the customer.

---

8. Install 120 Vac power wiring from the critical bus to the RIM II. See Figure 5-7, Figure 5-8, and Table 5-5 for the terminal location and wiring information.
9. Close the front door and secure the latch.

10. Restart the UPS. See Chapter 7, “UPS Operating Instructions,” for startup instructions.




**NOTE** Setup of the Powerware Hot Sync CAN Bridge Card must be performed by an authorized Eaton Customer Service Engineer. Contact an Eaton service representative to schedule a date.

11. Contact an Eaton service representative for verification and testing of the RIM II and its connections prior to making connections with J1 through J4 (see Table 5-6 and Figure 5-9).

You can order interface cables separately for connecting to the 15-Pin D-Sub Connectors.

**Table 5-6. J1 through J4 Interface Connectors**

Status	J1 through J4	Description
<b>UPS AVAILABLE</b>	Pins 1 and 12	Contacts are closed when the UPS is operating in Normal mode or ready to supply the load.
<b>UPS OFFLINE</b>	Pins 3 and 13	Contacts are open when the UPS is offline. Contacts are closed when the UPS is operating in Normal mode.
<b>BATTERY WEAK</b>	Pins 5 and 14	Contacts are closed when approximately two minutes of battery time remains before the critical load is lost.
<b>UTILITY FAILURE</b>	Pins 6 and 15	Contacts are closed when Utility Failure is detected.



**Figure 5-9. J1, J2, J3, and J4 15-Pin D-Sub Connectors**

## 5.5 Installing an Optional Supervisory Contact Module II

To install SCM II wiring:

1. Verify the UPS system is turned off and all power sources are removed. See Chapter 7, "UPS Operating Instructions," for shutdown instructions.
2. Perform the procedure listed in paragraph 5.1 on page 5-1.



**NOTE** If mounting to a hollow wall, secure the enclosure to a wood or metal stud within the wall. Do not use hollow wall anchors.

3. Securely mount the SCM II at the desired location. See Figure 5-14 on page 5-17 for mounting hole locations.



**NOTE** When installing signal wiring for CAN card J3 terminals, conduit must be installed between the device and the UPS cabinet.

4. Remove the ISBM cabinet top right interface conduit landing plate to drill or punch conduit holes (see Figure 4-16 on page 4-19).
5. Reinstall the conduit landing plate.
6. Install conduit between the UPS and SCM II. See Figure 5-14 on page 5-17 for SCM II knockout hole location.
7. Install wiring between the UPS and SCM II. See Figure 5-2 and Table 5-1 for the Powerware Hot Sync CAN Bridge Card terminal location and wiring information, and Figure 5-10, Figure 5-8, and Table 5-5 for the SCM II terminal location and wiring information.



**NOTE** 120 Vac for the SCM II should be supplied from the critical bus by facility planners or the customer.

8. Install 120 Vac power wiring from the critical bus to the SCM II. See Figure 5-10, Figure 5-8, and Table 5-5 for the terminal location and wiring information.





Figure 5-10. Supervisory Contact Module II Terminal Location



**NOTE** Setup of the Powerware Hot Sync CAN Bridge Card must be performed by an authorized Eaton Customer Service Engineer. Contact an Eaton service representative to schedule a date.

9. Install wiring between the SCM II terminal block TB2 and the monitoring equipment. See Figure 5-10 for terminal block location and Figure 5-11 for terminal assignments.
10. Close the front door and secure the latch.
11. Restart the UPS. See Chapter 7, "UPS Operating Instructions," for startup instructions.



**Figure 5-11. Supervisory Contact Module II TB2**



**NOTE** Supervisory contacts are rated at 2.0A at 28 Vdc or 120 Vac and 0.15A at 115 Vdc.

**NOTE** Supervisory contacts require an external power supply. Internal 24 Vdc is not capable of supplying contact current.

### 5.6 Accessory Mounting Dimensions

Figure 5-12 through Figure 5-14 show the dimensions of the RMP II, the RIM II, and the SCM II.




Figure 5-12. Remote Monitor Panel II Dimensions





Figure 5-13. Relay Interface Module II Dimensions




Figure 5-14. Supervisory Contact Module II Dimensions

This page intentionally left blank.



# **Section II**

## **Operation**



## Chapter 6


# Understanding UPS Operation

### 6.1 UPS System Overview

The Eaton 9395 UPS is a continuous-duty, solid-state, transformerless (at 480 Vac), three-phase, true online system that provides conditioned and uninterruptible AC power to the UPS system's output and critical load.

The basic system consists of a rectifier, battery converter, inverter, monitoring/operation control panel, integrated communication server, and digital signal processor (DSP) logic. Figure 6-1 shows the main elements of the UPS system.

If utility power is interrupted or falls outside the parameters specified in Chapter 10, "Product Specifications," the UPS uses a *backup battery supply* to maintain power to the critical load for a specified period of time or until the utility power returns. For extended power outages, the UPS allows you to either transfer to an alternative power system (such as a generator) or shut down your critical load in an orderly manner.



**NOTE** On a UPS configured as an Input Output Module (IOM), the bypass input, static switch, bypass breaker (CB4), and backfeed protection contactor (K5) are not present.

**NOTE** On a UPS configured with a Continuous Static Switch (CSS), bypass breaker (CB4) is not present.

**Figure 6-1. Main Elements of the UPS System**

The emergency bypass consists of either a momentary static switch and wraparound bypass breaker or a continuous static switch, and a backfeed protection contactor K5. The bypass breaker (if installed) is located in parallel with the static switch. The backfeed protection contactor is located in series with the static switch. The static switch is armed and ready during normal operation.

On a UPS configured as an Input Output Module (IOM), bypass circuitry is not installed. This configuration is primarily used in multiple UPS parallel systems that do not need a bypass for each UPS and use a separate System Bypass Module (SBM) to provide system bypass capabilities.

## 6.2 Single UPS

A single UPS operates independently to support an applied load from the inverter, providing conditioned and uninterruptible AC power to the critical load from the output of the module. During an outage, the inverter continues to operate, supporting power to the load from the battery supply. If the unit requires service, applied loads are transferred to the internal bypass either automatically or manually. With the exception of a battery cabinet, no other cabinets or equipment are required for the single UPS to successfully support its applied loads.

### 6.2.1 Modes

The Eaton 9395 UPS supports a critical load in five different modes of operation:




---

**NOTE** *Advanced Power Management and Energy Saver modes are mutually exclusive.*

---

- In Normal mode, the critical load is supplied by the inverter, which derives its power from rectified utility AC power. In this mode, the battery charger also provides charging current for the battery, if needed.
- In Energy Saver mode, commercial AC power is supplied directly to the critical load through the continuous static switch and transfers automatically to Online mode if an abnormal condition is detected. The Energy Saver mode requires a UPS with a continuous static switch.
- In Advanced Power Management mode, the UPS operates as a traditional double-conversion UPS, but selectively shifts the load to fewer UPMs to increase the efficiency of the UPS.
- In Bypass mode, the critical load is directly supported by utility power.
- In Battery mode, the battery provides DC power, which maintains inverter operation. The battery supports the critical load.

The UPS can automatically use all five modes, as required. The following paragraphs describe the differences in the five UPS operating modes, using block diagrams to show the power flow during each mode of operation.


### 6.2.2 Normal Mode

Figure 6-2 shows the path of electrical power through the UPS system when the UPS is operating in Normal mode.

During normal UPS operation, power for the system is derived from a utility input source through the rectifier input contactor K1. The front panel displays “Normal,” indicating the incoming power is within voltage and frequency acceptance windows. Three-phase AC input power is converted to DC using IGBT devices to produce a regulated DC voltage to the inverter. When contactor K2 is closed the battery is charged directly from the regulated rectifier output through a buck or boost DC converter, depending on the system voltage and the size of the battery string attached to the unit.

The battery converter derives its input from the regulated DC output of the rectifier and provides either a boosted or bucked regulated DC voltage charge current to the battery. The battery is always connected to the UPS and ready to support the inverter should the utility input become unavailable.

The inverter produces a three-phase AC output to a customer's load without the use of a transformer. The inverter derives regulated DC from the rectifier and uses IGBT devices and pulse-width modulation (PWM) to produce a regulated and filtered AC output. The AC output of the inverter is delivered to the system output through the output contactor K3.



**NOTE** On a UPS configured as an IOM, the bypass input, static switch, bypass breaker (CB4), and K5 are not present.

**NOTE** On a UPS configured with a Continuous Static Switch (CSS), bypass breaker (CB4) is not present.

**Figure 6-2. Path of Current Through the UPS in Normal Mode**

If the utility AC power is interrupted or is out of specification, the UPS automatically switches to Battery mode to support the critical load without interruption. When utility power returns, the UPS returns to Normal mode.




---

**NOTE** *Bypass mode is not available on a UPS configured as an IOM.*

---

If the UPS becomes overloaded or unavailable, the UPS switches to Bypass mode. The UPS automatically returns to Normal mode when the overload condition is cleared and system operation is restored within specified limits.

If the UPS suffers an internal failure, it switches automatically to Bypass mode and remains in that mode until the failure is corrected and the UPS is back in service.

### 6.2.3 Energy Saver Mode




---

**NOTE** *Advanced Power Management and Energy Saver modes are mutually exclusive. If Energy Saver is enabled, Advanced Power Management is disabled.*

---

When the UPS is operating in Energy Saver mode, commercial AC power is supplied directly to the critical load through the continuous static switch. Power line filtering and spike protection for the load are provided by the input and output filter networks, and the UPS actively monitors the critical bus for power disturbances. When in this mode, the input and output contactors are closed and the link is maintained through the diode bridge.

If commercial power voltage or frequency disturbances are detected, the system forward transfers to Battery mode for minor disturbances and then to double-conversion mode for more severe disturbances. During a complete power outage, the transfer takes place within 2 ms to ensure loads being fed by the system output are not interrupted. All forward transfers transfer to Battery mode before returning to double-conversion mode.

In High Alert mode the unit transfers from Energy Saver mode to double-conversion mode or if in double-conversion mode remains in double-conversion mode for a default time period of one hour (customer configurable). At the completion of the time period, the unit defaults back to Energy Saver mode. If the High Alert command is received during the time period, the timer will be restarted.

Energy Saver mode is a normal operating mode, and not an alarm condition. While the UPS is in this mode, the **NORMAL** light on the front display will illuminate.

### 6.2.4 Advanced Power Management




---

**NOTE** *Advanced Power Management and Energy Saver modes are mutually exclusive. If Advanced Power Management is enabled, Energy Saver is disabled.*

---

In Advanced Power Management (APM) mode, the UPS operates as a traditional double-conversion UPS. However, the UPS will selectively shift the load to fewer UPMs based on the required load in order to force the remaining UPMs to carry a higher load. The efficiency rating for each UPM is highest when loads are greater than 50% of the system rating. Therefore, with multiple UPMs, a UPS can achieve higher efficiencies for lighter loads.

When a UPM is placed into APM mode, the UPM will stop gating the inverter and rectifier and keep the output contactor closed in order to maintain voltage match and phase lock to the critical bus. In this mode the UPS actively monitors the critical bus, keeping the UPM input contactors closed in order to keep the DC link primed (through the rectifier diodes) and also to allow the UPM to immediately return to active mode in the event of a disturbance or load step on the critical bus.

APM limits the maximum power available from a UPM when in APM mode. The default setting is 80% of the UPM full power rating. If the limit is exceeded, additional UPMs take on the increased load. The APM redundancy setting sets the number of redundant UPMs that the customer requires. Both the APM UPM load limit and UPM redundancy are customer configurable.

In High Alert mode, the UPS defaults to double-conversion mode and all UPMs go active for one hour (customer configurable). At the completion of the hour, the UPS defaults back to APM mode. If the High Alert command is received during the one hour, the one hour timer will be restarted.

### 6.2.5 Bypass Mode



**NOTE** Bypass mode is not available on a UPS configured as an IOM.

The UPS automatically switches to Bypass mode if it detects an overload, load fault, or internal failure. The UPS can also be transferred from Normal mode to Bypass mode manually. The bypass source supplies the commercial AC power to the load directly. Figure 6-3 shows the path of electrical power through the UPS system when operating in Bypass mode.

In Bypass mode, the output of the system is provided with three-phase AC power directly from the system input. While in this mode, the output of the system is not protected from voltage or frequency fluctuations or power outages from the source. Some power line filtering and spike protection is provided to the load but no active power conditioning or battery support is available to the output of the system in the Bypass mode of operation.


The internal bypass is comprised of either of a solid-state, silicon-controlled rectifier (SCR) momentary static switch and motorized wraparound bypass breaker CB4 or a SCR continuous static switch, and a backfeed protection contactor K5. The static switch is used instantaneously anytime the inverter is unable to support the applied load. CB4 is also wired in parallel with the momentary static switch. Both the momentary and continuous static switches are wired in series with the backfeed protection contactor, and together they are wired in parallel with the rectifier and inverter.



#### CAUTION

The critical load is not protected from voltage or frequency fluctuations or power outages while the UPS is in Bypass mode.

The static switch, being an electronically-controlled device, can be turned on immediately to pick up the load from the inverter while inverter output contactor K3 opens to isolate the inverter. Bypass breaker CB4 also closes and the static switch stops conducting with a momentary static switch. The backfeed protection contactor is normally closed, ready to support the static switch unless the bypass input source becomes unavailable.



**NOTE** On a UPS configured as an IOM, the bypass input, static switch, bypass breaker (CB4), and K5 are not present.

**NOTE** On a UPS configured with a Continuous Static Switch (CSS), bypass breaker (CB4) is not present.

**Figure 6-3. Path of Current Through the UPS in Bypass Mode**

If the UPS transfers to Bypass mode from Normal mode due to any reason other than operator intervention, the UPS automatically attempts to transfer back to Normal mode (up to three times within a ten minute period). The fourth transfer locks the critical load to the bypass source and requires operator intervention to transfer.

### 6.2.6 Battery Mode

The UPS automatically transfers to Battery mode if a utility power outage occurs, or if the utility power does not conform to specified parameters. In Battery mode, the battery provides emergency DC power that the inverter converts to AC power.


Figure 6-4 shows the path of electrical power through the UPS system when operating in Battery mode.

During a utility power failure, the rectifier no longer has an AC utility source from which to supply the DC output current required to support the inverter. The input contactor K1 opens and the battery instantaneously supplies energy to the battery converter. The converter either bucks or boosts the voltage so that the inverter can support the customer's load without interruption. If bypass is common with the rectifier input, the backfeed protection contactor K5 also opens. The opening of contactors K1 and K5 prevent system voltages from bleeding backwards through the static switch and rectifier snubber components and re-entering the input source.



If the input power fails to return or is not within the acceptance windows required for normal operation, the battery continues discharging until a DC voltage level is reached where the inverter output can no longer support the connected loads. When this event occurs, the UPS issues another set of audible and visual alarms indicating SHUTDOWN IMMINENT. Unless the rectifier has a valid AC input soon, the output can be supported for only two minutes before the output of the system shuts down. If the bypass source is available, the UPS transfers to bypass instead of shutting down.

If at any time during the battery discharge the input power becomes available again, contactors K1 and K5 close and the rectifier begins to supply DC current to the converter and inverter. At this point, the unit returns to Normal mode. Depending on the total load and the duration of the battery discharge, battery current limit alarms may be seen for a short time due to the current required to recharge the battery.



**NOTE** On a UPS configured as an IOM, the bypass input, static switch, bypass breaker (CB4), and K5 are not present.


**NOTE** On a UPS configured with a Continuous Static Switch (CSS), bypass breaker (CB4) is not present.

**Figure 6-4. Path of Current Through the UPS in Battery Mode**

### 6.3 Single UPS Unit System Online Configurations

The system online drawings in this section show the simplified internal structure of the UPS, battery supply, and basic maintenance bypass.


Online Drawing	UPS Model	Voltage		System Type
		Input	Output	
Figure 6-5 on page 6-9	9395-1100/1000	400	400	Single Reverse Transfer UPS – Four UPM, Common Rectifier Feed, Common Battery, Dual-Feed Configuration, Momentary Static Switch
	9395-1100/1100	480	480	
Figure 6-6 on page 6-10	9395-1100/1000	400	400	Single Reverse Transfer UPS – Four UPM, Common Rectifier Feed, Separate Battery, Dual-Feed Configuration, Momentary Static Switch
	9395-1100/1100	480	480	
Figure 6-7 on page 6-11	9395-1100/650	400	400	Single Reverse Transfer UPS – Three UPM, Common Rectifier Feed, Common Battery, Dual-Feed Configuration, Momentary Static Switch
	9395-1100/750			
	9395-1100/825			
Figure 6-8 on page 6-12	9395-1100/650	400	400	Single Reverse Transfer UPS – Three UPM, Common Rectifier Feed, Separate Battery, Dual-Feed Configuration, Momentary Static Switch
	9395-1100/750			
	9395-1100/825			
Figure 6-9 on page 6-13	9395-1100/1000	400	400	Single Reverse Transfer UPS – Four UPM, Common Rectifier Feed, Common Battery, Dual-Feed Configuration, Continuous Static Switch
	9395-1100/1100	480	480	
Figure 6-10 on page 6-14	9395-1100/1000	400	400	Single Reverse Transfer UPS – Four UPM, Common Rectifier Feed, Separate Battery, Dual-Feed Configuration, Continuous Static Switch
	9395-1100/1100	480	480	
Figure 6-11 on page 6-15	9395-1100/650	400	400	Single Reverse Transfer UPS – Three UPM, Common Rectifier Feed, Common Battery, Dual-Feed Configuration, Continuous Static Switch
	9395-1100/750			
	9395-1100/825			
Figure 6-12 on page 6-16	9395-1100/650	400	400	Single Reverse Transfer UPS – Three UPM, Common Rectifier Feed, Separate Battery, Dual-Feed Configuration, Continuous Static Switch
	9395-1100/750			
	9395-1100/825			
Figure 6-13 on page 6-17	9395-1100/1000	400	400	Single Reverse Transfer UPS – Four UPM, Common Rectifier Feed, Common Battery, IOM Configuration
	9395-1100/1100	480	480	
Figure 6-14 on page 6-18	9395-1100/1000	400	400	Single Reverse Transfer UPS – Four UPM, Common Rectifier Feed, Separate Battery, IOM Configuration
	9395-1100/1100	480	480	
Figure 6-15 on page 6-19	9395-1100/650	400	400	Simplified Dual-Feed UPS with Maintenance Bypass Panel
	9395-1100/750			
	9395-1100/825			
	9395-1100/1000			
	9395-1100/1100			



**NOTE** Callout letters **A**, **B**, **C**, and **D** map to Table 3-4 on page 3-11.

**NOTE** If the load requires a neutral, a bypass source neutral must be provided. If the load does not require a neutral and there is no neutral conductor connected at the bypass input, a neutral to ground bonding jumper must be installed. DO NOT install both a source neutral and a bonding jumper.


**Figure 6-5. UPS System – Four UPM, Common Rectifier Feed, Common Battery, Dual-Feed Configuration, Momentary Static Switch**



**NOTE** Callout letters **A**, **B**, **C**, and **D** map to Table 3-5 on page 3-12.

**NOTE** If the load requires a neutral, a bypass source neutral must be provided. If the load does not require a neutral and there is no neutral conductor connected at the bypass input, a neutral to ground bonding jumper must be installed. DO NOT install both a source neutral and a bonding jumper.


**Figure 6-6. UPS System – Four UPM, Common Rectifier Feed, Separate Battery, Dual-Feed Configuration, Momentary Static Switch**




**NOTE** Callout letters **A**, **B**, **C**, and **D** map to Table 3-6 on page 3-13.

**NOTE** If the load requires a neutral, a bypass source neutral must be provided. If the load does not require a neutral and there is no neutral conductor connected at the bypass input, a neutral to ground bonding jumper must be installed. DO NOT install both a source neutral and a bonding jumper.

**Figure 6-7. UPS System – Three UPM, Common Rectifier Feed, Common Battery, Dual-Feed Configuration, Momentary Static Switch**






**NOTE** Callout letters **A**, **B**, **C**, and **D** map to Table 3-7 on page 3-14.

**NOTE** If the load requires a neutral, a bypass source neutral must be provided. If the load does not require a neutral and there is no neutral conductor connected at the bypass input, a neutral to ground bonding jumper must be installed. DO NOT install both a source neutral and a bonding jumper.




**Figure 6-8. UPS System – Three UPM, Common Rectifier Feed, Separate Battery, Dual-Feed Configuration, Momentary Static Switch**



**NOTE** Callout letters **A, B, C,** and **D** map to Table 3-4 on page 3-11.

**NOTE** If the load requires a neutral, a bypass source neutral must be provided. If the load does not require a neutral and there is no neutral conductor connected at the bypass input, a neutral to ground bonding jumper must be installed. DO NOT install both a source neutral and a bonding jumper.

**Figure 6-9. UPS System – Four UPM, Common Rectifier Feed, Common Battery, Dual-Feed Configuration, Continuous Static Switch**




**NOTE** Callout letters **A**, **B**, **C**, and **D** map to Table 3-5 on page 3-12.

**NOTE** If the load requires a neutral, a bypass source neutral must be provided. If the load does not require a neutral and there is no neutral conductor connected at the bypass input, a neutral to ground bonding jumper must be installed. DO NOT install both a source neutral and a bonding jumper.

**Figure 6-10. UPS System – Four UPM, Common Rectifier Feed, Separate Battery, Dual-Feed Configuration, Continuous Static Switch**






**NOTE** Callout letters **A**, **B**, **C**, and **D** map to Table 3-6 on page 3-13.

**NOTE** If the load requires a neutral, a bypass source neutral must be provided. If the load does not require a neutral and there is no neutral conductor connected at the bypass input, a neutral to ground bonding jumper must be installed. DO NOT install both a source neutral and a bonding jumper.


**Figure 6-11. UPS System – Three UPM, Common Rectifier Feed, Common Battery, Dual-Feed Configuration, Continuous Static Switch**



**NOTE** Callout letters **A**, **B**, **C**, and **D** map to Table 3-7 on page 3-14.

**NOTE** If the load requires a neutral, a bypass source neutral must be provided. If the load does not require a neutral and there is no neutral conductor connected at the bypass input, a neutral to ground bonding jumper must be installed. DO NOT install both a source neutral and a bonding jumper.


**Figure 6-12. UPS System – Three UPM, Common Rectifier Feed, Separate Battery, Dual-Feed Configuration, Continuous Static Switch**



**NOTE** Callout letters **A**, **C**, and **D** map to Table 3-4 on page 3-11.

**NOTE** If the load requires a neutral, a bypass source neutral must be provided. If the load does not require a neutral and there is no neutral conductor connected at the bypass input, a neutral to ground bonding jumper must be installed. DO NOT install both a source neutral and a bonding jumper.


**Figure 6-13. UPS System – Four UPM Common Rectifier Feed, Common Battery, IOM Configuration**



**NOTE** Callout letters **A**, **C**, and **D** map to Table 3-5 on page 3-12.

**NOTE** If the load requires a neutral, a bypass source neutral must be provided. If the load does not require a neutral and there is no neutral conductor connected at the bypass input, a neutral to ground bonding jumper must be installed. DO NOT install both a source neutral and a bonding jumper.

**Figure 6-14. UPS System – Four UPM Common Rectifier Feed, Separate Battery, IOM Configuration**



- RIB: Rectifier Input Breaker
- BIB: Bypass Input Breaker
- MIS: Maintenance Isolation Breaker
- MBP: Maintenance Bypass Breaker

**NOTE** If installing a maintenance bypass, a minimum of two separate feeds with upstream feeder breakers, or a single feed with two upstream feeder breakers, must be provided: one for the UPS or rectifier input breaker (RIB) (if installed) and one for the maintenance bypass input. DO NOT use a single feed or a single feeder breaker to supply both the UPS or RIB and the maintenance bypass. If a bypass input breaker (BIB) is installed in the maintenance bypass and a single-feed UPS is being installed, a single feed to the maintenance bypass is acceptable for supplying both the UPS and the bypass.

**Figure 6-15. Simplified Dual-Feed UPS with Maintenance Bypass Panel**

## 6.4 Multiple UPS Distributed Bypass System

Distributed bypass parallel operation extends the normal operation of Eaton 9395 UPSs by offering increased capacity and/or redundant capability. The parallel system continues to maintain power to the critical loads during commercial electrical power brownout, blackout, overvoltage, undervoltage, and out-of-tolerance frequency conditions.

The output of the system is normally supplied by Uninterruptible Power Modules (UPMs) contained in each UPS. Multiple UPMs are connected with their outputs in parallel (tied together) to provide a load level greater than the rating of one UPM, for redundancy, or both. The paralleled UPMs supply the output load with protected power as long as the load does not exceed the combined rating of the paralleled UPMs.

The power system is redundant as long as one of the UPMs can be disconnected from the output bus and the remaining UPMs can continue to supply power to the load without exceeding their ratings.

When the load is being supplied by the UPMs, the system output bus is continuously monitored for an overvoltage or undervoltage condition. If an out of limits condition is detected, the paralleled UPMs transfer the load to bypass using the UPS static switches.

Communication is required between the UPSs for system metering and mode control. System level communication and control are accomplished using a Controller Area Network (CAN). A single building alarm in each UPS, connected to the other UPSs in parallel and tied to the bypass contactor auxiliary contacts in each UPS, are used for a secondary communication path. This arrangement ensures bypass control even if the CAN bus is lost.

The system is paralleled for redundancy (1+1) in a system where two UPMs are paralleled together and the load is less than the supporting capability of one of the UPMs. The system is paralleled for capacity (2+0) if both UPMs in a system are required to support the load.

A parallel capacity system can also be redundant (2+1), as long as there is always one or more UPMs online than required to support the load.

### 6.4.1 Multiple UPS Parallel System Modes

Similar to the single UPS system, the Eaton 9395 UPS parallel system supports a critical load in five different modes of operation. The standard operation modes are:

- In Normal mode, the paralleled UPMs supply the critical load with clean, filtered power. Each UPM battery charger also provides charging current for the battery if needed.
- In Energy Saver mode, commercial AC power is supplied directly to the critical load through the continuous static switch and transfers automatically to Online mode if an abnormal condition is detected. The Energy Saver mode requires a UPS with a continuous static switch. Energy Saver mode in a parallel system operates the same as it does in a single UPS system (see paragraph 6.2.3).
- In Advanced Power Management mode, the UPS operates as a traditional double-conversion UPS, but selectively shifts the load to fewer UPMs to increase the efficiency of the UPS. In a parallel system each UPS will require at least one UPM to be in double-conversion mode at all times; otherwise, Advanced Power Management operates the same as it does in a single UPS system (see paragraph 6.2.4).

- In Bypass mode, the critical load is directly supported by utility power through the bypass circuit in each UPS.
- In Battery mode, the battery provides DC power, which maintains UPM operation. The UPM batteries support the critical load.

The UPSs continually monitor themselves and the incoming utility power and automatically switch between these modes as required, without operator intervention, except when manually switching to Bypass mode. The sophisticated detection and switching logic inside the UPSs ensures that operating mode changes are automatic and transparent to the critical load, while internal monitoring systems indicate the current mode of operation. The UPSs switch operating modes in response to these system events:

- A *command* is an intervention that is externally initiated by an operator or by some site action. A command causes the UPSs to switch operating modes; it usually does not require any further action.
- A *notice* is a minor system event that may or may not require attention.
- An *alarm* is a system event that requires immediate intervention.

The following paragraphs describe the differences in the parallel system operating modes, using block diagrams to show the power flow during each mode of operation.


#### 6.4.2 Normal Mode – Distributed Bypass

In Normal mode, utility AC power is supplied to the UPSs. Each UPS then conditions the incoming AC power and provides clean, regulated AC power to tie cabinet or distribution panel for parallel systems up to four modules. The applied load is shared equally among the available UPMs in the system.

Figure 6-16 shows the path of electrical power through the parallel system when operating in Normal mode.

If the utility AC power is interrupted or is out of specification, the UPSs automatically switch to Battery mode to support the critical load without interruption. When utility power returns, the UPSs return to Normal mode.

If the UPSs become overloaded or unavailable, the distributed bypass system switches to Bypass mode. The distributed bypass system automatically returns to Normal mode when the overload condition is cleared and system operation is restored within specified limits.



**Figure 6-16. Path of Current through the UPSs in Normal Mode – Distributed Bypass**

### 6.4.3 Bypass Mode – Distributed Bypass

In Bypass mode, the output of the system is provided with three-phase AC power directly from the bypass input. While in this mode, the output of the system is not protected from fluctuations, spikes, or power outages from the source. No battery support is available to the output of the system in the Bypass mode of operation.


The distributed bypass system automatically switches to Bypass mode if it detects a UPS system overload or load fault.

If one UPS becomes unavailable, the distributed bypass system dynamically updates the redundancy calculation to determine if the remaining UPSs can support the load. If the load can be supported, the system does not switch to bypass.

Figure 6-17 shows the path of electrical power through the parallel system when operating in Bypass mode.

In a distributed bypass system, each UPS operates similar to a single UPS, but in parallel with each other. The bypass source for the load is derived from the bypass input of one, two, three, or four UPSs, depending on the system configuration, through the internal static switches. If a module is taken offline, the other modules remain online to support the load. If more modules than can support the load must be taken offline, the load must be transferred to maintenance bypass or shut down.





**Figure 6-17. Path of Current through the UPSs in Bypass Mode – Distributed Bypass**

The distributed bypass system can be transferred from Normal mode to Bypass mode manually. However, the distributed bypass system automatically switches to Bypass mode whenever the UPSs can no longer supply the critical load. If the distributed bypass system transfers to Bypass mode from Normal mode due to an output voltage deviation, the distributed bypass system automatically attempts to return to Normal mode (up to three times within a 10-minute period). After three transfer attempts or an overload, the system locks the critical load to the bypass source and requires operator intervention to transfer.

Bypass mode is a normal operating mode, not an alarm condition. However, if the distributed bypass system is unable to return to Normal mode following an automatic transfer to Bypass mode, an alarm condition is recorded.

Bypass may also be used when the UPSs or UPMs in the system must be shut down to perform routine maintenance or repairs.

In the Parallel Redundant (N+1) arrangement, the bypass circuitry in each UPS operates to support the applied loads on bypass. If the UPSs are in NORMAL and one UPS trips offline, the remaining UPSs do not go to bypass as long as they have the capacity to support the load.

In the Parallel Capacity (N+0) arrangement, if one UPS trips offline and goes to bypass, the remaining UPSs also go to bypass.


### 6.4.4 Battery Mode – Distributed Bypass

The UPSs transfer to Battery mode automatically if a utility power outage occurs, or if the utility power does not conform to specified parameters. In Battery mode, the battery provides emergency DC power that the inverter converts to AC power.

Figure 6-18 shows the path of electrical power through the distributed bypass system when operating in Battery mode.

While in Battery mode, the UPSs sound an audible horn, illuminate a visual indicator lamp on the front panel (System Normal, On Battery), and create an entry into the alarm event history. As the battery discharges, the boost converter and inverter constantly make minute adjustments maintaining a steady output. The UPSs remain in this operating mode until the input power to the rectifier is again within the specified voltage or frequency acceptance windows.

If the input power fails to return or is not within the acceptance windows required for normal operation, the battery continues discharging until a DC voltage level is reached where the inverter output can no longer support the shared loads. When this event occurs, each UPS issues another set of audible and visual alarms that indicate a two-minute SHUTDOWN IMMINENT warning. Unless the system has a valid AC input soon, redundant UPMs begin shutting down until there are no longer enough UPMs online to support the connected load. When this event occurs, the system shuts down. If the bypass source is available, the system transfers to bypass instead of shutting down.



**Figure 6-18. Path of Current through the UPSs in Battery Mode – Distributed Bypass**

If at any time during the battery discharge the input power becomes available again, the rectifier begins to supply DC current to the inverter. At this point, the UPS returns to Normal mode. If at any time during the battery discharge the AC input power becomes available again, each rectifier turns on, assumes the inverter load from the batteries, and begins recharging the batteries. Depending on the total load and the duration of the battery discharge, battery and rectifier input current limit alarms may be seen for a short time due to the current required to recharge the batteries.

## 6.5 Multiple UPS Distributed Bypass System Online Configurations

The distributed bypass system online drawings in this section show the simplified internal structure of the UPS, battery supply, and basic maintenance bypass in a multiple UPS configuration. These onlines do not show each UPM in the UPSs, but represent each UPS in the distributed bypass system. The internal structure of each UPS is shown in Figure 6-5 through Figure 6-12.

Online Drawing	UPS Model	Voltage		System Type
		Input	Output	
Figure 6-19 on page 6-26	9395-1100/1000	400	400	Multiple UPS – Distributed Bypass, Momentary Static Switch, 1+1 and 2+0 Configurations
	9395-1100/1100			
	9395-1100/650			
	9395-1100/750			
	9395-1100/825			
Figure 6-20 on page 6-27	9395-1100/1000	400	400	Multiple UPS – Distributed Bypass, Momentary Static Switch, 2+1 and 3+0 Configurations
	9395-1100/1100			
	9395-1100/650			
	9395-1100/750			
	9395-1100/825			
Figure 6-21 on page 6-28	9395-1100/1000	400	400	Multiple UPS – Distributed Bypass, Momentary Static Switch, 3+1 and 4+0 Configurations
	9395-1100/1100			
	9395-1100/650			
	9395-1100/750			
	9395-1100/825			
Figure 6-22 on page 6-29	9395-1100/1000	400	400	Multiple UPS – Distributed Bypass, Continuous Static Switch, 1+1 and 2+0 Configurations
	9395-1100/1100			
	9395-1100/650			
	9395-1100/750			
	9395-1100/825			
Figure 6-23 on page 6-30	9395-1100/1000	400	400	Multiple UPS – Distributed Bypass, Continuous Static Switch, 2+1 and 3+0 Configurations
	9395-1100/1100			
	9395-1100/650			
	9395-1100/750			
	9395-1100/825			
Figure 6-24 on page 6-31	9395-1100/1000	400	400	Multiple UPS – Distributed Bypass, Continuous Static Switch, 3+1 and 4+0 Configurations
	9395-1100/1100			
	9395-1100/650			
	9395-1100/750			
	9395-1100/825			





Figure 6-19. Typical Distributed Bypass System – Momentary Static Switch, 1+1 and 2+0 Configurations



**Figure 6-20. Typical Distributed Bypass System – Momentary Static Switch, 2+1 and 3+0 Configurations**





Figure 6-21. Typical Distributed Bypass System – Momentary Static Switch, 3+1 and 4+0 Configurations




- A** – AC Input to UPS Rectifier
- B** – AC Input to Bypass
- C** – DC Input from Battery
- D** – UPS AC Output to Tie Cabinet
- E** – Output to Critical Load
- \* – Overcurrent Protection supplied by customer

**NOTE** This oneline does not show each UPM in the UPSs, but represents each UPS in the distributed bypass system. The internal structure of each UPS is shown in Figure 6-5 through Figure 6-12.


**NOTE** If the load requires a neutral, a bypass source neutral must be provided. If the load does not require a neutral and there is no neutral conductor connected at the bypass input, a neutral to ground bonding jumper must be installed. DO NOT install both a source neutral and a bonding jumper.

**Figure 6-22. Typical Distributed Bypass System – Continuous Static Switch, 1+1 and 2+0 Configurations**



**Figure 6-23. Typical Distributed Bypass System – Continuous Static Switch, 2+1 and 3+0 Configurations**





This page intentionally left blank.

## Chapter 7

# UPS Operating Instructions

This section describes how to operate the UPS.



**NOTE** Before starting the UPS, ensure all installation tasks are complete and a preliminary startup has been performed by authorized service personnel. The preliminary startup verifies all electrical interconnections to ensure the installation was successful and the system operates properly.

**NOTE** Read this section of the manual and have thorough knowledge of UPS operation before attempting to operate any of the controls.

**NOTE** The UPS displays two minutes of battery runtime at the initial startup. After a 24-hour charging period, the UPS automatically runs a battery test and the correct battery runtime displays.

### 7.1 UPS Controls and Indicators

The controls and indicators identified and described in this section are used to control and monitor UPS operation. Figure 7-1 shows the controls and indicators.




Figure 7-1. UPS Controls and Indicators

### 7.1.1 Control Panel


The control panel is used to set up and control the UPS, and to monitor UPS operation. For a description of the UPS control panel functions, see paragraph 7.2.

### 7.1.2 Circuit Breakers

Optional circuit breaker (CB1) is used to control the AC input to the UPS rectifier. CB1 is not available with the separate UPM rectifier feed configuration.

## 7.2 Using the Control Panel

The following paragraphs describe the UPS control panel, including controls and indicators, and how to monitor UPS operation. The control panel (see Figure 7-2) is located on the front door of the UPS.



**Figure 7-2. UPS Control Panel**

The control panel consists of:

- A liquid crystal display (LCD) (1)
- A horizontal row of pushbutton switches (2)
- A vertical column of status indicators (3). See paragraph 7.2.1.

The following paragraphs describe using the UPS control panel to monitor the UPS. See paragraph 7.3 for use of the operational controls.





When the unit powers up, the screen displays the Eaton logo as shown in Figure 7-2. To advance to the Main Menu and Mimic screen, press any control panel pushbutton once.

## 7.2.1 Status Indicators

The four symbols on the right side of the control panel are *status indicators*. These colored light emitting diode (LED) lamps work with the alarm horn to let you know the operating status of the UPS.

Table 7-1 describes the status indicators.

**Table 7-1. Status Indicators**

Indicator	Status	Description
 Green	On	The UPS is operating normally. The power module is supplying power to the critical load.
	Off	The UPS is turned off.
 Yellow	On	The UPS is in Battery mode. Because Battery mode is a normal condition of the UPS, the Normal indicator also remains illuminated.
 Yellow	On	The UPS is in Bypass mode. The critical load is supported by the bypass source. The Normal indicator is not illuminated when the system is in Bypass mode.
 Red	On	The UPS has an active alarm and requires immediate attention. The LCD shows the highest priority active alarms. All alarms are accompanied by an audible horn. To silence the horn, press any control panel pushbutton once. The Alarm indicator may be illuminated along with other indicators.
	Flashing	There is a new UPS alarm condition. The indicator flashes until acknowledged by pressing any control panel pushbutton once.

## 7.2.2 System Events


When the UPS system is running in Normal mode, it continually monitors itself and the incoming utility power. In Battery or Bypass modes, the UPS may issue alarms to let you know exactly what event caused the change from Normal mode. System events on the UPS can be indicated by horns, lights, messages, or all three.

Select **EVENTS** from the menu bar on the main menu screen to look at the active events screen. This screen shows any currently active alarms, notices, or commands. For more information on using the events screen, see paragraph 7.2.6 on page 7-6.

- **System Event Horns** – The system event horn beeps to alert an operator that an event needing attention is taking place. The horn cycles at a half-second rate.
- **System Event Indicators** – The status indicators on the UPS control panel work with the event horn to let the operator know when the UPS is operating in any mode other than normal. Only the ON indicator is visible during normal UPS system operation. The other indicators illuminate to indicate alarms or events. When an alarm occurs, first check these indicators to see what type of event has taken place. For descriptions of the status indicators, see paragraph 7.2.1.
- **System Event Messages** – When a system event occurs, a message appears on the LCD in the UPS status area. This message is also written to the Active Events Log and may be added to the History Log. The messages are divided into four categories: alarms, notices, status, and commands.

### 7.2.3 Using the LCD and Pushbuttons

The LCD on the control panel provides an operator interface with the UPS system. Figure 7-3 identifies the display areas discussed in the following sections.



**Figure 7-3. Parts of the LCD**

- A** The *UPS status* area automatically scrolls between the Eaton model number, current date and time, active alarms, active notices, and load percent and battery runtime for the UPS. If the Eaton Environmental Monitoring Probe is installed, the temperature and humidity sensed by the probe will also be displayed. The top line of display blinks while scrolling when the system needs attention. Some notices and alarms may be accompanied by an audible horn. To silence the horn, press any control panel pushbutton once. Shown is a typical alarm message. For more information about alarms and notices, see paragraph 7.2.2.
- B** The *information area* contains data about UPS status and operations.
- C** The *menu bar* lists the titles of the available screens. To select a screen, press the pushbutton underneath the desired screen.
- D** The *navigation pushbuttons* function depending on the screen displayed. Use the pushbuttons to select menu screens or scroll through available screens. The LCD options above the pushbuttons indicate each pushbutton's function.

You can use the LCD and the pushbuttons to:

- Look at a log of UPS events (alarms, notices, and commands) (see paragraph 7.2.6)
- Monitor UPS operation (see paragraph 7.2.6)
- Set UPS parameters (see paragraph 7.2.6)
- Control UPS operation (see paragraphs 7.2.8 and 7.2.7)

After approximately 30 minutes, the display screen darkens. To restore the screen, press any pushbutton once.

### 7.2.4 Using the Menu

The UPS menu bar allows you to display data in the information area to help you monitor and control UPS operation. Table 7-2 shows the basic menu structure.


**Table 7-2. Display Function Menu Map**

Menu Option	Description
EVENTS	Displays the list of Active System Events and a historical log of system events.
METERS	Displays performance meters for the system or critical load.
CONTROLS	Displays the System Status screen.
SETUP	Allows you to set the display contrast, set the date and time for the time stamp, configure the UPS serial communication ports, and view the firmware version numbers.
LOAD OFF	De-energizes the critical load and powers down the UPS.
ESC	Returns to Main Menu and Mimic screen from the Events, Meters, Controls, or Setup screens. Returns to the main System Setup Level screen from a setup submenu.
←	Return arrow acknowledges or executes a command, or saves a setting.
↑ ↓	Up and down arrows scroll through screens and lists or highlight settings.
← →	Left and right arrows select or adjust settings displayed on the screen.

### 7.2.5 Mimic Screen

Figure 7-4 shows the Main Menu and Mimic screen. To select the Mimic screen from the Events, Meters, Controls, or Setup screens, press the ESC pushbutton on the current menu bar.

The Mimic screen shows the internal components of the UPS cabinet and a real-time graphical representation of the operating status of the system.



**Figure 7-4. Main Menu and Mimic Screen (Normal Mode)**

## 7.2.6 Display Menu Operation

Table 7-3 describes the menu functions and how to use them.

**Table 7-3. Display Menu Operation**

Function	Subfunction	Operation
Events		Press the EVENTS pushbutton on the main menu bar or History menu bar to display a listing of all system events that are currently active. The most recent event is listed first. As events clear, they are removed from the Active System Events listing. To scroll through the events, press the up or down arrow pushbutton on the menu bar.
User History		Press the HISTORY pushbutton on the Active Events menu bar to display the User History Log. The User History Log lists up to 2048 events in chronological order, with the most recent event listed last (once 2048 is reached, the earliest event is overwritten). The end of the log (the most recent events) is displayed first; scroll upward to view older event listings. To scroll through the events, press the up or down arrow pushbutton on the menu bar. To return to the Active Events screen, press the EVENTS pushbutton on the menu bar.
Service History		The Service History Log is for service personnel and is password protected. If the customer needs access to the log, contact an Eaton service representative. Press the SERVICE pushbutton on the User History menu bar to display the Service History Log. The Service History Log lists up to 2048 events in chronological order, with the most recent event listed last (once 2048 is reached, the earliest event is overwritten). The end of the log (the most recent events) is displayed first; scroll upward to view older event listings. To scroll through the events, press the up or down arrow pushbutton on the menu bar. To return to the User History screen, press the USER pushbutton on the menu bar. To return to the Active Events screen, press the EVENTS pushbutton on the menu bar.
Meters – UPS Meters – UPM		The Meter screens show the UPS meter readings for the unit. The default voltage displayed on these screens is phase-to-neutral. However, an authorized Eaton Customer Service Engineer can change the screens to display the voltage phase-to-phase (A-B, B-C, C-A). Press the METERS pushbutton on the main menu bar to display the Meter screens. To scroll through the meter screens, press the up or down arrow pushbutton on the menu bar. The current UPS readings are displayed in the information area of the screen.
	Output – UPS Output – UPM	The Output screen shows output voltage (phase-to-neutral), output current (each phase), and frequency being supplied by the UPS, as well as the kVA, kW, and power factor measurements.
	Input – UPS Input – UPM	The Input screen shows input voltage (phase-to-neutral), input current (each phase), and frequency of the incoming utility source, as well as the kVA, kW, and power factor measurements.
	Bypass	The Bypass screen shows the bypass input voltage (phase-to-neutral), input current (each phase), and frequency of the incoming utility source, as well as the kVA, kW, and power factor measurements.
	Battery – UPS Battery – UPM	The Battery screen displays the battery voltage (Vdc), the battery current (Idc), the minutes of battery time remaining, and battery temperature. Battery temperature must be set up by an authorized Eaton Customer Service Engineer. When battery life decreases to less than 20%, Check Battery is displayed.
	Statistics	The Statistics screen displays the hours on line and the total kW hours used.
	Output Current – UPS Output Current – UPM	The Output Current screen displays a real-time bar graph of the output current of the UPS. The graph shows the current for each phase.
	Output Power – UPM	The Output Power screen displays the power in kW and kVA for each UPM.
System Level 0 Setup	Function Selection	This screen can be used to set the screen contrast, show the firmware versions installed, identify the unit type, change the display language, set up Energy Saver functions, set up Advanced Power Management functions, and enter a password to access Level 1 functions. Press the SETUP pushbutton on the main menu bar to display the System Setup Level 0 Screen. No password is necessary to access Level 0 functions. Use the up or down arrow pushbutton to highlight the setup function screen desired, then press the SELECT pushbutton to display the function screen.



**Table 7-3. Display Menu Operation (continued)**

Function	Subfunction	Operation
	Contrast Adjust	Select CONTRAST from the System Setup Level 0 menu to display the Contrast Adjust screen. Use the left or right arrow pushbutton to adjust the contrast for the LCD. When the contrast adjustment is complete, press the SAVE pushbutton. Once the setting is saved, the System Setup screen displays. To return to the System Setup screen without saving the setting, press the ESC pushbutton.
	Firmware Versions	The Versions screen provides the firmware version numbers installed on the UPS. Select VERSIONS from the System Setup Level 0 menu to display the Versions screen. To scroll through the firmware types, press the up or down arrow pushbutton on the menu bar. To return to the System Setup screen, press the ESC pushbutton.
	Identification	The Unit Type screen provides the model, CTO, and serial numbers of the UPS unit. Select UNIT TYPE from the System Setup Level 0 menu to display the Unit Type screen. To return to the System Setup screen, press the ESC pushbutton.
	Language	The Language Setup screen allows the display menu language to be set. Select LANGUAGE SETUP from the System Setup Level 0 menu to display the Language Setup screen. Use the up or down arrow pushbutton to highlight the desired language, then press the SELECT pushbutton. To return to the System Setup screen, press the ESC pushbutton.
	Energy Saver Mode	The Energy Saver Setup Mode screen allows the Energy Saver function to be configured. Select ENERGY SAVER MODE SETUP from the System Setup Level 0 menu to display the Energy Saver Mode Setup screen. Use the up or down arrow pushbutton to highlight the desired function, then press the SELECT pushbutton. To return to the System Setup screen, press the ESC pushbutton.
	Storm Detection Counter	The Storm Detection Counter screen sets the number of power line disturbances that can occur before the UPS locks into Normal mode. Select STORM DETECTION COUNTER from the Energy Saver Mode Setup screen to display the Storm Detection Counter screen. Use the up or down arrow pushbutton to set the counter. Press SAVE or ABORT. Once the action is completed, the Energy Saver Mode Setup screen is displayed.
	Storm Detection Timer	The Storm Detection Timer screen sets the length of time that power line disturbances are monitored. The time can be set in 10 minute increments from 0 to 990 minutes. Select STORM DETECTION TIMER from the Energy Saver Mode Setup screen to display the Storm Detection Timer screen. Use the up or down arrow pushbutton to set the time. Press SAVE or ABORT. Once the action is completed, the Energy Saver Mode Setup screen is displayed.
	High Alert Timer	The High Alert Timer screen sets the length of time the UPS remains in Normal mode before transferring back to Energy Saver mode. The time can be set in 10 minute increments from 0 to 990 minutes. Select HIGH ALERT TIMER from the Energy Saver Mode Setup screen to display the High Alert Timer screen. Use the up or down arrow pushbutton to set the time. Press SAVE or ABORT. Once the action is completed, the Energy Saver Mode Setup screen is displayed.
	Advanced Power Management	The Advanced Power Management Setup screen allows the Advanced Power Management function to be configured. Select ADVANCED POWER MANAGEMENT SETUP from the System Setup Level 0 menu to display the Advanced Power Management Setup screen. Use the up or down arrow pushbutton to highlight the desired function, then press the SELECT pushbutton. To return to the System Setup screen, press the ESC pushbutton.
	APM Load Limit	The APM Load Limit screen sets the maximum load that can be drawn from a UPM before additional UPMs are activated. Select APM LOAD LIMIT from the Advanced Power Management Setup screen to display the APM Load Limit screen. Use the up or down arrow pushbutton to set the load limit. Press SAVE or ABORT. Once the action is completed, the Advanced Power Management screen is displayed.
	APM UPM Redundancy	The APM UPM Redundancy screen sets the number of UPMs to remain active to maintain redundancy. Select APM UPM REDUNDANCY from the Advanced Power Management Setup screen to display the APM UPM Redundancy screen. Use the up or down arrow pushbutton to set the number of UPMs. Press SAVE or ABORT. Once the action is completed, the Advanced Power Management Setup screen is displayed.

**Table 7-3. Display Menu Operation (continued)**


Function	Subfunction	Operation
	High Alert Timer	The High Alert Timer screen sets the length of time the all UPMs remain active before transferring back to Advanced Power Management mode. The time can be set in 10 minute increments from 0 to 990 minutes. Select HIGH ALERT TIMER from the Advanced Power Management Setup screen to display the High Alert Timer screen. Use the up or down arrow pushbutton to set the time. Press SAVE or ABORT. Once the action is completed, the Advanced Power Management Setup screen is displayed.
System Level 1 Setup	Password	The System Setup Level 1 screen can be used to set the UPS date and time, set the serial ports, change the Level 1 password, and log out of Level 1. In addition, the Level 0 functions are available. A password is required to access the Level 1 functions. To enter the password, select ENTER PASSWORD from the System Setup Level 0 menu to display the Enter Password screen. Use the left or right arrow pushbutton to select the password character position. Use the up or down arrow pushbutton to change the password character. Once the password is entered, press the DONE pushbutton. The System Setup Level 1 menu screen is displayed. The default password is L1.
	Function Selection	Use the up or down arrow pushbutton to highlight the setup function screen desired, then press the SELECT pushbutton to display the function screen. The Level 1 screen times out after 60 minutes or can be logged out at any time by selecting the LOG OUT function from the menu screen.
	Change Password	The Change Password screen allows the System Setup Level 1 password to be changed. Select CHANGE PASSWORD from the System Setup Level 1 menu to display the Change Password screen. Use the left or right arrow pushbutton to select the password character position. Use the up or down arrow pushbutton to change the password character. Once the new password is entered, press the DONE pushbutton. The Change Password Save screen is displayed.
	Change Password Save	The Change Password Save screen lets you save the new password, retry another password, or abort the password change. Press SAVE, RETRY, or ABORT. If SAVE or ABORT is pressed, the action is completed, and the System Setup screen displays. If RETRY is pressed, the Change Password screen is redisplayed.
	Time Format	The Time Format Setup screen allows the selection of either month/day/year or day/month/year formats for display on the screen and for logging events in the Event and History Logs. Select SET DATE AND TIME from the System Setup Level 1 menu to display the Time Format Setup screen. Use the up or down arrow pushbutton to highlight the desired format, then press the SELECT pushbutton to display the Set Date and Time screen. To return to the System Setup screen, press the ESC pushbutton.
	Set Date and Time MM/DD/YYYY	The Set Date and Time MM/DD/YYYY screen allows the internal date and time of the UPS to be set in the month/day/year format. The date and time information is used for display on the screen and for logging events in the Event and History Logs. Use the left or right arrow pushbutton to highlight the setting to be changed. Use the up or down arrow pushbutton to make the change. When finished making changes, use the left or right arrow pushbutton to highlight SAVE and the up or down arrow pushbutton to select YES. To complete the save function and return to the System Setup screen, select the return arrow pushbutton.
	Set Date and Time DD/MM/YYYY	The Set Date and Time DD/MM/YYYY screen allows the internal date and time of the UPS to be set in the day/month/year format. The date and time information is used for display on the screen and for logging events in the Event and History Logs. Use the left or right arrow pushbutton to highlight the setting to be changed. Use the up or down arrow pushbutton to make the change. When finished making changes, use the left or right arrow pushbutton to highlight SAVE and the up or down arrow pushbutton to select YES. To complete the save function and return to the System Setup screen, select the return arrow pushbutton.
	Com Port Selection	The Com Port Setup screen allows selection of the serial COM port to set up. Select COM PORT SETUP from the System Setup Level 1 menu to display the COM Port Setup screen. Use the up or down arrow pushbutton to highlight the COM port to be set up, then press the SELECT pushbutton. To return to the System Setup screen, press the ESC pushbutton.

**Table 7-3. Display Menu Operation (continued)**

Function	Subfunction	Operation
	Com Port Setup	The COM Setup screen is used to change and save the settings for the selected serial communication port. The COM port number selected from the COM Port Setup screen displays. If the changes are not wanted, use the ABORT pushbutton to return to the COM Port Setup screen. Use the up or down arrow pushbutton to highlight the setting to be changed. Use the return arrow pushbutton to toggle through the values for the setting to make the change. Press SAVE or ABORT. Once the action is completed, the COM Port Setup screen is displayed.
Controls		See paragraph 7.2.8 for details.

**7.2.7 Load Off Screen**

The Load Off screen (Figure 7-5) is displayed when the LOAD OFF pushbutton is selected from the main menu bar, the UPS Control Command screen, or the Bypass Control Command screen. This screen allows the LOAD OFF process to be aborted if the LOAD OFF pushbutton was pressed accidentally. For Load Off procedures, see paragraph 7.3.24 on page 7-26 or paragraph 7.4.27 on page 7-46.



**Figure 7-5. Load Off Screen**

### 7.2.8 System Status Screen and Controls

Press the **CONTROLS** pushbutton on the main menu bar to display the System Status screen. Normal operation, transfer to bypass, charger control, UPM startup and shutdown, and **LOAD OFF** commands are controlled through this screen. In addition, the screen displays the current status of the UPS, indicates whether the UPS is in Maintenance Bypass or Bypass, and displays the state of the UPM and battery charger. Figure 7-6 shows the System Status screen.

Use the **↑** or **↓** pushbutton on the System Status menu bar to highlight the command screen desired, then press the **CONTROLS** pushbutton to display the command menu screen.

Table 7-4 lists the typical System Status Screen Messages that are displayed during UPS operation.

Table 7-5 describes the control functions and provides instructions to access and use the command menu screens.

For detailed information about using the System Controls, see paragraph 7.3.




Figure 7-6. Typical System Status Screen

Table 7-4. Typical System Status Messages

Function	Message
UPS	Shutdown; Bypass; Online; Online with ESM; Online + APM; High Alert
Bypass	Off; On; Available
Maintenance Bypass	Off; On
Charger	Charger Off; Charging
UPM (during startup)	DC Starting, Charger Off; DC Starting, Close Battery Breaker; Inverter Starting; Inverter Syncing; Ready; Online
UPM 1	Offline; Shutdown, Charger Off; Ready; Ready, Charging;
UPM 2	Online, Charger Off; Online, Charging
UPM 3	
UPM 4 (not displayed on three UPM model)	

**Table 7-5. Command Menu Operation**

Function	Subfunction	Operation
UPS Control Commands		Use the up or down arrow pushbutton to highlight the command function desired, then press the SELECT pushbutton to execute the command or proceed to further command screens.
	Go to Online	Starts the UPS in Normal mode or transfers the UPS to Normal mode from Bypass mode.
	Enable (Disable) Energy Saver	Enables or disables Energy Saver. Enable changes to Disable when Energy Saver is enabled.
	Enable (Disable) Adv Power Management	Enables or disables Advanced Power Management. Enable changes to Disable when Advanced Power Management is enabled.
	Start High Alert	Starts High Alert mode.
	Go to Bypass	Starts the UPS in Bypass mode or transfers the UPS to Bypass mode from Normal mode.
	Load Off	Displays the Load Off screen (see paragraph 7.2.7).
Bypass Commands		Use the up or down arrow pushbutton to highlight the command function desired, then press the SELECT pushbutton to execute the command or proceed to further command screens.
	Go to Bypass	Starts the UPS in Bypass mode or transfers the UPS to Bypass mode from Normal mode.
	Go to Online	Starts the UPS in Normal mode or transfers the UPS to Normal mode from Bypass mode.
	Enable (Disable) Energy Saver	Enables or disables Energy Saver. Enable changes to Disable when Energy Saver is enabled.
	Enable (Disable) Adv Power Management	Enables or disables Advanced Power Management. Enable changes to Disable when Advanced Power Management is enabled.
	Start High Alert	Starts High Alert mode.
	Load Off	Displays the Load Off screen (see paragraph 7.2.7).
Charger Control Commands		Use the up or down arrow pushbutton to highlight the command function desired, then press the SELECT pushbutton to execute the command.
	Charger On	Turns the battery charger on.
	Charger Off	Turns the battery charger off.
UPM Control Commands		Use the up or down arrow pushbutton to highlight the command function desired, then press the SELECT pushbutton to execute the command.
	UPM On	Turns the UPM on without transferring the load to Normal mode. The Load is on bypass.
	UPM Off	Transfers the load to bypass and turns the UPM off.
	UPM Go to Normal	Turns the UPM on and transfers the load to Normal mode.
	Charger On	Turns the battery charger on.
	Charger Off	Turns the battery charger off.

NOTE The Energy Saver and Advanced Power Management mode commands are displayed only if enabled at the factory or by an Eaton Customer Service Engineer.

NOTE Advanced Power Management and Energy Saver modes are mutually exclusive.

## 7.3 Single UPS Operation

The paragraphs in this section provide operating instructions for a UPS system containing only one UPS.




---

**NOTE** A Field Installed UPM (FI-UPM) is always designated as UPM 4.

---

### 7.3.1 Starting the UPS in Normal Mode

To start the UPS system:

1. Unfasten the front door latch and swing the door open (see Figure 4-1 on page 4-2).
2. If the UPS contains input breaker CB1, verify that input breaker CB1 is open.
3. Close the UPS input feeder circuit breaker.
4. Close the UPS Bypass input feeder circuit breaker.
5. If the UPS contains input breaker CB1, close input breaker CB1.
6. Close the door and secure the latch.
7. Observe the UPS control panel display becoming active, indicating logic power.
8. Press the **CONTROLS** pushbutton on the main menu bar. The System Status screen is displayed.
9. On the System Status screen, verify the UPS status is **SHUTDOWN** and the UPM status is **OFFLINE**.
10. Close the battery breaker.
11. Verify no alarms are active.
12. On the System Status screen, select the **UPS** command.
13. Press the **CONTROLS** pushbutton on the System Status menu bar. The UPS Control Command screen is displayed.
14. On the UPS Control Command screen, select **GO TO NORMAL**.
15. Press the **SELECT** pushbutton on the UPS Command menu bar.

If Auto Bypass is enabled (factory default), the critical load is immediately supplied by the bypass source, in Bypass mode, until the inverter turns on and the UPS transfers to Normal mode. The status indicator on the UPS control panel indicates the UPS is in Bypass mode. If Auto Bypass is not enabled, the UPS output remains off until the UPS transfers to Normal mode.

16. Verify the following messages display sequentially on the UPM status line:

DC STARTING, CHARGER OFF  
 INVERTER STARTING  
 INVERTER SYNCING  
 ONLINE, CHARGING

The rectifier and inverter turn on. The inverter continues to ramp up to full voltage.

Once the inverter reaches full voltage, the UPS output contactor K3 closes and the static switch turns off. Power is now supplied to the critical load in Normal mode. It takes approximately one minute for the UPS to achieve Normal mode.

The **NORMAL** status indicator is illuminated. The UPS status indicates **ONLINE**. The UPM status indicates **ONLINE, CHARGING**.

### 7.3.2 Enable Energy Saver Mode from the UPS Command Menu

To enable Energy Saver mode:



**NOTE** The Energy Saver mode commands are displayed only if enabled at the factory or by an Eaton Customer Service Engineer.

**NOTE** Advanced Power Management and Energy Saver modes are mutually exclusive. If Advanced Power Management is enabled, Energy Saver commands will not be displayed.

1. Press the **CONTROLS** pushbutton on the main menu bar. The System Status screen is displayed.
2. On the System Status screen, select the **UPS** command.
3. Press the **CONTROLS** pushbutton on the System Status menu bar. The UPS Control Command screen is displayed.
4. On the UPS Control Command screen, select **ENABLE ENERGY SAVER**.
5. Press the **SELECT** pushbutton on the UPS Command menu bar.

The UPS transfers to Energy Saver mode.

The **NORMAL** status indicator is illuminated. The UPS status indicates **ONLINE WITH ESM**. The UPM status indicates **ONLINE**. If the battery is not charging, the power module is off.

### 7.3.3 Disable Energy Saver Mode from the UPS Command Menu

To disable Energy Saver mode:



**NOTE** The Energy Saver mode commands are displayed only if enabled at the factory or by an Eaton Customer Service Engineer.

**NOTE** Advanced Power Management and Energy Saver modes are mutually exclusive. If Advanced Power Management is enabled, Energy Saver commands will not be displayed.

1. Press the **CONTROLS** pushbutton on the main menu bar. The System Status screen is displayed.
2. On the System Status screen, select the **UPS** command.

3. Press the **CONTROLS** pushbutton on the System Status menu bar. The UPS Control Command screen is displayed.
4. On the UPS Control Command screen, select **DISABLE ENERGY SAVER**.
5. Press the **SELECT** pushbutton on the UPS Command menu bar.

The UPS transfers to Battery mode and then to Normal mode.

The **NORMAL** status indicator is illuminated. The UPS status indicates **ONLINE**. The UPM status indicates **ONLINE**.

### 7.3.4 Start Energy Saver High Alert Mode from the UPS Command Menu

To start High Alert mode:




---

**NOTE** *The High Alert mode commands are displayed only if enabled at the factory or by an Eaton Customer Service Engineer.*

**NOTE** *Advanced Power Management and Energy Saver modes are mutually exclusive. If Advanced Power Management is enabled, Energy Saver commands will not be displayed.*

---

1. Press the **CONTROLS** pushbutton on the main menu bar. The System Status screen is displayed.
2. On the System Status screen, select the **UPS** command.
3. Press the **CONTROLS** pushbutton on the System Status menu bar. The UPS Control Command screen is displayed.
4. On the UPS Control Command screen, select **START HIGH ALERT**.
5. Press the **SELECT** pushbutton on the UPS Command menu bar.

The UPS starts High Alert mode with the UPMs online supplying the critical load. After one hour the UPS transfers to Energy Saver mode.

The **NORMAL** status indicator is illuminated. The UPS status indicates **HIGH ALERT**. The UPM status indicates **ONLINE**. The power module is on.

### 7.3.5 Enable Advanced Power Management Mode from the UPS Command Menu

To enable Advanced Power Management mode:




---

**NOTE** *The Advanced Power Management mode commands are displayed only if enabled at the factory or by an Eaton Customer Service Engineer.*

**NOTE** *Advanced Power Management and Energy Saver modes are mutually exclusive. If Energy Saver is enabled, Advanced Power Management commands will not be displayed.*

---

1. Press the **CONTROLS** pushbutton on the main menu bar. The System Status screen is displayed.
2. On the System Status screen, select the **UPS** command.
3. Press the **CONTROLS** pushbutton on the System Status menu bar. The UPS Control Command screen is displayed.
4. On the UPS Control Command screen, select **ENABLE ADV POWER MANAGEMENT**.



5. Press the **SELECT** pushbutton on the UPS Command menu bar.

The UPS transfers to Advanced Power Management mode. In approximately twenty seconds the UPS calculates the required number of UPMs needed to support the load.

The **NORMAL** status indicator is illuminated. The UPS status indicates **ONLINE + APM**. The UPM status indicates **ONLINE**.

### 7.3.6 Disable Advanced Power Management Mode from the UPS Command Menu

To disable Advanced Power Management mode:



**NOTE** The Advanced Power Management mode commands are displayed only if enabled at the factory or by an Eaton Customer Service Engineer.

**NOTE** Advanced Power Management and Energy Saver modes are mutually exclusive. If Energy Saver is enabled, Advanced Power Management commands will not be displayed.

1. Press the **CONTROLS** pushbutton on the main menu bar. The System Status screen is displayed.
2. On the System Status screen, select the **UPS** command.
3. Press the **CONTROLS** pushbutton on the System Status menu bar. The UPS Control Command screen is displayed.
4. On the UPS Control Command screen, select **DISABLE ADV POWER MANAGEMENT**.
5. Press the **SELECT** pushbutton on the UPS Command menu bar.

The UPS transfers to Battery mode and then to Normal mode in approximately ten seconds.

The **NORMAL** status indicator is illuminated. The UPS status indicates **ONLINE**. The UPM status indicates **ONLINE**.

### 7.3.7 Start Advanced Power Management High Alert Mode from the UPS Command Menu

To start High Alert mode:



**NOTE** The High Alert mode commands are displayed only if enabled at the factory or by an Eaton Customer Service Engineer.

**NOTE** Advanced Power Management and Energy Saver modes are mutually exclusive. If Energy Saver is enabled, Advanced Power Management commands will not be displayed.

1. Press the **CONTROLS** pushbutton on the main menu bar. The System Status screen is displayed.
2. On the System Status screen, select the **UPS** command.
3. Press the **CONTROLS** pushbutton on the System Status menu bar. The UPS Control Command screen is displayed.
4. On the UPS Control Command screen, select **START HIGH ALERT**.

5. Press the **SELECT** pushbutton on the UPS Command menu bar.

The UPS starts High Alert mode with the UPMs online supplying the critical load. After one hour the UPS transfers to Advanced Power Management mode.

The **NORMAL** status indicator is illuminated. The UPS status indicates **HIGH ALERT**. The UPM status indicates **ONLINE**. The power module is on.

### 7.3.8 Starting the UPS in Bypass Mode

If the inverter output of the UPS is not available and the critical load needs to be energized:



#### CAUTION

In Bypass mode, the critical load is not protected from commercial power interruptions and abnormalities.

1. Unfasten the front door latch and swing the door open (see Figure 4-1 on page 4-2).
2. If the UPS contains input breaker CB1, verify that input breaker CB1 is open.
3. Close the UPS input feeder circuit breaker.
4. Close the UPS Bypass input feeder circuit breaker.
5. If the UPS contains input breaker CB1, close input breaker CB1.
6. Close the door and secure the latch.
7. Observe the UPS control panel becoming active, indicating logic power.
8. Press the **CONTROLS** pushbutton on the main menu bar. The System Status screen is displayed.
9. On the System Status screen, verify the UPS status is **SHUTDOWN** and the UPM status is **OFFLINE**.
10. On the System Status screen, select the **BYPASS** command.
11. Press the **CONTROLS** pushbutton on the System Status menu bar. The Bypass Control Command screen is displayed.
12. On the Bypass Control Command screen, select **GO TO BYPASS**.
13. Press the **SELECT** pushbutton on the Bypass Command menu bar.

The critical load is immediately supplied by the bypass source, in Bypass mode.

The **BYPASS** status indicator is illuminated. The Bypass status indicates **ON**. The UPM status indicates **SHUTDOWN, CLOSE BATTERY**.

### 7.3.9 Enable Energy Saver Mode from the Bypass Command Menu

To enable Energy Saver mode:



**NOTE** The Energy Saver mode commands are displayed only if enabled at the factory or by an Eaton Customer Service Engineer.

**NOTE** Advanced Power Management and Energy Saver modes are mutually exclusive. If Advanced Power Management is enabled, Energy Saver commands will not be displayed.

1. Press the **CONTROLS** pushbutton on the main menu bar. The System Status screen is displayed.
2. On the System Status screen, select the **BYPASS** command.
3. Press the **CONTROLS** pushbutton on the System Status menu bar. The Bypass Control Command screen is displayed.
4. On the Bypass Control Command screen, select **ENABLE ENERGY SAVER**.
5. Press the **SELECT** pushbutton on the Bypass Command menu bar.

If the UPS is online, the UPS transfers to Energy Saver mode.

The **NORMAL** status indicator is illuminated. The UPS status indicates **ONLINE WITH ESM**. The UPM status indicates **ONLINE**. If the battery is not charging, the power module is off.

### 7.3.10 Disable Energy Saver Mode from the Bypass Command Menu

To disable Energy Saver mode:



**NOTE** The Energy Saver mode commands are displayed only if enabled at the factory or by an Eaton Customer Service Engineer.

**NOTE** Advanced Power Management and Energy Saver modes are mutually exclusive. If Advanced Power Management is enabled, Energy Saver commands will not be displayed.

1. Press the **CONTROLS** pushbutton on the main menu bar. The System Status screen is displayed.
2. On the System Status screen, select the **BYPASS** command.
3. Press the **CONTROLS** pushbutton on the System Status menu bar. The Bypass Control Command screen is displayed.
4. On the Bypass Control Command screen, select **DISABLE ENERGY SAVER**.
5. Press the **SELECT** pushbutton on the Bypass Command menu bar.

If the UPS is online, the UPS transfers to Battery mode and then to Normal mode.

The **NORMAL** status indicator is illuminated. The UPS status indicates **ONLINE**. The UPM status indicates **ONLINE**.

### 7.3.11 Start Energy Saver High Alert Mode from the Bypass Command Menu

To start High Alert mode:



**NOTE** The High Alert mode commands are displayed only if enabled at the factory or by an Eaton Customer Service Engineer.

**NOTE** Advanced Power Management and Energy Saver modes are mutually exclusive. If Advanced Power Management is enabled, Energy Saver commands will not be displayed.

1. Press the **CONTROLS** pushbutton on the main menu bar. The System Status screen is displayed.
2. On the System Status screen, select the **BYPASS** command.
3. Press the **CONTROLS** pushbutton on the System Status menu bar. The Bypass Control Command screen is displayed.
4. On the Bypass Control Command screen, select **START HIGH ALERT**.
5. Press the **SELECT** pushbutton on the Bypass Command menu bar.

If the UPS is online, the UPS starts High Alert mode with the UPMs online supplying the critical load. After one hour the UPS transfers to Energy Saver mode.

The **NORMAL** status indicator is illuminated. The UPS status indicates **HIGH ALERT**. The UPM status indicates **ONLINE**. The power module is on.

### 7.3.12 Enable Advanced Power Management Mode from the Bypass Command Menu

To enable Advanced Power Management mode:



**NOTE** The Advanced Power Management mode commands are displayed only if enabled at the factory or by an Eaton Customer Service Engineer.

**NOTE** Advanced Power Management and Energy Saver modes are mutually exclusive. If Energy Saver is enabled, Advanced Power Management commands will not be displayed.

1. Press the **CONTROLS** pushbutton on the main menu bar. The System Status screen is displayed.
2. On the System Status screen, select the **BYPASS** command.
3. Press the **CONTROLS** pushbutton on the System Status menu bar. The Bypass Control Command screen is displayed.
4. On the Bypass Control Command screen, select **ENABLE ADV POWER MANAGEMENT**.
5. Press the **SELECT** pushbutton on the Bypass Command menu bar.

If the UPS is online, the UPS transfers to Advanced Power Management mode. In approximately twenty seconds the UPS calculates the required number of UPMs needed to support the load.

The **NORMAL** status indicator is illuminated. The UPS status indicates **ONLINE + APM**. The UPM status indicates **ONLINE**.

### 7.3.13 Disable Advanced Power Management Mode from the Bypass Command Menu

To disable Advanced Power Management mode:



**NOTE** The Advanced Power Management mode commands are displayed only if enabled at the factory or by an Eaton Customer Service Engineer.

**NOTE** Advanced Power Management and Energy Saver modes are mutually exclusive. If Energy Saver is enabled, Advanced Power Management commands will not be displayed.

1. Press the **CONTROLS** pushbutton on the main menu bar. The System Status screen is displayed.
2. On the System Status screen, select the **BYPASS** command.
3. Press the **CONTROLS** pushbutton on the System Status menu bar. The Bypass Control Command screen is displayed.
4. On the Bypass Control Command screen, select **DISABLE ADV POWER MANAGEMENT**.
5. Press the **SELECT** pushbutton on the Bypass Command menu bar.

If the UPS is online, the UPS transfers to Battery mode and then to Normal mode in approximately ten seconds.

The **NORMAL** status indicator is illuminated. The UPS status indicates **ONLINE**. The UPM status indicates **ONLINE**.

### 7.3.14 Start Advanced Power Management High Alert Mode from the Bypass Command Menu

To start High Alert mode:



**NOTE** The High Alert mode commands are displayed only if enabled at the factory or by an Eaton Customer Service Engineer.

**NOTE** Advanced Power Management and Energy Saver modes are mutually exclusive. If Energy Saver is enabled, Advanced Power Management commands will not be displayed.

1. Press the **CONTROLS** pushbutton on the main menu bar. The System Status screen is displayed.
2. On the System Status screen, select the **BYPASS** command.
3. Press the **CONTROLS** pushbutton on the System Status menu bar. The Bypass Control Command screen is displayed.
4. On the Bypass Control Command screen, select **START HIGH ALERT**.
5. Press the **SELECT** pushbutton on the Bypass Command menu bar.

If the UPS is online, the UPS starts High Alert mode with the UPMs online supplying the critical load. After one hour the UPS transfers to Advanced Power Management mode.

The **NORMAL** status indicator is illuminated. The UPS status indicates **HIGH ALERT**. The UPM status indicates **ONLINE**. The power module is on.

### 7.3.15 Starting the UPMs

To start the power module without transferring the critical load to Normal mode:

1. Unfasten the front door latch and swing the door open (see Figure 4-1 on page 4-2).
2. If the UPS contains input breaker CB1, verify that input breaker CB1 is open.
3. Close the UPS input feeder circuit breaker.
4. Close the UPS Bypass input feeder circuit breaker.
5. If the UPS contains input breaker CB1, close input breaker CB1.
6. Close the door and secure the latch.
7. Observe the UPS control panel becoming active, indicating logic power.
8. Press the **CONTROLS** pushbutton on the main menu bar. The System Status screen is displayed.
9. On the System Status screen, the UPS status should indicate **SHUTDOWN** and the UPM status should indicate **OFFLINE**.
10. Verify no alarms are active.
11. On the System Status screen, select the **UPM** command. The UPS Control Command screen is displayed.
12. On the UPS Control Command screen, select the **UPM 1** command.
13. Press the **CONTROLS** pushbutton on the UPS Control Command menu bar. The UPM 1 Control Command screen is displayed.
14. On the UPM 1 Control Command screen, select **UPM ON**.
15. Press the **SELECT** pushbutton on the UPM 1 Command menu bar.
16. Verify the following messages display sequentially on the UPM status line:

```
DC STARTING, CHARGER OFF
INVERTER STARTING
INVERTER SYNCING
READY
```

The UPM 1 rectifier and inverter turn on.

If the Inherent Redundancy option is enabled, a loss of redundancy alarm will be issued. Silence the alarm and continue to Step 17.

17. Repeat Steps 12 through 15 selecting **UPM 2** to start UPM 2.
18. Verify the following messages display sequentially on the UPM status line:

```
DC STARTING, CHARGER OFF
INVERTER STARTING
INVERTER SYNCING
READY
```

The UPM 2 rectifier and inverter turn on. When the inverter reaches full voltage, the UPS is ready to transfer to Normal mode and supply the critical load.

19. Repeat Steps 12 through 15 selecting **UPM 3** to start UPM 3.
20. Verify the following messages display sequentially on the UPM status line:

DC STARTING, CHARGER OFF  
 INVERTER STARTING  
 INVERTER SYNCING  
 READY

The UPM 3 rectifier and inverter turn on. When the inverter reaches full voltage, the UPS is ready to transfer to Normal mode and supply the critical load.




---

**NOTE** Steps 21 and 22 are not applicable to the three UPM model.

---

21. Repeat Steps 12 through 15 selecting **UPM 4** to start UPM 4.
22. Verify the following messages display sequentially on the UPM status line:

DC STARTING, CHARGER OFF  
 INVERTER STARTING  
 INVERTER SYNCING  
 READY

The UPM 4 rectifier and inverter turn on. When the inverter reaches full voltage, the UPS is ready to transfer to Normal mode and supply the critical load.




---

**NOTE** To transfer to Normal mode after starting individual UPMs, follow the procedure in paragraph 7.3.18. .

---

### 7.3.16 Starting a Single UPM

To start a single UPM:

1. Unfasten the front door latch and swing the door open (see Figure 4-1 on page 4-2).
2. If the UPS contains input breaker CB1, verify that input breaker CB1 is open.
3. Close the UPS input feeder circuit breaker.
4. Close the UPS Bypass input feeder circuit breaker.
5. If the UPS contains input breaker CB1, close input breaker CB1.
6. Close the door and secure the latch.
7. Observe the UPS control panel becoming active, indicating logic power.
8. Press the **CONTROLS** pushbutton on the main menu bar. The System Status screen is displayed.
9. On the System Status screen, the UPS status should indicate **SHUTDOWN** and the UPM status should indicate **OFFLINE**.
10. Verify no alarms are active.
11. On the System Status screen, select the **UPM** command. The UPS Control Command screen is displayed.

12. On the UPS Control Command screen, select the UPM to start.
13. Press the **CONTROLS** pushbutton on the UPS Control Command menu bar. The UPM Control Command screen is displayed.
14. On the UPM Control Command screen, select **UPM ON**.
15. Press the **SELECT** pushbutton on the UPM Command menu bar.
16. Verify the following messages display sequentially on the UPM status line:

DC STARTING, CHARGER OFF  
 INVERTER STARTING  
 INVERTER SYNCING  
 READY

The UPM rectifier and inverter turn on.

17. To transfer the UPM to Normal mode, press the **CONTROLS** pushbutton on the UPS Control Command menu bar. The UPM Control Command screen is displayed.
18. On the UPM Control Command screen, select **UPM GO TO NORMAL**.
19. Press the **SELECT** pushbutton on the UPM Command menu bar.  
 The UPM transfers to Normal mode. The UPM status indicates **ONLINE**.

### 7.3.17 Transfer from Normal to Bypass Mode

To transfer the critical load to Bypass mode:



#### CAUTION

In Bypass mode, the critical load is not protected from commercial power interruptions and abnormalities.

1. Press the **CONTROLS** pushbutton on the main menu bar. The System Status screen is displayed.
2. On the System Status screen, select the **BYPASS** command.
3. Press the **CONTROLS** pushbutton on the System Status menu bar. The Bypass Control Command screen is displayed.
4. On the Bypass Control Command screen, select **GO TO BYPASS**.
5. Press the **SELECT** pushbutton on the Bypass Command menu bar.

The UPS transfers to Bypass mode and the critical load is immediately supplied by the bypass source. If the bypass source is not available, the power module remains on and an alarm sounds.

The **BYPASS** status indicator is illuminated. The Bypass status indicates **ON**. The UPM status indicates **READY**. The power module remains on.



#### WARNING

Power is present inside the UPS cabinet.



### 7.3.18 Transfer from Bypass to Normal Mode

To transfer the critical load to Normal mode:

1. If not already closed, close the battery breaker.
2. Press the **CONTROLS** pushbutton on the main menu bar. The System Status screen is displayed.
3. On the System Status screen, select the **UPS** command.
4. Press the **CONTROLS** pushbutton on the System Status menu bar. The UPS Control Command screen is displayed.
5. On the UPS Control Command screen, select **GO TO NORMAL**.
6. Press the **SELECT** pushbutton on the UPS Command menu bar.

The UPS transfers to Normal mode. If the power module is not available, the system remains on bypass and an alarm sounds.

The **NORMAL** status indicator is illuminated. The UPS status indicates **ONLINE**. The UPM status indicates **ONLINE**.

### 7.3.19 Transfer from Normal to Bypass Mode and Shut Down UPMs

To transfer the critical load to Bypass mode and shut down the UPMs:

1. Transfer the critical load to bypass by performing the procedure in paragraph 7.3.17.
2. Press the **CONTROLS** pushbutton on the main menu bar. The System Status screen is displayed.
3. On the System Status screen, select the **UPM** command. The UPS Control Command screen is displayed.
4. On the UPS Control Command screen, select the **UPM 1** command.
5. Press the **CONTROLS** pushbutton on the UPS Control Command menu bar. The UPM 1 Control Command screen is displayed.
6. On the UPM 1 Control Command screen, select **UPM OFF**.
7. Press the **SELECT** pushbutton on the UPM 1 Command menu bar.

The UPM status indicates **READY**. The input, output, and battery contactors open, and the power module remains on.

8. To turn off the power module, press the **CONTROLS** pushbutton on the UPS Control Command menu bar. The UPM 1 Control Command screen is displayed.
9. On the UPM 1 Control Command screen, select **UPM OFF**.
10. Press the **SELECT** pushbutton on the UPM 1 Command menu bar.

The UPM status indicates **SHUTDOWN**. The power module is turned off.

Logic power remains on.

11. Repeat Steps 4 through 10 selecting **UPM 2** to shut down UPM 2.

- Repeat Steps 4 through 10 selecting **UPM 3** to shut down UPM 3.




---

**NOTE** Step 13 is not applicable to the three UPM model.

---

- Repeat Steps 4 through 10 selecting **UPM 4** to shut down UPM 4.



### WARNING

Power is present inside the UPS cabinet.

---

#### 7.3.20 Single UPM Shutdown

To shutdown a single UPM:

- Press the **CONTROLS** pushbutton on the main menu bar. The System Status screen is displayed.
- On the System Status screen, select the **UPM** command. The UPS Control Command screen is displayed.
- On the UPS Control Command screen, select the UPM to shutdown.
- Press the **CONTROLS** pushbutton on the UPS Control Command menu bar. The UPM Control Command screen is displayed.
- On the UPM Control Command screen, select **UPM OFF**.
- Press the **SELECT** pushbutton on the UPM Command menu bar.

The UPM status indicates **READY**. The input, output, and battery contactors open, and the power module remains on. The remaining UPMs supply the critical load.

- To turn off the power module, press the **CONTROLS** pushbutton on the UPS Control Command menu bar. The UPM Control Command screen is displayed.
- On the UPM Control Command screen, select **UPM OFF**.
- Press the **SELECT** pushbutton on the UPM Command menu bar.

The UPM status indicates **SHUTDOWN**. The power module is turned off. The remaining UPMs continue to supply the critical load.

Logic power remains on.

#### 7.3.21 Single UPM Restart

To restart a single UPM from a shutdown state:

- Press the **CONTROLS** pushbutton on the main menu bar. The System Status screen is displayed.
- On the System Status screen, select the **UPM** command. The UPS Control Command screen is displayed.
- On the UPS Control Command screen, select the UPM to restart.
- Press the **CONTROLS** pushbutton on the UPS Control Command menu bar. The UPM Control Command screen is displayed.

5. On the UPM Control Command screen, select **UPM ON**.
6. Press the **SELECT** pushbutton on the UPM Command menu bar.
7. Verify the following messages display sequentially on the UPM status line:

DC STARTING, CHARGER OFF  
 INVERTER STARTING  
 INVERTER SYNCING  
 READY

The UPM rectifier and inverter turn on.

8. To transfer the UPM to Normal mode, press the **CONTROLS** pushbutton on the UPS Control Command menu bar. The UPM Control Command screen is displayed.
9. On the UPM Control Command screen, select **UPM GO TO NORMAL**.
10. Press the **SELECT** pushbutton on the UPM Command menu bar.

The UPM transfers to Normal mode. The UPM status indicates **ONLINE**.

### 7.3.22 UPS and Critical Load Shutdown

To perform maintenance or service on the critical load, shut down power to the load:

1. Turn off all equipment that is being powered by the UPS.
2. Perform the **LOAD OFF** procedure in paragraph 7.3.24.

The input, output, battery, and bypass backfeed contactors open, and the power module is turned off.



#### WARNING

Power is present inside the UPS cabinet until the upstream input feeder circuit breaker is opened.

3. If the UPS contains input breaker CB1, open the UPS input breaker CB1.
4. Open the UPS input and bypass feeder circuit breakers.

### 7.3.23 Charger Control

To turn the battery charger on:

1. Press the **CONTROLS** pushbutton on the main menu bar. The System Status screen is displayed.
2. On the System Status screen, select the **CHARGER** command.
3. Press the **CONTROLS** pushbutton on the System Status menu bar. The Charger Control Command screen is displayed.
4. On the Charger Control Command screen, select **CHARGER ON**.
5. Press the **SELECT** pushbutton on the Charger Command menu bar.

To turn the battery charger off:

1. Press the **CONTROLS** pushbutton on the main menu bar. The System Status screen is displayed.
2. On the System Status screen, select the **CHARGER** command.
3. Press the **CONTROLS** pushbutton on the System Status menu bar. The Charger Control Command screen is displayed.
4. On the Charger Control Command screen, select **CHARGER OFF**.
5. Press the **SELECT** pushbutton on the Charger Command menu bar.

### 7.3.24 Using the UPS LOAD OFF Pushbutton or Command

A UPS Load Off is initiated by the **LOAD OFF** pushbutton from the main menu bar, the Load Off command on the UPS Control Command screen, or the Load Off command on the Bypass Control Command screen. The **UPS LOAD OFF** controls the UPS output by powering down the UPS and de-energizing the critical load.

The UPS (including Bypass) remains off until restarted.

To use the **LOAD OFF** pushbutton:

1. Press the **LOAD OFF** pushbutton.

The Load Off screen is displayed, providing a choice to proceed or abort the shutdown.

#### CAUTION



All power to the critical load is lost when the **LOAD OFF** is selected in the following step. You should use this feature only when you want to de-energize the critical load.

2. To shut down the UPS, press **LOAD OFF** from the Load Off menu bar, and hold for three seconds. To abort the shutdown, press **CANCEL**.

When **LOAD OFF** is selected and held for three seconds, the input, output, battery, and bypass backfeed contactors open, and the power module is turned off.

#### CAUTION



Do not attempt to restart the system after Load Off until the cause of the shutdown has been identified and cleared.

3. To restart the UPS after pressing the **LOAD OFF** pushbutton, follow the procedure in paragraph 7.3.1 on page 7-12 or 7.3.8 on page 7-16.

#### WARNING



Power is present inside the UPS cabinet until the upstream input feeder circuit breaker is opened.

To use the **LOAD OFF** command:

1. Press the **CONTROLS** pushbutton on the main menu bar. The System Status screen is displayed.
2. On the System Status screen, select either the **UPS** or the **BYPASS** command.

3. Press the **CONTROLS** pushbutton on the System Status menu bar. The UPS or Bypass Control Command screen is displayed.
4. On the Control Command screen, select **LOAD OFF**.
5. Press the **SELECT** pushbutton on the Command menu bar.

The Load Off screen is displayed, providing a choice to proceed or abort the shutdown.

### CAUTION



All power to the critical load is lost when the **LOAD OFF** is selected in the following step. You should use this feature only when you want to de-energize the critical load.

6. To shut down the UPS, press **LOAD OFF** from the Load Off menu bar, and hold for three seconds. To abort the shutdown, press **CANCEL**.

When **LOAD OFF** is selected and held for three seconds, the input, output, battery, and bypass backfeed contactors open, and the power module is turned off.

### CAUTION



Do not attempt to restart the system after the Load Off until the cause of the shutdown has been identified and cleared.

7. To restart the UPS after pressing the **LOAD OFF** pushbutton, follow the procedure in paragraph 7.3.1 on page 7-12 or 7.3.8 on page 7-16.

### WARNING



Power is present inside the UPS cabinet until the upstream input feeder circuit breaker is opened.

### 7.3.25 Using the Remote Emergency Power-off Switch

A UPS emergency power-off is initiated by the REPO pushbutton switch. In an emergency, you can use this switch to control the UPS output. The REPO switch de-energizes the critical load and powers down the UPS immediately, without asking for verification.

The UPS, including Bypass, remains off until restarted.

#### CAUTION



All power to the critical load is lost when the REPO switch is activated in the following step. You should use this feature only when you want to de-energize the critical load.



**NOTE** The following instructions are for the Eaton-supplied REPO switch. If a customer-supplied REPO switch is used, it may not activate in the same manner; refer to the operating instructions provided with the switch.

To use the REPO switch:

1. Firmly push the red pushbutton until it locks into place. The switch latches into the activated state (see Figure 7-7).

The input, output, and bypass backfeed contactors open, the battery breaker or disconnect is tripped, and the power module is turned off immediately, without asking for verification.

#### CAUTION



Do not attempt to restart the system after the REPO until the cause of the shutdown has been identified and cleared.

2. To deactivate the REPO switch in preparation for restarting the UPS, insert the supplied key and rotate clockwise until the red pushbutton releases (see Figure 7-7). To remove the key, rotate the key back to the vertical position.
3. Restart the UPS by following the procedure in paragraph 7.3.1 on page 7-12 or 7.3.8 on page 7-16.

#### WARNING



Power is present inside the UPS cabinet until the upstream input feeder circuit breaker is opened.




Figure 7-7. REPO Operation

## 7.4 Multiple UPS Distributed Bypass Operation

The paragraphs in this section provide operating instructions for a UPS system containing multiple UPSs.

### 7.4.1 Starting the Distributed Bypass System in Normal Mode

To start the distributed bypass system:

1. Unfasten the front door latches and swing the doors open on all of the UPSs (see Figure 4-1 on page 4-2).
2. If the UPSs contain input breakers (CB1), verify that all input breakers are open.
3. Close all Module Output Breakers (MOBs).
4. Close all UPS input feeder circuit breakers.
5. Close all UPS Bypass input feeder circuit breakers.
6. If the UPSs contain input breakers (CB1), close all input breakers.
7. Close the doors and secure the latches.
8. Observe the UPS control panel displays becoming active, indicating logic power.
9. On any UPS, press the **CONTROLS** pushbutton on the main menu bar. The System Status screen is displayed.
10. On the System Status screen, verify the UPS status is **SHUTDOWN** and the UPM status is **SHUTDOWN**.
11. Close all battery breakers.
12. Verify no alarms are active.
13. On the System Status screen, select the **UPS** command.
14. Press the **CONTROLS** pushbutton on the System Status menu bar. The UPS Control Command screen is displayed.
15. On the UPS Control Command screen, select **GO TO NORMAL**.
16. Press the **SELECT** pushbutton on the UPS Command menu bar.

If Auto Bypass is enabled (factory default), the critical load is immediately supplied by the bypass source in Bypass mode from all UPSs, until the inverter turns on and the UPSs transfer to Normal mode. The status indicator on the UPS control panel indicates the UPS is in Bypass mode. If Auto Bypass is not enabled, the UPS outputs remain off until the UPSs transfer to Normal mode.

17. Verify the following messages display sequentially on the UPS status line:

DC STARTING, CHARGER OFF  
 INVERTER STARTING  
 INVERTER SYNCING  
 ONLINE, CHARGER ON

The rectifier and inverter turn on. The inverter continues to ramp up to full voltage.

Once the inverter reaches full voltage, all UPS output contactors (K3) close and the bypass circuits open. Power is now supplied to the critical load in Normal mode from all UPSs. It takes approximately one minute for the UPSs to achieve Normal mode.

The **NORMAL** status indicator is illuminated. The UPS status indicates **ONLINE**. The UPM status indicates **ONLINE, CHARGER ON**.

#### 7.4.2 Enable Energy Saver Mode from the UPS Command Menu

To enable Energy Saver mode:




---

**NOTE** The Energy Saver mode commands are displayed only if enabled at the factory or by an Eaton Customer Service Engineer.

**NOTE** Advanced Power Management and Energy Saver modes are mutually exclusive. If Advanced Power Management is enabled, Energy Saver commands will not be displayed.

---

1. Press the **CONTROLS** pushbutton on the main menu bar. The System Status screen is displayed.
2. On the System Status screen, select the UPS command.
3. Press the **CONTROLS** pushbutton on the System Status menu bar. The UPS Control Command screen is displayed.
4. On the UPS Control Command screen, select **ENABLE ENERGY SAVER**.
5. Press the **SELECT** pushbutton on the UPS Command menu bar.

The UPS transfers to Energy Saver mode.

The **NORMAL** status indicator is illuminated. The UPS status indicates **ONLINE WITH ESM**. The UPM status indicates **ONLINE**. If the battery is not charging, the power module is off.

#### 7.4.3 Disable Energy Saver Mode from the UPS Command Menu

To disable Energy Saver mode:




---

**NOTE** The Energy Saver mode commands are displayed only if enabled at the factory or by an Eaton Customer Service Engineer.

**NOTE** Advanced Power Management and Energy Saver modes are mutually exclusive. If Advanced Power Management is enabled, Energy Saver commands will not be displayed.

---

1. Press the **CONTROLS** pushbutton on the main menu bar. The System Status screen is displayed.
2. On the System Status screen, select the UPS command.



3. Press the **CONTROLS** pushbutton on the System Status menu bar. The UPS Control Command screen is displayed.
4. On the UPS Control Command screen, select **DISABLE ENERGY SAVER**.
5. Press the **SELECT** pushbutton on the UPS Command menu bar.

The UPS transfers to Battery mode and then to Normal mode.

The **NORMAL** status indicator is illuminated. The UPS status indicates **ONLINE**. The UPM status indicates **ONLINE**.

#### 7.4.4 Start Energy Saver High Alert Mode from the UPS Command Menu

To start High Alert mode:




---

**NOTE** *The High Alert mode commands are displayed only if enabled at the factory or by an Eaton Customer Service Engineer.*

**NOTE** *Advanced Power Management and Energy Saver modes are mutually exclusive. If Advanced Power Management is enabled, Energy Saver commands will not be displayed.*

---

1. Press the **CONTROLS** pushbutton on the main menu bar. The System Status screen is displayed.
2. On the System Status screen, select the **UPS** command.
3. Press the **CONTROLS** pushbutton on the System Status menu bar. The UPS Control Command screen is displayed.
4. On the UPS Control Command screen, select **START HIGH ALERT**.
5. Press the **SELECT** pushbutton on the UPS Command menu bar.

The UPS starts High Alert mode with the UPMs online supplying the critical load. After one hour the UPS transfers to Energy Saver mode.

The **NORMAL** status indicator is illuminated. The UPS status indicates **HIGH ALERT**. The UPM status indicates **ONLINE**. The power module is on.

#### 7.4.5 Enable Advanced Power Management Mode from the UPS Command Menu

To enable Advanced Power Management mode:




---

**NOTE** *The Advanced Power Management mode commands are displayed only if enabled at the factory or by an Eaton Customer Service Engineer.*

**NOTE** *Advanced Power Management and Energy Saver modes are mutually exclusive. If Energy Saver is enabled, Advanced Power Management commands will not be displayed.*

---

1. Press the **CONTROLS** pushbutton on the main menu bar. The System Status screen is displayed.
2. On the System Status screen, select the **UPS** command.
3. Press the **CONTROLS** pushbutton on the System Status menu bar. The UPS Control Command screen is displayed.
4. On the UPS Control Command screen, select **ENABLE ADV POWER MANAGEMENT**.

5. Press the **SELECT** pushbutton on the UPS Command menu bar.

The UPS transfers to Advanced Power Management mode. In approximately twenty seconds the UPS calculates the required number of UPMs needed to support the load.

The **NORMAL** status indicator is illuminated. The UPS status indicates **ONLINE + APM**. The UPM status indicates **ONLINE**.

#### 7.4.6 Disable Advanced Power Management Mode from the UPS Command Menu

To disable Advanced Power Management mode:




---

**NOTE** *The Advanced Power Management mode commands are displayed only if enabled at the factory or by an Eaton Customer Service Engineer.*

**NOTE** *Advanced Power Management and Energy Saver modes are mutually exclusive. If Energy Saver is enabled, Advanced Power Management commands will not be displayed.*

---

1. Press the **CONTROLS** pushbutton on the main menu bar. The System Status screen is displayed.
2. On the System Status screen, select the UPS command.
3. Press the **CONTROLS** pushbutton on the System Status menu bar. The UPS Control Command screen is displayed.
4. On the UPS Control Command screen, select **DISABLE ADV POWER MANAGEMENT**.
5. Press the **SELECT** pushbutton on the UPS Command menu bar.

The UPS transfers to Battery mode and then to Normal mode in approximately ten seconds.

The **NORMAL** status indicator is illuminated. The UPS status indicates **ONLINE**. The UPM status indicates **ONLINE**.

#### 7.4.7 Start Advanced Power Management High Alert Mode from the UPS Command Menu

To start High Alert mode:




---

**NOTE** *The High Alert mode commands are displayed only if enabled at the factory or by an Eaton Customer Service Engineer.*

**NOTE** *Advanced Power Management and Energy Saver modes are mutually exclusive. If Energy Saver is enabled, Advanced Power Management commands will not be displayed.*

---

1. Press the **CONTROLS** pushbutton on the main menu bar. The System Status screen is displayed.
2. On the System Status screen, select the UPS command.
3. Press the **CONTROLS** pushbutton on the System Status menu bar. The UPS Control Command screen is displayed.
4. On the UPS Control Command screen, select **START HIGH ALERT**.

5. Press the **SELECT** pushbutton on the UPS Command menu bar.

The UPS starts High Alert mode with the UPMs online supplying the critical load. After one hour the UPS transfers to Advanced Power Management mode.

The **NORMAL** status indicator is illuminated. The UPS status indicates **HIGH ALERT**. The UPM status indicates **ONLINE**. The power module is on.

### 7.4.8 Starting the Distributed Bypass System in Bypass Mode

If the inverter output of the distributed bypass system is not available and the critical load needs to be energized:



#### CAUTION

In Bypass mode, the critical load is not protected from commercial power interruptions and abnormalities.

1. Unfasten the front door latches and swing the doors open on all of the UPSs (see Figure 4-1 on page 4-2).
2. If the UPSs contain input breakers (CB1), verify that all input breakers are open.
3. Close all MOBs.
4. Close all UPS input feeder circuit breakers.
5. Close all UPS Bypass input feeder circuit breakers.
6. If the UPSs contain input breakers (CB1), close all input breakers.
7. Close the doors and secure the latches.
8. Observe the UPS control panel displays becoming active, indicating logic power.
9. On any UPS, press the **CONTROLS** pushbutton on the main menu bar. The System Status screen is displayed.
10. On the System Status screen, verify the UPS status is **SHUTDOWN** and the UPM status is **SHUTDOWN**.
11. On the System Status screen, select the **BYPASS** command.
12. Press the **CONTROLS** pushbutton on the System Status menu bar. The Bypass Control Command screen is displayed.
13. On the Bypass Control Command screen, select **GO TO BYPASS**.
14. Press the **SELECT** pushbutton on the Bypass Command menu bar.

The critical load is immediately supplied by the bypass source in Bypass mode from all UPSs.

The **BYPASS** status indicator is illuminated. The Bypass status indicates **ON**. The UPM status indicates **SHUTDOWN, CLOSE BATTERY**.

### 7.4.9 Enable Energy Saver Mode from the Bypass Command Menu

To enable Energy Saver mode:




---

**NOTE** The Energy Saver mode commands are displayed only if enabled at the factory or by an Eaton Customer Service Engineer.

**NOTE** Advanced Power Management and Energy Saver modes are mutually exclusive. If Advanced Power Management is enabled, Energy Saver commands will not be displayed.

---

1. Press the **CONTROLS** pushbutton on the main menu bar. The System Status screen is displayed.
2. On the System Status screen, select the **BYPASS** command.
3. Press the **CONTROLS** pushbutton on the System Status menu bar. The Bypass Control Command screen is displayed.
4. On the Bypass Control Command screen, select **ENABLE ENERGY SAVER**.
5. Press the **SELECT** pushbutton on the Bypass Command menu bar.

If the UPS is online, the UPS transfers to Energy Saver mode.

The **NORMAL** status indicator is illuminated. The UPS status indicates **ONLINE WITH ESM**. The UPM status indicates **ONLINE**. If the battery is not charging, the power module is off.

### 7.4.10 Disable Energy Saver Mode from the Bypass Command Menu

To disable Energy Saver mode:




---

**NOTE** The Energy Saver mode commands are displayed only if enabled at the factory or by an Eaton Customer Service Engineer.

**NOTE** Advanced Power Management and Energy Saver modes are mutually exclusive. If Advanced Power Management is enabled, Energy Saver commands will not be displayed.

---

1. Press the **CONTROLS** pushbutton on the main menu bar. The System Status screen is displayed.
2. On the System Status screen, select the **BYPASS** command.
3. Press the **CONTROLS** pushbutton on the System Status menu bar. The Bypass Control Command screen is displayed.
4. On the Bypass Control Command screen, select **DISABLE ENERGY SAVER**.
5. Press the **SELECT** pushbutton on the Bypass Command menu bar.

If the UPS is online, the UPS transfers to Battery mode and then to Normal mode.

The **NORMAL** status indicator is illuminated. The UPS status indicates **ONLINE**. The UPM status indicates **ONLINE**.

### 7.4.11 Start Energy Saver High Alert Mode from the Bypass Command Menu

To start High Alert mode:



**NOTE** The High Alert mode commands are displayed only if enabled at the factory or by an Eaton Customer Service Engineer.

**NOTE** Advanced Power Management and Energy Saver modes are mutually exclusive. If Advanced Power Management is enabled, Energy Saver commands will not be displayed.

1. Press the **CONTROLS** pushbutton on the main menu bar. The System Status screen is displayed.
2. On the System Status screen, select the **BYPASS** command.
3. Press the **CONTROLS** pushbutton on the System Status menu bar. The Bypass Control Command screen is displayed.
4. On the Bypass Control Command screen, select **START HIGH ALERT**.
5. Press the **SELECT** pushbutton on the Bypass Command menu bar.

If the UPS is online, the UPS starts High Alert mode with the UPMs online supplying the critical load. After one hour the UPS transfers to Energy Saver mode.

The **NORMAL** status indicator is illuminated. The UPS status indicates **HIGH ALERT**. The UPM status indicates **ONLINE**. The power module is on.

### 7.4.12 Enable Advanced Power Management Mode from the Bypass Command Menu

To enable Advanced Power Management mode:



**NOTE** The Advanced Power Management mode commands are displayed only if enabled at the factory or by an Eaton Customer Service Engineer.

**NOTE** Advanced Power Management and Energy Saver modes are mutually exclusive. If Energy Saver is enabled, Advanced Power Management commands will not be displayed.

1. Press the **CONTROLS** pushbutton on the main menu bar. The System Status screen is displayed.
2. On the System Status screen, select the **BYPASS** command.
3. Press the **CONTROLS** pushbutton on the System Status menu bar. The Bypass Control Command screen is displayed.
4. On the Bypass Control Command screen, select **ENABLE ADV POWER MANAGEMENT**.
5. Press the **SELECT** pushbutton on the Bypass Command menu bar.

If the UPS is online, the UPS transfers to Advanced Power Management mode. In approximately twenty seconds the UPS calculates the required number of UPMs needed to support the load.

The **NORMAL** status indicator is illuminated. The UPS status indicates **ONLINE + APM**. The UPM status indicates **ONLINE**.

### 7.4.13 Disable Advanced Power Management Mode from the Bypass Command Menu

To disable Advanced Power Management mode:



**NOTE** The Advanced Power Management mode commands are displayed only if enabled at the factory or by an Eaton Customer Service Engineer.

**NOTE** Advanced Power Management and Energy Saver modes are mutually exclusive. If Energy Saver is enabled, Advanced Power Management commands will not be displayed.

1. Press the **CONTROLS** pushbutton on the main menu bar. The System Status screen is displayed.
2. On the System Status screen, select the **BYPASS** command.
3. Press the **CONTROLS** pushbutton on the System Status menu bar. The Bypass Control Command screen is displayed.
4. On the Bypass Control Command screen, select **DISABLE ADV POWER MANAGEMENT**.
5. Press the **SELECT** pushbutton on the Bypass Command menu bar.

If the UPS is online, the UPS transfers to Battery mode and then to Normal mode in approximately ten seconds.

The **NORMAL** status indicator is illuminated. The UPS status indicates **ONLINE**. The UPM status indicates **ONLINE**.

### 7.4.14 Start Advanced Power Management High Alert Mode from the Bypass Command Menu

To start High Alert mode:



**NOTE** The High Alert mode commands are displayed only if enabled at the factory or by an Eaton Customer Service Engineer.

**NOTE** Advanced Power Management and Energy Saver modes are mutually exclusive. If Energy Saver is enabled, Advanced Power Management commands will not be displayed.

1. Press the **CONTROLS** pushbutton on the main menu bar. The System Status screen is displayed.
2. On the System Status screen, select the **BYPASS** command.
3. Press the **CONTROLS** pushbutton on the System Status menu bar. The Bypass Control Command screen is displayed.
4. On the Bypass Control Command screen, select **START HIGH ALERT**.
5. Press the **SELECT** pushbutton on the Bypass Command menu bar.

If the UPS is online, the UPS starts High Alert mode with the UPMs online supplying the critical load. After one hour the UPS transfers to Advanced Power Management mode.

The **NORMAL** status indicator is illuminated. The UPS status indicates **HIGH ALERT**. The UPM status indicates **ONLINE**. The power module is on.

### 7.4.15 Starting the UPS UPMs

To start the power modules without transferring the critical load to Normal mode:

1. Unfasten the front door latches and swing the doors open on all of the UPSs (see Figure 4-1 on page 4-2).
2. If the UPSs contain input breakers (CB1), verify that all input breakers are open.
3. Close all UPS input feeder circuit breakers.
4. Close all UPS Bypass input feeder circuit breakers.
5. If the UPSs contain input breakers (CB1), close all input breakers.
6. Close the doors and secure the latches.
7. Observe the UPS control panel displays becoming active, indicating logic power.
8. On any UPS, press the **CONTROLS** pushbutton on the main menu bar. The System Status screen is displayed.
9. On the System Status screen, verify the UPS status is **SHUTDOWN** and the UPM status is **OFFLINE**.
10. Verify no alarms are active.
11. On the System Status screen, select the **UPM** command. The UPS Control Command screen is displayed.
12. On the UPS Control Command screen, select the **UPM 1** command.
13. Press the **CONTROLS** pushbutton on the UPS Control Command menu bar. The UPM 1 Control Command screen is displayed.
14. On the UPM 1 Control Command screen, select **UPM 0N**.
15. Press the **SELECT** pushbutton on the UPM 1 Command menu bar.
16. Verify the following messages display sequentially on the UPM status line:

```
DC STARTING, CHARGER OFF
INVERTER STARTING
INVERTER SYNCING
READY
```

The UPM 1 rectifier and inverter turn on.

If the Inherent Redundancy option is enabled, a loss of redundancy alarm will be issued. Silence the alarm and continue to Step 17.

17. Repeat Steps 12 through 15 selecting **UPM 2** to start UPM 2.
18. Verify the following messages display sequentially on the UPM status line:

```
DC STARTING, CHARGER OFF
INVERTER STARTING
INVERTER SYNCING
READY
```

The UPM 2 rectifier and inverter turn on.

19. Repeat Steps 12 through 15 selecting UPM 3 to start UPM 3.
20. Verify the following messages display sequentially on the UPM status line:

DC STARTING, CHARGER OFF  
 INVERTER STARTING  
 INVERTER SYNCING  
 READY

The UPM 3 rectifier and inverter turn on.




---

**NOTE** Steps 21 and 22 are not applicable to the three UPM model.

---

21. Repeat Steps 12 through 15 selecting UPM 4 to start UPM 4.
22. Verify the following messages display sequentially on the UPM status line:

DC STARTING, CHARGER OFF  
 INVERTER STARTING  
 INVERTER SYNCING  
 READY

The UPM 4 rectifier and inverter turn on. When the inverter reaches full voltage, the UPS is ready to transfer to Normal mode and supply the critical load.

23. Repeat Steps 1 through 22 for each UPS in the distributed bypass system.




---

**NOTE** To transfer to Normal mode after starting individual UPMs, follow the procedure in paragraph 7.4.18.

---

#### 7.4.16 Starting a Single UPM

To start a single UPM:

1. Unfasten the front door latch and swing the door open (see Figure 4-1 on page 4-2).
2. If the UPS contains input breaker CB1, verify that input breaker CB1 is open.
3. Close the UPS input feeder circuit breaker.
4. Close the UPS Bypass input feeder circuit breaker.
5. If the UPS contains input breaker CB1, close input breaker CB1.
6. Close the door and secure the latch.
7. Observe the UPS control panel becoming active, indicating logic power.
8. Press the **CONTROLS** pushbutton on the main menu bar. The System Status screen is displayed.
9. On the System Status screen, the UPS status should indicate **SHUTDOWN** and the UPM status should indicate **OFFLINE**.
10. Verify no alarms are active.
11. On the System Status screen, select the UPM command. The UPS Control Command screen is displayed.



12. On the UPS Control Command screen, select the UPM to start.
13. Press the **CONTROLS** pushbutton on the UPS Control Command menu bar. The UPM Control Command screen is displayed.
14. On the UPM Control Command screen, select **UPM ON**.
15. Press the **SELECT** pushbutton on the UPM Command menu bar.
16. Verify the following messages display sequentially on the UPM status line:

DC STARTING, CHARGER OFF  
 INVERTER STARTING  
 INVERTER SYNCING  
 READY

The UPM rectifier and inverter turn on.

17. To transfer the UPM to Normal mode, press the **CONTROLS** pushbutton on the UPS Control Command menu bar. The UPM Control Command screen is displayed.
18. On the UPM Control Command screen, select **UPM GO TO NORMAL**.
19. Press the **SELECT** pushbutton on the UPM Command menu bar.  
 The UPM transfers to Normal mode. The UPM status indicates **ONLINE**.

#### 7.4.17 Transfer from Normal to Bypass Mode

To transfer the critical load to Bypass mode:



#### CAUTION

In Bypass mode, the critical load is not protected from commercial power interruptions and abnormalities.

1. On any UPS, press the **CONTROLS** pushbutton on the main menu bar. The System Status screen is displayed.
2. On the System Status screen, select the **BYPASS** command.
3. Press the **CONTROLS** pushbutton on the System Status menu bar. The Bypass Control Command screen is displayed.
4. On the Bypass Control Command screen, select **GO TO BYPASS**.
5. Press the **SELECT** pushbutton on the Bypass Command menu bar.

All of the UPSs transfer to Bypass mode and the critical load is immediately supplied by the bypass source. If the bypass source is not available, the power module remains on and an alarm sounds.

The **BYPASS** status indicator is illuminated. The Bypass status indicates **ON**. The UPM status indicates **READY**. The power module remains on.



#### WARNING

Power is present inside the UPS cabinet.

### 7.4.18 Transfer from Bypass to Normal Mode

To transfer the critical load to Normal mode:

1. If not already closed, close the battery breaker.
2. On any UPS, press the **CONTROLS** pushbutton on the main menu bar. The System Status screen is displayed.
3. On the System Status screen, select the **UPS** command.
4. Press the **CONTROLS** pushbutton on the System Status menu bar. The UPS Control Command screen is displayed.
5. On the UPS Control Command screen, select **GO TO NORMAL**.
6. Press the **SELECT** pushbutton on the UPS Command menu bar.

All of the UPSs transfer to Normal mode. If the power module is not available, the system remains on bypass and an alarm sounds.

The **NORMAL** status indicator is illuminated. The UPS status indicates **ONLINE**. The UPM status indicates **ONLINE**.

### 7.4.19 Transfer from Normal to Bypass Mode and Shut Down UPMs

To transfer the critical load to Bypass mode and shut down all UPMs:

1. Transfer the critical load to bypass by performing the procedure in paragraph 7.4.17.
2. Press the **CONTROLS** pushbutton on the main menu bar. The System Status screen is displayed.
3. On the System Status screen, select the **UPM** command. The UPS Control Command screen is displayed.
4. On the UPS Control Command screen, select the **UPM 1** command.
5. Press the **CONTROLS** pushbutton on the UPS Control Command menu bar. The UPM 1 Control Command screen is displayed.
6. On the UPM 1 Control Command screen, select **UPM OFF**.
7. Press the **SELECT** pushbutton on the UPM 1 Command menu bar.

The UPM status indicates **READY**. The input, output, and battery contactors open, and the power module remains on.

8. To turn off the power module, press the **CONTROLS** pushbutton on the UPS Control Command menu bar. The UPM 1 Control Command screen is displayed.
9. On the UPM 1 Control Command screen, select **UPM OFF**.
10. Press the **SELECT** pushbutton on the UPM 1 Command menu bar.

The UPM status indicates **SHUTDOWN**. The power module is turned off.

Logic power remains on.

11. Repeat Steps 4 through 10 selecting **UPM 2** to shut down UPM 2.
12. Repeat Steps 4 through 10 selecting **UPM 3** to shut down UPM 3.




---

**NOTE** Step 13 is not applicable to the three UPM model.

---

13. Repeat Steps 4 through 10 selecting **UPM 4** to shut down UPM 4.
14. Repeat Steps 2 through 13 for each UPS in the distributed bypass system.



## WARNING

Power is present inside the UPS cabinet.

---

### 7.4.20 Single UPM Shutdown

To shut down a single UPM:

1. Press the **CONTROLS** pushbutton on the main menu bar. The System Status screen is displayed.
2. On the System Status screen, select the **UPM Command**. The UPS Control Command screen is displayed.
3. On the UPS Control Command screen, select the UPM to shutdown.
4. Press the **CONTROLS** pushbutton on the UPS Control Command menu bar. The UPM Control Command screen is displayed.
5. On the UPM Control Command screen, select **UPM OFF**.
6. Press the **SELECT** pushbutton on the UPM Command menu bar.

The UPM status indicates **READY**. The input, output, and battery contactors open, and the power module remains on. The remaining UPMs supply the critical load.

7. To turn off the power module, press the **CONTROLS** pushbutton on the UPS Control Command menu bar. The UPM Control Command screen is displayed.
8. On the UPM Control Command screen, select **UPM OFF**.
9. Press the **SELECT** pushbutton on the UPM Command menu bar.

The UPM status indicates **SHUTDOWN**. The power module is turned off. The remaining UPMs continue to supply the critical load.

Logic power remains on.

### 7.4.21 Single UPM Restart

To restart a single UPM from a shutdown state:

1. Press the **CONTROLS** pushbutton on the main menu bar. The System Status screen is displayed.
2. On the System Status screen, select the **UPM** command. The UPS Control Command screen is displayed.

3. On the UPS Control Command screen, select the UPM to restart.
4. Press the **CONTROLS** pushbutton on the UPS Control Command menu bar. The UPM Control Command screen is displayed.
5. On the UPM Control Command screen, select **UPM ON**.
6. Press the **SELECT** pushbutton on the UPM Command menu bar.
7. Verify the following messages display sequentially on the UPM status line:

DC STARTING, CHARGER OFF  
 INVERTER STARTING  
 INVERTER SYNCING  
 READY

The UPM rectifier and inverter turn on.

8. To transfer the UPM to Normal mode, press the **CONTROLS** pushbutton on the UPS Control Command menu bar. The UPM Control Command screen is displayed.
9. On the UPM Control Command screen, select **UPM GO TO NORMAL**.
10. Press the **SELECT** pushbutton on the UPM Command menu bar.

The UPM transfers to Normal mode. The UPM status indicates **ONLINE**.

#### 7.4.22 Single UPS Shutdown using Load Off




---

**NOTE** To shut down a single UPS, MOBs with dual auxiliary contacts must be installed and connected according to the procedure in paragraph 5.2 on page 5-4.

---

To shut down a single UPS:

1. Open the MOB for the UPS being shut down.
2. On the UPS to shut down, press the **CONTROLS** pushbutton on the main menu bar. The System Status screen is displayed.
3. On the System Status screen, select the **BYPASS** command.
4. Press the **CONTROLS** pushbutton on the System Status menu bar. The Bypass Control Command screen is displayed.
5. On the Bypass Control Command screen, select **GO TO BYPASS**.
6. Press the **SELECT** pushbutton on the Bypass Command menu bar.

The UPS being shut down transfers to Bypass mode.

The **BYPASS** status indicator is illuminated. The Bypass status indicates **ON**. The UPM status indicates **READY**. The power module remains on.




---

**NOTE** Load Off will turn off only the UPS being shut down. The remaining UPSs will remain online supplying power to the critical load.

---

7. Perform the LOAD OFF procedure in paragraph 7.4.27 on the UPS being shut down.

The input, output, battery, and bypass backfeed contactors open, and the power module is turned off on the UPS being shut down.

Logic power remains on.

8. Verify the battery breaker or disconnect for the UPS being shut down is open. If not, open the breaker.



### WARNING

Power is present inside the UPS cabinet until the upstream input feeder circuit breaker is opened.



**NOTE** If the UPS contains an input breaker (CB1), DO NOT open the breaker unless no input feeder breaker is installed.

9. Open the input and bypass feeder circuit breakers for the UPS being shut down.

The UPS is now completely shut down.

External Communications Failure alarm is active on remaining online UPSs. This is an expected event and will clear upon UPS restart.

#### 7.4.23 Single UPS Shutdown using UPM Shutdown



**NOTE** To shut down a single UPS, MOBs with dual auxiliary contacts must be installed and connected according to the procedure in paragraph 5.2 on page 5-4.

To shut down a single UPS:

1. Open the MOB for the UPS being shut down.
2. On the UPS being shut down, press the **CONTROLS** pushbutton on the main menu bar. The System Status screen is displayed.
3. On the System Status screen, select the **BYPASS** command.
4. Press the **CONTROLS** pushbutton on the System Status menu bar. The Bypass Control Command screen is displayed.
5. On the Bypass Control Command screen, select **GO TO BYPASS**.
6. Press the **SELECT** pushbutton on the Bypass Command menu bar.

The UPS being shut down transfers to Bypass mode.

The **BYPASS** status indicator is illuminated. The Bypass status indicates **ON**. The UPM status indicates **READY**. The power module remains on.

7. On the System Status screen, select the **UPM** command. The UPS Control Command screen is displayed.
8. On the UPS Control Command screen, select the **UPM 1** command.
9. Press the **CONTROLS** pushbutton on the UPS Control Command menu bar.
10. On the UPM 1 Control Command screen, select **UPM OFF**.

11. Press the **SELECT** pushbutton on the UPM 1 Command menu bar.

The UPM status indicates **SHUTDOWN**. The input, output, and battery contactors open, and the power module is turned off. The remaining UPMs supply the critical load.

Logic power remains on.

12. Repeat Steps 8 through 11 selecting **UPM 2** to shut down UPM 2.

13. Repeat Steps 8 through 11 selecting **UPM 3** to shut down UPM 3.




---

**NOTE** Step 14 is not applicable to the three UPM model.

---

14. Repeat Steps 8 through 11 selecting **UPM 4** to shut down UPM 4.

15. Verify the battery breaker or disconnect for the UPS being shut down is open. If not, open the breaker.



### WARNING

Power is present inside the UPS cabinet until the upstream input feeder circuit breaker is opened.

---




---

**NOTE** If the UPS contains an input breaker (CB1), **DO NOT** open the breaker unless no input feeder breaker is installed.

---

16. Open the input and bypass feeder circuit breakers for the UPS being shut down.

The UPS is now completely shut down.

External Communications Failure alarm is active on remaining online UPSs. This is an expected event and will clear upon UPS restart.

#### 7.4.24 Single UPS Restart

To restart a single UPS from a shutdown state:

1. Close the MOB for the UPS being restarted.
2. Close UPS input and bypass feeder circuit breakers for the UPS being restarted.
3. Unfasten the front door latch and swing the door open on the UPS being restarted (see Figure 4-1 on page 4-2).
4. If input breaker (CB1) is installed on the UPS being restarted and is open, close the breaker.
5. Close the door and secure the latch.
6. On the UPS being restarted, observe the UPS control panel display becoming active, indicating logic power.
7. On the UPS being restarted, press the **CONTROLS** pushbutton on the main menu bar. The System Status screen is displayed.
8. On the System Status screen, verify the UPS status is **SHUTDOWN** and the UPM status is **SHUTDOWN**.
9. Close the battery breaker for the UPS being restarted.

10. Verify no alarms are active on UPS being restarted.
11. Verify the External Communications Failure alarm has cleared and no other alarms are active on the online UPSs.
12. On the System Status screen, select the UPS command.
13. Press the **CONTROLS** pushbutton on the System Status menu bar. The UPS Control Command screen is displayed.
14. On the UPS Control Command screen, select **GO TO NORMAL**.
15. Press the **SELECT** pushbutton on the UPS Command menu bar.



**NOTE** If the UPS is starting on a bus with other online paralleled UPSs, the UPS will not go to bypass during startup. The UPS will start, sync to the other UPSs online, and go online.

16. Verify the following messages display sequentially on the UPS status line:

DC STARTING, CHARGER OFF  
 INVERTER STARTING  
 INVERTER SYNCING  
 ONLINE, CHARGER ON

The rectifier and inverter turn on. The inverter continues to ramp to full voltage.

Once the inverter reaches full voltage, the UPS output contactor (K3) closes. Power is now supplied to the critical load in Normal mode along with the other UPSs online. It takes approximately one minute for the UPS to achieve Normal mode.

The **NORMAL** status indicator is illuminated. The UPS status indicates **ONLINE**. The UPM status indicates **ONLINE, CHARGER ON**.

#### 7.4.25 UPS and Critical Load Shutdown

To perform maintenance or service on the critical load, shut down power to the load:

1. Turn off all equipment that is being powered by the distributed bypass system.
2. Transfer the UPSs to bypass by performing the procedure in paragraph 7.4.17.
3. Perform the **LOAD OFF** procedure in paragraph 7.4.27.

The input, output, battery, and bypass backfeed contactors open, and the power module is turned off.



#### WARNING

Power is present inside the UPS cabinet until the upstream input feeder circuit breaker is opened.

4. If the UPSs contain input breakers (CB1), open all UPS input breakers.
5. Open the input and bypass feeder circuit breakers on all UPSs.

### 7.4.26 Charger Control

To turn the battery charger on:

1. Press the **CONTROLS** pushbutton on the main menu bar. The System Status screen is displayed.
2. On the System Status screen, select the **CHARGER** command.
3. Press the **CONTROLS** pushbutton on the System Status menu bar. The Charger Control Command screen is displayed.
4. On the Charger Control Command screen, select **CHARGER ON**.
5. Press the **SELECT** pushbutton on the Charger Command menu bar.

To turn the battery charger off:

1. Press the **CONTROLS** pushbutton on the main menu bar. The System Status screen is displayed.
2. On the System Status screen, select the **CHARGER** command.
3. Press the **CONTROLS** pushbutton on the System Status menu bar. The Charger Control Command screen is displayed.
4. On the Charger Control Command screen, select **CHARGER OFF**.
5. Press the **SELECT** pushbutton on the Charger Command menu bar.

### 7.4.27 Using the UPS LOAD OFF Pushbutton or Command

A UPS Load Off is initiated by the **LOAD OFF** pushbutton from the main menu bar, the Load Off command on the UPS Control Command screen, or the Load Off command on the Bypass Control Command screen. The UPS **LOAD OFF** controls the UPSs' outputs by powering down the UPS and de-energizing the critical load.

The UPSs (including Bypass) remain off until restarted.




---

**NOTE** *The UPS Load Off controls each UPS independently and does not shut down the whole distributed bypass system unless all UPSs have been transferred to bypass. To immediately shut down the whole system, use the REPO switch (see paragraph 7.4.28).*

---

To use the **LOAD OFF** pushbutton:

1. Press the **LOAD OFF** pushbutton on the UPS to shut down.

The Load Off screen is displayed, providing a choice to proceed or abort the shutdown.



#### CAUTION

---

All power to the critical load is lost when the **LOAD OFF** is selected in the following step. You should use this feature only when you want to de-energize the critical load.

---

2. To shut down the UPS, press **LOAD OFF** from the Load Off menu bar, and hold for three seconds. To abort the shutdown, press **CANCEL**.

When **LOAD OFF** is selected and held for three seconds, the input, output, battery, and bypass backfeed contactors open, and the power module is turned off on the UPS.



3. If another UPS is to be shut down, proceed to that UPS and repeat Steps 1 and 2.

### CAUTION



Do not attempt to restart the system after Load Off until the cause of the shutdown has been identified and cleared.

4. Restart the UPS after pressing the **LOAD OFF** pushbutton by following the procedure in paragraph 7.4.1 on page 7-29 or 7.4.8 on page 7-33.

### WARNING



Power is present inside the UPS cabinet until the upstream input feeder circuit breaker is opened.

To use the **LOAD OFF** command:

1. Press the **CONTROLS** pushbutton on the main menu bar of the UPS to be shut down. The System Status screen is displayed.
2. On the System Status screen, select either the **UPS** or the **BYPASS** command.
3. Press the **CONTROLS** pushbutton on the System Status menu bar. The UPS or Bypass Control Command screen is displayed.
4. On the Control Command screen, select **LOAD OFF**.
5. Press the **SELECT** pushbutton on the Command menu bar.

The Load Off screen is displayed, providing a choice to proceed or abort the shutdown.

### CAUTION



All power to the critical load is lost when **LOAD OFF** is selected in the following step. You should use this feature only when you want to de-energize the critical load.

6. To shut down the UPS, press **LOAD OFF** from the Load Off menu bar, and hold for three seconds. To abort the shutdown, press **CANCEL**.

When **LOAD OFF** is selected and held for three seconds, the input, output, battery, and bypass backfeed contactors open, and the power module is turned off on the UPS.

7. If another UPS is to be shut down, proceed to that UPS and repeat Steps 1 through 6.

### CAUTION



Do not attempt to restart the system after the Load Off until the cause of the shutdown has been identified and cleared.

8. Restart the UPS after pressing the **LOAD OFF** pushbutton by following the procedure in paragraph 7.4.1 on page 7-29 or 7.4.8 on page 7-33.

### WARNING



Power is present inside the UPS cabinet until the upstream input feeder circuit breaker is opened.

### 7.4.28 Using the Remote Emergency Power-off Switch

A UPS emergency power-off is initiated by the REPO pushbutton switch. In an emergency, you can use this switch to control the UPS output. The REPO switch de-energizes the critical load and powers down the UPSs immediately, without asking for verification.

The UPS, including Bypass, remains off until restarted.

#### CAUTION



All power to the critical load is lost when the REPO switch is activated in the following step. You should use this feature only when you want to de-energize the critical load.



**NOTE** *The following instructions are for the Eaton-supplied REPO switch. If a customer-supplied REPO switch is used, it may not activate in the same manner; refer to the operating instructions provided with the switch.*

To use the REPO switch:

1. Firmly push the red pushbutton until it locks into place. The switch latches into the activated state (see Figure 7-7).

The input, output, and bypass backfeed contactors open, the battery breaker or disconnect is tripped, and the power module is turned off immediately, without asking for verification on all UPSs.

#### CAUTION



Do not attempt to restart the system after the REPO until the cause of the shutdown has been identified and cleared.

2. To deactivate the REPO switch in preparation for restarting the UPS, insert the supplied key and rotate clockwise until the red pushbutton releases (see Figure 7-7). To remove the key, rotate the key back to the vertical position.
3. Restart the UPSs by following the procedure in paragraph 7.4.1 on page 7-29 or 7.4.8 on page 7-33.

#### WARNING



Power is present inside the UPS cabinet until the upstream input feeder circuit breaker is opened.

This chapter describes the communication features of the Eaton 9395 UPS and provides information about connecting hardware and using Terminal mode. For terminal wiring information, see paragraph 3.2.3 on page 3-21 and paragraph 4.9 on page 4-27. For location of the customer interface panels and terminals, see Figure 4-16 on page 4-19 and Figure 4-22 through Figure 4-25 starting on page 4-28.

### 8.1 X-Slot Cards

The Eaton 9395 UPS has four standard, factory-installed X-Slot communication bays. See Figure 4-22 on page 4-28 for bay locations. The UPS is compatible with the following X-Slot cards (see Figure 8-1):

- Modbus Card – provides direct integration of UPS information (meters and status) to a Building Management System (BMS) using the Modbus RTU protocol.
- ConnectUPS-X Web/SNMP Card – provides remote monitoring through a Web browser interface, e-mail, and a network management system (NMS) using SNMP; connects to a twisted-pair Ethernet (10/100BaseT) network. It has a built-in switching hub that allows three additional network devices to be connected to the network without the requirement of additional network drops.



---


**NOTE** *The Modem Card cannot be installed in X-Slot 2.*

---

- Modem Card – provides “out-of-band” remote notification and monitoring using modem communication directly to cell phones and pagers.
- Relay Interface Card (AS/400) – has isolated dry contact (Form-C) relay outputs for UPS status: Utility failure, Low battery, UPS alarm/OK, or On bypass when interfacing with IBM AS/400 computers, other relay connected computers, and industrial applications.
- Industrial Relay Card (IRC) – indicates the operating status of the UPS system using the customer’s monitoring equipment. The IRC uses four isolated normally-open or normally-closed dry relay contacts to indicate the UPS status. Normal, Bypass, Battery, and Alarm modes can be monitored.
- Powerware Hot Sync CAN Bridge Card – provides connectivity for operational mode control and metering of a parallel system at any UPM in the system. In addition, this card can be used to connect optional system monitoring devices, such as a Remote Monitor Panel II (RMP II), a Relay Interface Module II (RIM II), or a Supervisory Contact Module II (SCM II) to the UPS.
- Power Xpert® Gateway Card – provides a data gateway from the UPS to the Power Xpert software; provides remote monitoring through a Web browser interface, e-mail, and a network management system using SNMP; connects to a twisted-pair Ethernet (10/100BaseT) network. Modbus TCP support provides direct integration of the PDU’s parameters to a Building Management System (BMS). It has a built-in switching hub that allows one additional network device to be connected to the network without the requirement of an additional network drop.

LAN and telephone drops for use with X-Slot connectivity cards must be provided by facility planners or the customer.

For installation and setup of an X-Slot card, contact an Eaton service representative (see page 1-10). Refer to the manual supplied with the X-Slot card for user instructions.



**Figure 8-1. Optional X-Slot Cards**

## 8.2 eNotify Service

The Eaton 9395 UPS supports Eaton's eNotify Service. eNotify Service is included at no charge during the first year of operation (warranty period), and also with the purchase of an Eaton PowerTrust Support Agreement after the initial warranty expires. eNotify and support agreement availability or specific features may vary by market; for more information, refer to: [www.eaton.com/enotify/](http://www.eaton.com/enotify/).

### 8.2.1 eNotify Service Features

The eNotify Service provides proactive monitoring and a monthly report detailing the ongoing health of your Eaton 9395 UPS:

- Proactive monitoring, called Anomaly Detection, automatically analyzes the status of the Eaton 9395 UPS on a daily basis. All data gathered from the unit, current and historical, is analyzed at the Customer Reliability Center (CRC) for trending issues. A set of factors, or rules, compared against your UPS's data can indicate a potential impending failure and trigger an appropriate anomaly notification to a CRC Analyst. Critical events are checked for additional anomalies. Through this service, the CRC can take pre-emptive, corrective action to ensure the highest level of availability of your Eaton 9395 UPS.
- The Customer Monitoring Report delivers information about Eaton's analysis of your Eaton 9395 UPS on a monthly basis. Depending on the model, the report provides detailed information about voltages, loads, external factors such as temperature and humidity, the attached batteries, and system availability. All of these factors contribute to the Relative Health Index (RHI) score that allows you to compare your unit's health relative to Eaton's optimum UPS operating levels.

### 8.2.2 Installing eNotify Service

A quick start guide and self-installation wizard tool are available on both the Software Suite CD included with the Eaton 9395 UPS documentation and on the Web at: [www.eaton.com/enotify/](http://www.eaton.com/enotify/). For the latest updates, installation tips, and information on connecting eNotify, visit the eNotify Web page. For installation support or questions about the eNotify Service, contact [crctriagegroup@eaton.com](mailto:crctriagegroup@eaton.com).

The eNotify Service relies on a ConnectUPS-X Web/SNMP Card (or Power Xpert card) installed with the UPS sending one-way status and event e-mails to Eaton Remote Monitoring servers that analyze and store the data. Those servers also take the appropriate actions of sending notifications and reports. The ConnectUPS Card gathers information from the UPS directly and from any external sensors that are attached. The card also records all events that are generated by the UPS. This data is stored within the non-volatile memory logs on the ConnectUPS Card.

The eNotify Service runs on common protocols and transport mechanisms, making the connectivity between the Eaton 9395 UPS and the Eaton Remote Monitoring servers easy to set up. By using common e-mail transport mechanism, you do not have to open your network to proprietary or potentially unsecure protocols and transports.

### 8.3 Eaton LanSafe Power Management Software

Each Eaton 9395 UPS ships with LanSafe Power Management Software. To install the Eaton LanSafe software, see the instructions accompanying the Software Suite CD.

Eaton LanSafe software uses an RS-232 serial link to communicate with the UPS. The software provides up-to-date graphics of UPS power and system data and power flow, a complete record of critical power events, and notification of important UPS or power information. With custom views for monitoring status and metering information, various user groups can select the most useful view for their specific needs.

### 8.4 Remote Notification

For connection and setup of a modem, or to enable Remote Notify and Call Home features within the UPS, contact an Eaton service representative (see page 1-10).

Remote Notification allows the UPS to use a standard off-the-shelf PC modem as a telephone interface. The features provided by this option are:

- Call to a remote terminal or pager based on programmable events and alarms
- Four separate, programmable notification groups (phone numbers)
- Automatic answering (user-configurable) for access to the Terminal mode of the UPS
- Remote and local ability to clear Call Out alarms and events
- Error detection and correction for misconfigured and disconnected modems.

Remote Notification provides the user with the option of receiving alarms and notices at a remote location. Using the Terminal mode, the user calls the UPS to perform basic monitoring. In the event of a UPS alarm or notice, the user is notified at the remote location. The UPS calls through the modem to the user's computer or pager and leaves a message.

Remote Notification is an extension of the Terminal mode with the additional support algorithms necessary to control an external modem. Connection to the UPS is made when a user calls the UPS on the phone. The user has exactly the same capabilities as if using a terminal connected directly to an RS-232 port.

Remote Notification differs from the basic Terminal mode with the addition the following functions:

- Call Answer

The Call Answer function allows the user to call into the UPS from a remote location and enter Terminal mode.

- Call Out

The Call Out function allows the UPS to be configured to call either a remote computer or numeric paging service over the phone line. Call Out allows the UPS to call a remote computer and leave a one-line descriptive message of the alarm or notice condition. Numeric paging support allows the UPS to call a paging service and send numeric messages.

- Housekeeping

The Housekeeping function maintains the link between the UPS and modem.

## 8.5 Terminal Mode

In Terminal mode, the user can request the following functions:




---

**NOTE** The brackets ([ ]) in the following bullets indicate standard keyboard characters. To use a key combination, hold down the Escape key and press the indicated letter key.

---

- [ESC] [A] displays the Active Alarms.
- [ESC] [H] displays the Event History.
- [ESC] [N] displays the Node Bits Setup.
- [ESC] [Q] Quit.

### 8.5.1 Display UPS Control Panel

When this function is invoked, a facsimile of the UPS control panel is displayed on the terminal screen. All controls are functional and can control the UPS remotely. The only exception is the Load Off control which requires the operator to press and hold the local control for two seconds to shut down the UPS.

To remotely control the UPS or view UPS information, use the Escape key legend to control the function normally controlled by the control panel softkeys. See paragraph 7.2 on page 7-2, "Using the Control Panel," for instructions on navigating the control panel.

## 8.5.2 Event History Log

This key sequence prints the entire Event History Log of the UPS at the time the data is requested. The printout begins with the oldest alarm entry in the queue and ends with the most recent. Any alarms that occur while the Event History Log is printing are included in chronological order.

The Event History Log lists up to 2048 system events in chronological order with the most recent event listed last. Figure 8-2 shows a sample Event History Log printout.

In this mode, system events are continually logged through the serial port to the device connected to the port.

The printed log entries contain a time and date stamp and the alarm text message. Terminal mode uses this format for printing alarm entries:

**MM DD YYYY HH:MM:SS.hh KYWD MESSAGE <CR> <LF>**

Where	Equals
MM	Month (2 digits)
DD	Day (2 digits)
YYYY	Year (4 digits)
HH	Hour (2 digits)
MM	Minute (2 digits)
SS	Second (2 digits)
hh	Hundredths of Second (3 digits)
KYWD	Keyword (ALARM, NOTICE, COMMAND, or STATUS)
Message	System Diagnostic Information
<CR>	Carriage Return Character (ASCII 13)
<LF>	Line Feed (ASCII 10)

An alarm message is prefixed by the word “CLEAR” whenever an alarm is entered into the Event History Log with a cleared status.

If a port is operating in Terminal mode and is connected to a computer, you can press **[Esc] [H]** to print the entire log with a firmware version header. The log in Terminal mode is always in English.

**MODEL: EATON 9395**  
**CTO: TF1271000000**  
**SERIAL:**

<b>MCU DSP:</b>	<b>70.81.14</b>	
<b>MCU BOOTLOADER:</b>		<b>80.40</b>
<b>MCU PLD:</b>	<b>1.00</b>	
<b>PMF 1 DSP:</b>	<b>80.81.14</b>	
<b>PMF 1 BOOTLOADER:</b>		<b>80.40</b>
<b>PMF 1 PLD:</b>	<b>1.00</b>	
<b>X SLOT CAN BRIDGE:</b>		<b>0.00</b>
<b>CSB DSP:</b>	<b>70.81.14</b>	
<b>CSB BOOTLOADER:</b>		<b>1.12</b>
<b>DISPLAY:</b>	<b>1.06</b>	

**TIME: 19:17:16 DATE: 03/23/2099**

03/16/2099 21:25:20.355 S138: CONTROL POWER ON (PM1)  
 03/16/2099 21:25:20.515 N011: OUTPUT UNDER OR OVER FREQ (PM1)  
 03/16/2099 21:25:20.675 S302: EEPS CONFIGURING (PM1)  
 03/16/2099 21:25:23.475 N267: POWER MODULE CABLE FAIL 15 (PM1)  
 03/16/2099 21:25:25.180 N271: DC HW AMPS LIMIT (PM1)  
 03/16/2099 21:25:25.215 N007: INPUT AC UNDER VOLTAGE (PM1)  
 03/16/2099 21:25:25.850 N011: OUTPUT UNDER OR OVER FREQ OK (PM1)  
 ...  
 03/23/2099 18:59:20.225 A199: BATTERIES DISCONNECTED (PM1)

**ACTIVE ALARMS:**

11 NOTICE: OUTPUT UNDER OR OVER FREQ (PM1)  
 12 ALARM: REMOTE EMERGENCY POWER OFF (MCU)  
 102 NOTICE: INVERTER L1 CURRENT LIMIT (PM1)  
 103 NOTICE: INVERTER L2 CURRENT LIMIT (PM1)  
 104 NOTICE: INVERTER L3 CURRENT LIMIT (PM1)

**Figure 8-2. Sample Event History Log**



## 8.6 Building Alarm Monitoring

This standard feature lets you connect the UPS to your building alarms, such as smoke detectors or overtemperature alarms. The customer interface terminals for external connections are located inside the UPS. You should use twisted-pair wires for each alarm input and common.

The building alarms can be programmed to display the alarm functional name.

## 8.7 General Purpose Relay Contact

One general purpose relay contact is provided as a standard feature on the UPS. The alarm contact is located inside the UPS on the customer interface terminal board.

You can use a normally-closed or normally-open contact. If the state of the contact changes from the state you specify as normal, a signal is issued. You can connect this contact to equipment at your facility (such as a light or an alarm bell) to let you know when an alarm is active on the UPS. This feature is useful if the UPS is located in a remote area where the UPS horn may not be heard immediately.



### CAUTION

Contacts should not be operated in excess of 30 Vac @ 5A maximum.

## 8.8 Remote Monitor Panel II

As an option, an Remote Monitor Panel II (RMP II) can be installed to monitor the operation of the UPS system from virtually any location within the facility, up to 150m (500 ft) from the UPS. The RMP II contains backlit status indicators and a local horn. The RMP II can be flush-mounted or surface-mounted on a desktop, or secured to a wall. Figure 8-3 shows an RMP II front panel.




Figure 8-3. Remote Monitor Panel II Front Panel

The RMP II contains a local horn and the backlit status indicators listed in Table 8-1.

**Table 8-1. RMP II Status Indicators**

**SYSTEM NORMAL**

The UPS is energized (either with utility power or battery backup) and is supplying conditioned power to the critical load.

**NO REDUNDANCY**

This indicator applies only to parallel systems when one cabinet is not functioning.

**ON GENERATOR**

The UPS input and bypass are being supplied by the power from the generator instead of from the utility power.

**ON BYPASS**

The bypass source is supplying the critical load. Usually this means that the UPS is not energized. The load is not protected in Bypass mode, and a horn sounds after 30 seconds.

**UPS ALARM**

The UPS system is issuing an alarm. Conditions that affect the current UPS mode are indicated by the indicators and horn on the UPS.

**ON BATTERY**


The UPS battery backup is supplying the critical load. The utility power is either interrupted or out of specification. The SYSTEM NORMAL indicator is also illuminated.

**BYPASS UNAVAILABLE**

The UPS system is in Normal mode, but a bypass source is not within specification. A horn sounds after 30 seconds.


**SHUTDOWN IMMINENT**

The UPS is preparing to shut down because the UPS is in Battery mode and the DC voltage is approaching its low limit. This indicator is accompanied by a horn.



## 8.9 Relay Interface Module II

An optional Relay Interface Module II (RIM II) uses relay contact closures to indicate the operating status and alarm condition of the UPS system. The module uses a serial interface line and may support up to eight critical loads. The RIM II can be flush-mounted or surface-mounted on a desktop, or secured to a wall. Figure 8-4 shows the RIM II with its four 15-pin connectors labeled J1 through J4.



**Figure 8-4. Relay Interface Module II Customer Interface Connectors J1 through J4**


The RIM II can provide the status and alarm signals shown in Table 8-2.

**Table 8-2. Customer Interface Connectors**

Status	J1 through J4	Description
<b>UPS AVAILABLE</b>	Pins 1 and 12	Contacts are closed when the UPS is operating in Normal mode or ready to supply the load.
<b>UPS OFFLINE</b>	Pins 3 and 13	Contacts are open when the UPS is offline. Contacts are closed when the UPS is operating in Normal mode.
<b>BATTERY WEAK</b>	Pins 5 and 14	Contacts are closed when approximately two minutes of battery time is remaining before the critical load is lost.
<b>UTILITY FAILURE</b>	Pins 6 and 15	Contacts are closed when Utility Failure is detected.

## 8.10 Supervisory Contact Module II

An optional Supervisory Contact Module II (SCM II) establishes an interface between the UPS system and the customer's monitor. This interface allows the customer to monitor operational status of the UPS system equipment. The SCM II can be flush-mounted or surface-mounted on a desktop, or secured to a wall. Figure 8-5 shows the SCM II.



**Figure 8-5. Supervisory Contact Module II Enclosure**

The SCM II provides signals for the indications shown in Table 8-3.

**Table 8-3. SCM II Status Indicators and Connections**

<b>Indication</b>	<b>TB2 Connections</b>
<b>SYSTEM NORMAL</b>	TB2-1 through TB2-3
<b>NO REDUNDANCY</b>	TB2-4 through TB2-6
<b>ON GENERATOR</b>	TB2-7 through TB2-9
<b>BYPASS NOT AVAILABLE</b>	TB2-10 through TB2-12
<b>ON BATTERY</b>	TB2-13 through TB2-15
<b>UPS ALARM</b>	TB2-16 through TB2-18
<b>ON BYPASS</b>	TB2-19 through TB2-21
<b>SHUTDOWN IMMINENT</b>	TB2-22 through TB2-24

## Chapter 9

# UPS Maintenance

The components inside the UPS cabinet are secured to a sturdy metal frame. All repairable parts and assemblies are located for easy removal, with very little disassembly. This design allows authorized service personnel to perform routine maintenance and servicing quickly.

You must schedule periodic performance checks of your UPS system to keep it running properly. Regular routine checks of operation and system parameters enable your system to function efficiently for many trouble-free years.

### 9.1 Important Safety Instructions

Remember that your UPS system is designed to supply power **EVEN WHEN DISCONNECTED FROM THE UTILITY POWER**. The UPS module interiors are unsafe until the DC power source is disconnected and the electrolytic capacitors are discharged. After disconnecting the utility power and the DC power, authorized service personnel should wait at least five minutes for capacitor bleedoff before attempting internal access to the UPS module.



#### WARNING

- Servicing and maintenance should be performed by qualified service personnel only.
- **LETHAL VOLTAGE PRESENT.** This unit should not be operated with the cabinet doors open or protective panels removed. Do not make any assumptions about the electrical state of any cabinet in the UPS system.

Because each battery string is an energy source in itself, opening the battery circuit breaker does not de-energize the voltage within the battery string. **DO NOT ATTEMPT TO ACCESS ANY INTERNAL AREA OF THE BATTERY STRING YOURSELF. VOLTAGES ARE ALWAYS PRESENT IN THE BATTERY STRING.** If you suspect that a battery string needs service, contact an Eaton service representative.

If the string requires service, refer to the battery manufacturer's operating manual for instructions on battery maintenance or contact an Eaton service representative.

Observe these precautions when working on or around batteries:

- Remove watches, rings, or other metal objects.
- Use tools with insulated handles.
- Wear rubber gloves and boots.
- Do not lay tools or metal parts on top of batteries.
- Disconnect the charging source prior to connecting or disconnecting terminals.
- Determine if the battery is inadvertently grounded. If it is, remove the source of the ground. Contact with any part of a grounded battery can result in electrical shock. The likelihood of such shock is reduced if such grounds are removed during installation and maintenance.
- When replacing batteries, use the same number of sealed, lead-acid batteries.

- Proper disposal of batteries is required. Refer to your local codes for disposal requirements.
- Do not dispose of batteries in a fire. Batteries may explode when exposed to flame.
- Do not open or mutilate batteries. Released electrolyte is harmful to the skin and eyes. It may be toxic.

## 9.2 Performing Preventive Maintenance

The UPS system requires very little preventive maintenance. However, the system should be inspected periodically to verify that the units are operating normally and that the batteries are in good condition.

### 9.2.1 DAILY Maintenance

Perform the following steps daily:

1. Check the area surrounding the UPS system. Ensure the area is not cluttered, allowing free access to the unit.
2. Ensure the air intakes (vents on the front door or panels) and the exhaust openings (on top of the UPM section) are not blocked.
3. Ensure the operating environment is within the parameters specified in paragraph 3.2.1 on page 3-1 and Chapter 10, "Product Specifications."
4. Ensure the UPS is in Normal mode (Normal status indicator is illuminated). If an alarm lamp is illuminated or the Normal status indicator is not illuminated, contact an Eaton service representative.

### 9.2.2 MONTHLY Maintenance

Perform the following steps monthly:

1. Monitor system parameters as described in paragraph 7.2, "Using the Control Panel" on page 3-1.
2. Check the UPS air filters (located behind the front panels or door) and wash or replace as necessary. See Figure 9-1 or Figure 9-2 and Figure 9-3 for filter locations, and Table 9-1 for filter sizes. Contact an Eaton service representative for replacement filters. To remove and replace the filters:

**Table 9-1. UPS Filter Sizes**


Filter Location	Size
Bottom Left ISBM Section Air Filters (Momentary Static Switch and Continuous Static Switch)	12" × 20" × 0.25"
Bottom Right ISBM Section Air Filters (Continuous Static Switch only)	12" × 20" × 0.25"
Middle Right ISBM Section Air Filter (Continuous Static Switch only)	20" × 6.3" × 0.25"
UPM Section Air Filters	20" × 44" × 0.25"




### CAUTION

Verify washed filters are thoroughly dry before reinstalling.

- a. Remove one top screw and two bottom screws securing each UPM section front panel (see Figure 4-3 on page 4-4). Lift the panel straight up to remove it from the panel hanger bracket at the top of the cabinet.
- b. Remove one top screw and two bottom screws securing each ISBM section front panel (see Figure 4-2 on page 4-3). Lift the panel straight up to remove it from the panel hanger bracket at the top of the cabinet.
- c. If the UPS is a continuous static switch configuration, unfasten the front door latch and swing the door open (see Figure 4-1 on page 4-2).
- d. Pull the foam filters over the screw heads on the cabinet mounted studs and remove the filters from the cabinet.
- e. Push the washed or new foam filters over the screw heads on the cabinet mounted studs until seated against the cabinet.
- f. Reinstall the UPM section front panels removed in Step a and secure with the retained hardware.
- g. Reinstall the ISBM section front panel removed in Step b and secure with the retained hardware.
- h. If opened, close the front door and secure the latch.




**Figure 9-1. ISBM Section Air Filter Locations – Momentary Static Switch**



**Figure 9-2. ISBM Section Air Filter Locations – Continuous Static Switch**





**Figure 9-3. UPM Section Air Filter Locations**


3. If the UPS is a four UPM model, check the Field Installed UPM (FI-UPM) air filter (located behind the front panel) and wash or replace as necessary. See Figure 9-4 for the filter location. The FI-UPM filter size is 20" × 44" × 0.25". Contact an Eaton service representative for a replacement filter. To remove the filter:
  - a. Remove one top screw and two bottom screws securing the FI-UPM front panel (refer to the *Eaton 9395 Field Installed UPM Mechanical Installation Manual*). Lift the panel straight up to remove it from the panel hanger bracket at the top of the cabinet.
  - b. Pull the foam filter over the screw heads on the cabinet mounted studs and remove the filter from the cabinet.



### CAUTION

Verify washed filter is thoroughly dry before reinstalling.

- c. Push the washed or new foam filter over the screw heads on the cabinet mounted studs until seated against the cabinet.
  - d. Reinstall the FI-UPM front panel removed in Step a and secure with the retained hardware.
4. Record maintenance results and any corrective actions in a suitable log.



**Figure 9-4. FI-UPM Air Filter Location**

### 9.2.3 PERIODIC Maintenance

Periodic inspections of the UPS should be made to determine if components, wiring, and connections exhibit evidence of overheating. Particular attention should be given to bolted connections. Maintenance procedures should specify that the bolted connections be retorqued to values listed in this manual.

### 9.2.4 ANNUAL Maintenance

Annual preventive maintenance should be performed only by authorized service personnel familiar with maintenance and servicing of the UPS system. Contact an Eaton service representative for more information about service offerings.

### 9.2.5 BATTERY Maintenance

Contact an Eaton service representative for battery maintenance. Battery replacement and maintenance should be performed only by authorized service personnel.

## 9.3 Installing Batteries



**NOTE** *There is no manual DC disconnect device within the UPS.*

Install batteries in accordance with the battery and battery system manufacturer's instructions.

## 9.4 Recycling the Used Battery or UPS

Contact your local recycling or hazardous waste center for information on proper disposal of the used battery or UPS.



### WARNING

- Do not dispose of the battery or batteries in a fire. Batteries may explode. Proper disposal of batteries is required. Refer to your local codes for disposal requirements.
- Do not open or mutilate the battery or batteries. Released electrolyte is harmful to the skin and eyes. It may be toxic.
- A battery can cause electrical shock, burn from high short-circuit current, or fire. Observe proper precautions.



### ATTENTION!

- Une batterie peut présenter un risque de choc électrique, de brûlure, ou d'incendie. Suivre les précautions qui s'imposent.
- Pour le remplacement, utiliser le même nombre et modèle des batteries.
- L'élimination des batteries est réglementée. Consulter les codes locaux à cet effet.



### CAUTION

Do not discard the UPS or the UPS batteries in the trash. This product contains sealed, lead-acid batteries and must be disposed of properly. For more information, contact your local recycling/reuse or hazardous waste center.



### CAUTION

Do not discard waste electrical or electronic equipment (WEEE) in the trash. For proper disposal, contact your local recycling/reuse or hazardous waste center.

## 9.5 Maintenance Training

A basic training course, available from Eaton Corporation, gives you a competent working knowledge of the UPS system operation and teaches you how to perform first level corrective maintenance. For more information about training and other services, contact the Eaton Help Desk (see page 1-10).

This page intentionally left blank.

## Chapter 10

## Product Specifications

### 10.1 Model Numbers

The UPS is housed in a free-standing cabinet, divided into two sections with safety shields behind the door and front panels. The UPS is available in 50 or 60 Hz with various output power ratings.

Models	Power Rating	Frequency
Eaton 9395-1100/1000 (four UPM)	1000 kVA	50/60 Hz
Eaton 9395-1100/1100 (four UPM)	1100 kVA	50/60 Hz
Eaton 9395-1100/650 (three UPM)	650 kVA	50/60 Hz
Eaton 9395-1100/750 (three UPM)	750 kVA	50/60 Hz
Eaton 9395-1100/825 (three UPM)	825 kVA	50/60 Hz

### 10.2 Specifications

The following sections detail the input, output, environmental, and battery specifications for the UPS.

#### 10.2.1 UPS Input

<b>Operating Input Voltage</b>	400 Vac 480 Vac
<b>Operating Input Frequency Range</b>	50/60 Hz
<b>Operating Input Current</b>	See Table 3-4 on page 3-11 or Table 3-5 on page 3-12 for four UPM models.  See Table 3-6 on page 3-13 or Table 3-7 on page 3-14 for three UPM models.  Reduced for Generator Adjustable
<b>Input Current Harmonic Content</b>	5% THD at full load
<b>Power Factor</b>	Minimum 0.99
<b>Line Surges</b>	6 kV OC, 3 kA SC per ANSI 62.41 and IEC 801-4
<b>Battery Voltage</b>	480 Vdc
<b>Battery Charging Capacity</b>	Configurable per UPM at nominal line voltage: Up to 120A with less than 85% load Up to 80A with 100% load
<b>Battery Shunt Trip</b>	48 Vdc

### 10.2.2 UPS Output

<b>UPS Output Capacity</b>	100% rated current
<b>Output Voltage Regulation</b>	± 1% (10% to 100% load)
<b>Output Voltage Adjustment (Nominal +/-3%)</b>	400 Vac nominal, adjustable from 388 Vac to 412 Vac 480 Vac nominal, adjustable from 466 Vac to 494 Vac
<b>Output Voltage Harmonic Content</b>	1.5% maximum THD (linear load) 5% maximum THD (nonlinear load)
<b>Output Current</b>	See Table 3-4 on page 3-11 or Table 3-5 on page 3-12 for four UPM models.  See Table 3-6 on page 3-13 or Table 3-7 on page 3-14 for three UPM models.
<b>Output Voltage Balance</b>	3% for 100% maximum load imbalance (linear load)
<b>Output Voltage Phase Displacement</b>	3° for 100% maximum load imbalance (linear load)
<b>Output Transients</b>	± 5% (10% to 100% load)
<b>Frequency Regulation</b>	± 0.1 Hz free running
<b>Synchronous to Bypass</b>	+10% to -10% ± 3%
<b>Frequency Slew Rate</b>	1 Hz per second maximum
<b>Load Compatibility</b>	0.9 pF Leading 0.8 pF Lagging
<b>Overload Capability</b>	110% for 10 minutes 125% for 30 seconds 150% for 10 seconds

### 10.2.3 UPS Environmental

<b>Operating Temperature</b>	0 to 40°C (32 to 104°F) without derating. The recommended operating temperature is 25°C (77°F).
<b>Operating Altitude</b>	Maximum 1500m (5000 ft) at 40°C without derating
<b>Storage Temperature</b>	-25 to +60°C, excluding batteries (prolonged storage above 40°C causes rapid battery self-discharge)
<b>Relative Humidity (operating and storage)</b>	5% to 95% maximum noncondensing
<b>Acoustical Noise</b>	83 dB at a 1m distance, A weighted for three UPM UPS 85 dB at a 1m distance, A weighted for four UPM UPS
<b>EMI Suppression</b>	Meets FCC Regulation 47, Part 15, for class A devices
<b>Electrostatic Discharge (ESD) Immunity</b>	Meets IEC 801-2 specifications. Withstands up to 25 kV pulse without damage and with no disturbance or adverse effect to the critical load.

# Warranty

## LIMITED FACTORY WARRANTY FOR THREE-PHASE POWERWARE® UPS PRODUCTS

**WARRANTOR:** The warrantor for the limited warranties set forth herein is Eaton Corporation, a Delaware Corporation (“Eaton”).

**LIMITED WARRANTY:** This limited warranty (this “Warranty”) applies only to the original end-user (the “End-User”) of the Powerware Three-Phase UPS Products (the “Product”) and cannot be transferred. This Warranty applies even in the event that the Product is initially sold by Eaton for resale to an End-User.

**LIMITED WARRANTY PERIOD:** The period covered by this Warranty for Product installed [and currently located] in the fifty (50) United States and the District of Columbia is twelve (12) months from the date of Product start-up or eighteen (18) months from the date of Product shipment, whichever occurs first, for parts coverage and 90 days from the date of Product start-up for labor coverage. The period covered by this Warranty for Product installed [and currently located] outside of the fifty (50) United States and the District of Columbia is twelve (12) months from the date of Product start-up or eighteen (18) months from the date of Product shipment, whichever occurs first, for parts coverage.

**WHAT THIS LIMITED WARRANTY COVERS:** The warrantor warrants that the Powerware three-phase UPS electronics, Eaton-built accessories, and Powerware-built battery cabinets (individually and collectively, the “Warranted Items”) are free from defects in material and workmanship. If, in the opinion of Eaton, a Warranted Item is defective and the defect is within the terms of this Warranty, Eaton’s sole obligation will be to repair or replace such defective item (including by providing service, parts, and labor, as applicable), at the option of Eaton. The Warranted Item will be repaired or replaced onsite at the End-User’s location or such other location as determined by Eaton. Any parts that are replaced may be new or reconditioned. All parts replaced by Eaton shall become the property of Eaton.

**WHAT THIS LIMITED WARRANTY DOES NOT COVER:** This Warranty does not cover any defects or damages caused by: (a) failure to properly store the Product before installation, including the “trickle charge” of batteries no later than the date indicated on the packaging; (b) shipping and delivery of the Product if shipping is FOB Factory; (c) neglect, accident, fire, flood, lightning, vandalism, acts of God, Customer’s neglect, abuse, misuse, misapplication, incorrect installation; (d) repair or alteration not authorized in writing by Eaton personnel or performed by an authorized Eaton Customer Service Engineer or Agent; or (e) improper testing, operation, maintenance, adjustment, or any modification of any kind not authorized in writing by Eaton personnel or performed by an authorized Eaton Customer Service Engineer or Agent.

This Warranty is not valid: (a) unless an authorized Eaton Customer Service Engineer (in the USA) or Agent (outside of the USA) performs startup and commissioning of the Product; (b) if the Product is moved to a new location by someone other than an authorized Eaton Customer Service Engineer (in the USA) or Agent (outside of the USA); or (c) if the Product’s serial numbers have been removed or are illegible. Any Warranted Items repaired or replaced pursuant to this Warranty will be warranted for the remaining portion of the original Warranty subject to all the terms thereof. Labor warranty is not provided for Product located outside of the fifty (50) United States or the District of Columbia. Any equipment, parts, or materials included in the Product and not manufactured by Eaton are warranted solely by the manufacturer of such equipment, parts, or materials and are not included as part of this Warranty. Batteries are not warranted by Eaton.

**THIS WARRANTY IS THE END-USER’S SOLE REMEDY AND IS EXPRESSLY IN LIEU OF, AND THERE ARE NO OTHER EXPRESSED OR IMPLIED GUARANTEES OR WARRANTIES (INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR ANY PURPOSE, WHICH ARE EXPRESSLY DISCLAIMED).**

**LIMITATION OF LIABILITY:** In no event shall Eaton be liable for any indirect, incidental, special, or consequential damages of any kind or type whatsoever, or based on any claim or cause of action, however denominated. Eaton shall not be responsible for failure to provide service or parts due to causes beyond Eaton’s reasonable control. In no case will Eaton’s liability under this Warranty exceed the replacement value of the Warranted Items.

**END-USER’S OBLIGATIONS:** In order to receive the benefits of this Warranty, the End-User must use the Product in a normal way, follow the Product’s installation, operation and maintenance manual, and protect against further damage to the Product if there is a covered defect.

**OTHER LIMITATIONS:** Eaton’s obligations under this Warranty are expressly conditioned upon receipt by Eaton of all payments due to it (including interest charges, if any). During such time as Eaton has not received payment of any amount due to it for the Product, in accordance with the contract terms under which the Product is sold, Eaton shall have no obligation under this Warranty. Also during such time, the period of this Warranty shall continue to run and the expiration of this Warranty shall not be extended upon payment of any overdue or unpaid amounts.

**COSTS NOT RELATED TO WARRANTY:** The End-User shall be invoiced for, and shall pay for, all services not expressly provided for by the terms of this Warranty, including without limitation site calls involving an inspection that determines no corrective maintenance is required. Any costs for replacement equipment, installation, materials, freight charges, travel expenses, or labor of Eaton representatives outside the terms of this Warranty will be borne by the End-User.

**OBTAINING WARRANTY SERVICE:** In the USA, call the Eaton Customer Reliability Center 7x24 at 800-843-9433. Outside of the USA, call your local Eaton sales or service representative, or call the Eaton Customer Reliability Center in the USA at 919-870-3028. For comments or questions about this Limited Factory Warranty, write to the Customer Quality Representative, 3301 Spring Forest Road, Raleigh, North Carolina 27616 USA.

This page intentionally left blank.







164201764 2